

Rosemount 848T High Density Temperature Transmitter with FOUNDATION™ fieldbus

Device Revision 8



Rosemount 848T High Density Temperature Transmitter with FOUNDATION™ fieldbus

⚠ CAUTION

Read this manual before working with the product. For personal and system safety, and for optimum product performance, make sure to thoroughly understand the contents before installing, using, or maintaining this product.

The United States has two toll-free assistance numbers and one international number

Customer Central

1-800-999-9307 (7:00 a.m. to 7:00 p.m. CST)

National Response Center

1-800-654-7768 (24 hours a day)

Equipment service needs

International

1-(952) 906-8888

⚠ CAUTION

The products described in this document are NOT designed for nuclear-qualified applications.

Using non-nuclear qualified products in applications that require nuclear-qualified hardware or products may cause inaccurate readings.

For information on Rosemount nuclear-qualified products, contact an Emerson Process Management Sales Representative.]

Section 1: Introduction

1.1 Safety messages.....	1
1.1.1 Warnings	1
1.2 Overview	2
1.2.1 Transmitter	2
1.2.2 Manual	2
1.3 Service support.....	3

Section 2: Installation

2.1 Safety messages.....	5
2.1.1 Warnings	5
2.2 Mounting.....	5
2.2.1 Mounting to a DIN rail without an enclosure	6
2.2.2 Mounting to a panel with a junction box	6
2.2.3 Mounting to a 2-in. pipe stand.....	7
2.3 Wiring.....	8
2.3.1 Connections.....	8
2.3.2 Power supply	11
2.3.3 Surges/transients	11
2.4 Grounding	11
2.5 Switches.....	14
2.6 Tagging	14
2.7 Installation.....	16
2.7.1 Using cable glands	16
2.7.2 Using conduit entries	17

Section 3: Configuration

3.1 Safety messages.....	19
3.1.1 Warnings	19
3.2 Configuration	20
3.2.1 Standard.....	20
3.2.2 Transmitter configuration.....	20
3.2.3 Custom configuration	20
3.2.4 Methods.....	20
3.2.5 Alarms.....	21
3.2.6 Damping.....	21
3.2.7 Configure the differential sensors	21
3.2.8 Configure measurement validation	22

3.3	Common configurations for high density applications	22
3.3.1	Interfacing analog transmitters to Foundation fieldbus	25
3.4	Block configuration	25
3.4.1	Resource block	25
3.4.2	Field Diagnostics & PlantWeb Alerts	31
3.4.3	PlantWeb alerts	32
3.4.4	Recommended actions for PlantWeb alerts	35
3.4.5	Field Diagnostics Alerts	36
3.4.6	Recommended actions for field diagnostics alerts	40
3.4.7	Transducer blocks	41
3.4.8	Transducer block sub-parameter tables	47

Section 4: Operation and Maintenance

4.1	Safety messages	53
4.1.1	Warnings	53
4.2	Foundation™ fieldbus information	53
4.2.1	Commissioning (addressing)	54
4.3	Hardware maintenance	54
4.3.1	Sensor check	54
4.3.2	Communication/power check	54
4.3.3	Resetting the configuration (RESTART)	55
4.4	Troubleshooting	55
4.4.1	Foundation fieldbus	55
4.4.2	Resource block	56
4.4.3	Transducer block troubleshooting	56

Appendix A: Reference Data

A.1	Functional specifications	57
A.1.1	Inputs	57
A.1.2	Outputs	57
A.1.3	Status	57
A.1.4	Ambient temperature limits	57
A.1.5	Isolation	57
A.1.6	Power supply	57
A.1.7	Transient protection	57
A.1.8	Update time	58
A.1.9	Humidity limits	58
A.1.10	Turn-on time	58

A.1.11 Alarms	58
A.1.12 Backup Link Active Scheduler (LAS)	58
A.2 Physical specifications	58
A.2.1 Mounting	58
A.2.2 Entries for optional junction box	58
A.2.3 Environmental ratings	59
A.3 Function blocks	59
A.3.1 Analog input (AI)	59
A.3.2 Input selector (ISEL)	59
A.3.3 Multiple analog input block (MAI)	59
A.4 Performance specifications	60
A.4.1 Stability	60
A.4.2 Self calibration	60
A.4.3 Vibration effect	60
A.4.4 Electromagnetic compatibility compliance testing	60
A.4.5 Accuracy	60
A.4.6 Differential configuration notes	61
A.4.7 Accuracy for differential configurations	61
A.4.8 Analog sensors 4–20mA	61
A.4.9 Ambient temperature effect	62
A.4.10 Ambient temperature effects	62
A.4.11 Ambient temperature notes	63
A.5 Dimensional drawings	64
A.5.1 Mounting options	66
A.6 Ordering information	67

Appendix B: Product Certificates

B.1 North American Approvals	69
B.1.1 European Approvals	72
B.2 Intrinsically Safe and Non-Incendive installations	78
B.3 Installation drawings	79

Appendix C: Foundation™ fieldbus Technology

C.1 Overview	89
C.2 Function blocks	89
C.3 Device descriptions	90
C.4 Block operation	91
C.4.1 Instrument-specific function blocks	91


C.4.2 Alerts	91
C.5 Network communication	91
C.5.1 LAS	92
C.5.2 Addressing	93
C.5.3 Scheduled transfers	94
C.5.4 Unscheduled transfers	95
C.5.5 Function block scheduling	96

Appendix D: Function Blocks

D.1 Analog Input (AI) function block	97
D.1.1 Functionality	100
D.1.2 AI block troubleshooting	105
D.2 Multiple analog input (MAI) function block	106
D.2.1 Functionality	108
D.2.2 MAI block troubleshooting	112
D.3 Input selector function block	113
D.3.1 Functionality	115
D.3.2 ISEL block troubleshooting	119

Section 1 Introduction

1.1 Safety messages

Instructions and procedures in this section may require special precautions to ensure the safety of the personnel performing the operations. Information that potentially raises safety issues is indicated by a warning symbol () . Refer to the following safety messages before performing an operation preceded by this symbol.

1.1.1 Warnings

WARNING

Failure to follow these installation guidelines could result in death or serious injury.

- Make sure only qualified personnel perform the installation.

Process leaks could result in death or serious injury.

- Do not remove the thermowell while in operation. Removing while in operation may cause process fluid leaks.
- Install and tighten thermowells and sensors before applying pressure, or process leakage may result.

Electrical shock could cause death or serious injury.

- If the sensor is installed in a high voltage environment and a fault condition or installation error occurs, high voltage may be present on transmitter leads and terminals.
 - Use extreme caution when making contact with the leads and terminals.
-

1.2 Overview

1.2.1 Transmitter

The Rosemount 848T is optimal for process temperature measurement because of its ability to simultaneously measure eight separate and independent temperature points with one transmitter. Multiple temperature sensor types may be connected to each transmitter. In addition, the 848T can accept 4-20 mA inputs. The enhanced measurement capability of the 848T allows it to communicate these variables to any FOUNDATION™ fieldbus host or configuration tool.

1.2.2 Manual

This manual is designed to assist in the installation, operation, and maintenance of the Rosemount 848T Temperature Transmitter.

Section 1: Introduction

- Overview
- Considerations
- Return of Materials

Section 2: Installation

- Mounting
- Installation
- Wiring
- Power Supply
- Commissioning

Section 3: Configuration

- FOUNDATION fieldbus Technology
- Configuration
- Function Block Configuration

Section 4: Operation and Maintenance

- Hardware Maintenance
- Troubleshooting

Appendix A: Reference Data

- Specifications
- Dimensional Drawings
- Ordering Information

Appendix B: Product Certificates

- Hazardous Locations Certificates
- Intrinsically Safe and Non-Incendive Installations
- Installation Drawings

Appendix C: Foundation™ fieldbus Technology

- Device Descriptions
- Block Operation

Appendix D: Function Blocks

- Analog Input (AI) Function Block
- Multiple Analog Input (MAI) Function Block
- Input Selector Function Block

1.3 Service support

To expedite the return process in North America, call the Emerson Process Management National Response Center toll-free at 800-654-7768. This center, available 24 hours a day, will assist with any needed information or materials.



The center will ask for the following information:

- Product model
- Serial numbers
- The last process material to which the product was exposed

The center will provide the following:

- A Return Material Authorization (RMA) number
- Instructions and procedures that are necessary to return goods that were exposed to hazardous substances

For other locations, contact an Emerson Process Management sales representative.

Note

If a hazardous substance is identified, a Material Safety Data Sheet (MSDS), required by law to be available to people exposed to specific hazardous substances, must be included with the returned materials.

Section 2 Installation

Safety messages	page 5
Mounting	page 5
Wiring	page 8
Grounding	page 11
Switches	page 14
Tagging	page 14
Installation	page 16

2.1 Safety messages

Instructions and procedures in this section may require special precautions to ensure the safety of the personnel performing the operations. Information that potentially raises safety issues is indicated by a warning symbol (⚠). Refer to the following safety messages before performing an operation preceded by this symbol.

2.1.1 Warnings

WARNING

Failure to follow these installation guidelines could result in death or serious injury.

- Make sure only qualified personnel perform the installation.

Process leaks could result in death or serious injury.

- Do not remove the thermowell while in operation. Removing while in operation may cause process fluid leaks.
- Install and tighten thermowells and sensors before applying pressure, or process leakage may result.

Electrical shock could cause death or serious injury.

- If the sensor is installed in a high voltage environment and a fault condition or installation error occurs, high voltage may be present on transmitter leads and terminals.
 - Use extreme caution when making contact with the leads and terminals.
-

2.2 Mounting

The 848T is always mounted remote from the sensor assembly. There are three mounting configurations.


- To a DIN rail without an enclosure
- To a panel with an enclosure
- To a 2-in pipe stand with an enclosure using a pipe mounting kit

2.2.1 Mounting to a DIN rail without an enclosure

To mount the 848T to a DIN rail without an enclosure, follow these steps:

1. Pull up the DIN rail mounting clip located on the top back side of the transmitter.
2. Hinge the DIN rail into the slots on the bottom of the transmitter.
3. Tilt the 848T and place onto the DIN rail. Release the mounting clip. The transmitter should be securely fastened to the DIN rail.

Figure 2-1. Mounting the 848T to a DIN Rail




- A. DIN Rail Mounting Clip
- B. 848T without installed enclosure
- C. DIN Rail

2.2.2 Mounting to a panel with a junction box

When inside of a plastic or aluminum junction box, the 848T mounts to a panel using four 1/4-20 x 1.25-in. screws.

When inside of a stainless steel junction box, the 848T mounts to a panel using two 1/4-20 x 1/2-in. screws.

Figure 2-2. Mounting the 848T Junction Box to a Panel




- A. 848T with aluminum or plastic box
- B. Cover screws (4)
- C. Mounting screws (4 for aluminum/plastic mounting, 2 for stainless steel mounting)
- D. Panel
- E. 848T with a stainless steel box

2.2.3 Mounting to a 2-in. pipe stand

Use the optional mounting bracket (option code B6) to mount the 848T to a 2-in. pipe stand when using a junction box.

Figure 2-3. Mounting the 848T to a 2-in. Pipe Stand Using a Junction Box



2.3 Wiring




If the sensor is installed in a high-voltage environment and a fault condition or installation error occurs, the sensor leads and transmitter terminals could carry lethal voltages. Use extreme caution when making contact with the leads and terminals.

Note

Do not apply high voltage (e.g. AC line voltage) to the transmitter terminals. Abnormally high voltage can damage the unit (bus terminals are rated to 42.4 VDC).

Figure 2-4. 848T Transmitter Field Wiring




- A. Integrated Power Conditioner and Filter
- B. 6234 ft (1900 m) max (depending on cable characteristics)
- C. Terminators (Trunk)
- D. Power supply
- E. FOUNDATION™ fieldbus host or configuration tool
- F. Spur
- G. Signal wiring
- H. Devices 1-16 (Intrinsically safe installations may allow fewer devices per I.S. barrier)

2.3.1 Connections

The 848T transmitter is compatible with 2 or 3-wire RTD, thermocouple, ohm, and millivolt sensor types. Figure 2-5 shows the correct input connections to the sensor terminals on the transmitter. The 848T can also accept inputs from analog devices using the optional analog input connector. Figure 2-6 shows the correct input connections to the analog input connector when installed on the transmitter. Tighten the terminal screws to ensure proper connection.

Figure 2-5. Sensor Wiring Diagram



- A. 2-wire RTD and ohms
- B. 3-wire RTD and ohms (Emerson provides 4-wire sensors for all single-element RTDs; use these RTDs in 3-wire configurations by clipping the fourth lead or leaving it disconnected and insulated with electrical tape.)
- C. Thermocouples/ohms and Millivolts
- D. 2-wire RTD with compensation loop (transmitter must be configured for a 3-wire RTD in order to recognize an RTD with a compensation loop)

RTD or ohm inputs

Various RTD configurations, including 2-wire and 3-wire are used in industrial applications. If the transmitter is mounted remotely from a 3-wire RTD, it will operate within specifications, without recalibration, for lead wire resistances of up to 60 ohms per lead (equivalent to 6,000 feet of 20 AWG wire). If using a 2-wire RTD, both RTD leads are in series with the sensor element, so errors can occur if the lead lengths exceed one foot of 20 AWG wire. Compensation for this error is provided when using 3-wire RTDs.

Thermocouple or millivolt inputs

Use appropriate thermocouple extension wire to connect the thermocouple to the transmitter. Make connections for millivolt inputs using copper wire. Use shielding for long runs of wire.

Analog inputs

The analog connector converts the 4–20 mA signal to a 20–100 mV signal that can be read by the 848T and transmitted using FOUNDATION fieldbus.

Use the following steps when installing the 848T with the analog connector:

1. The 848T, when ordered with option code S002, comes with four analog connectors. Replace the standard connector with the analog connector on the desired channels.
2. Wire one or two analog transmitters to the analog connector according to [Figure 2-6](#). There is space available on the analog connector label for identification of the analog inputs.


Note

Power supply should be rated to support the connected transmitter(s).

3. If the analog transmitters can communicate using HART[®] protocol, the analog connectors are supplied with the ability to switch in a 250 ohm resistor for HART communication (see [Figure 2-7](#)).


One switch is supplied for each input (top switch for “A” inputs and bottom switch for “B” inputs). Setting the switch in the “ON” position (to the right) bypasses the 250 ohm resistor. Terminals are provided for each analog input to connect a field communicator for local configuration.

Figure 2-6. 848T Analog Input Wiring Diagram



- A. Analog input connectors
- B. Analog transmitters
- C. Power supply

Figure 2-7. 848T Analog Connector



- A. HART Channel A
- B. 250 ohm resistor in the loop when switched to the left
- C. HART Channel B
- D. Space available for identification of inputs

2.3.2 Power supply

Connections

The transmitter requires between 9 and 32 VDC to operate and provide complete functionality. The DC power supply should provide power with less than 2% ripple. A fieldbus segment requires a power conditioner to isolate the power supply filter and decouple the segment from other segments attached to the same power supply.




All power to the transmitter is supplied over the signal wiring. Signal wiring should be shielded, twisted pair for best results in electrically noisy environments. Do not use unshielded signal wiring in open trays with power wiring or near heavy electrical equipment.

Use ordinary copper wire of sufficient size to ensure the voltage across the transmitter power terminals does not go below 9 VDC. The power terminals are polarity insensitive. To power the transmitter:

1. Connect the power leads to the terminals marked “Bus,” as shown in [Figure 2-8](#).
2. Tighten the terminal screws to ensure adequate contact. No additional power wiring is necessary.

Figure 2-8. Transmitter Label



- A. Ground (required with T1 option)
- B. Connect power leads here

2.3.3 Surges/transients

The transmitter will withstand electrical transients encountered through static discharges or induced switching transients. However, a transient protection option (option code T1) is available to protect the 848T against high-energy transients. The device must be properly grounded using the ground terminal (see [Figure 2-8](#)).

2.4 Grounding

The 848T transmitter provides input/output isolation up to 620 V rms.

Note

Neither conductor of the fieldbus segment can be grounded. Grounding out one of the signal wires will shut down the entire fieldbus segment.


Shielded wire

Each process installation has different requirements for grounding. Use the grounding options recommended by the facility for the specific sensor type or begin with grounding option 1 (most common).

Ungrounded thermocouple, mV, and RTD/ohm inputs

Option 1:


1. Connect signal wiring shield to the sensor wiring shield(s).
2. Ensure shields are tied together and electrically isolated from transmitter enclosure.
3. Only ground shield at the power supply end.
4. Ensure sensor shield(s) is electrically isolated from the surrounding grounded fixtures.



- A. Sensor wires
- B. 848T
- C. Power supply
- D. Shield ground point

Option 2:


1. Connect sensor wiring shield(s) to the transmitter enclosure (only if enclosure is grounded).
2. Ensure sensor shield(s) is electrically isolated from surrounding fixtures that may be grounded.
3. Ground signal wiring shield at the power supply end.



- A. Sensor wires
- B. 848T
- C. Power supply
- D. Shield ground points

Grounded thermocouple inputs


1. Ground sensor wiring shield(s) at the sensor.
2. Ensure that the sensor wiring and signal wiring shields are electrically isolated from the transmitter enclosure.
3. Do not connect the signal wiring shield to the sensor wiring shield(s).
4. Ground signal wiring shield at the power supply end.



- A. Sensor wires
- B. 848T
- C. Power supply
- D. Shield ground points

Analog device inputs

1. Ground analog signal wire at the power supply of the analog devices.
2. Ensure the analog signal wire and the fieldbus signal wire shields are electrically isolated from the transmitter enclosure.
3. Do not connect the analog signal wire shield to the fieldbus signal wire shield.
4. Ground fieldbus signal wire shield at the power supply end.




- A. 4-20 mA loop
- B. FOUNDATION fieldbus bus
- C. Analog device power supply
- D. Analog device
- E. 848T
- F. Power supply
- G. Shield ground points

Transmitter enclosure (optional)

Ground the transmitter in accordance with local electrical requirements.

2.5 Switches

Figure 2-9. Switch Location on the Rosemount 848T



Security

After configuring the transmitter, the data can be protected from unwarranted changes. Each 848T is equipped with a security switch that can be positioned “ON” to prevent the accidental or deliberate change of configuration data. This switch is located on the front side of the electronics module and is labeled SECURITY.

See Figure 2-9 for switch location on the transmitter label.

Simulate enable

The switch labeled SIMULATE ENABLE is used in conjunction with the Analog Input (AI) and Multiple Analog Input (MAI) function blocks. This switch is used to simulate temperature measurement.

Not used

The switch is not functional.


2.6 Tagging

Commissioning tag

The 848T has been supplied with a removable commissioning tag that contains both the Device ID (the unique code that identifies a particular device in the absence of a device tag) and a space to record the device tag [the operational identification for the device as defined by the Piping and Instrumentation Diagram (P&ID)].

When commissioning more than one device on a fieldbus segment, it can be difficult to identify which device is at a particular location. The removable tag, provided with the transmitter, can aid in this process by linking the Device ID to its physical location. The installer should note the physical location of the transmitter on both the upper and lower location of the commissioning tag. The bottom portion should be torn off for each device on the segment and used for commissioning the segment in the control system.

Figure 2-10. Commissioning Tag



- A. Device ID
- B. Device Tag to denote physical location

Transmitter tag

Hardware

- Tagged in accordance with customer requirements
- Permanently attached to the transmitter

Software

- The transmitter can store up to 32 characters.
- If no characters are specified, the first 30 characters of the hardware tag will be used.

Sensor tag

Hardware

- A plastic tag is provided to record identification of eight sensors.
- This information can be printed at the factory upon request.
- In the field, the tag can be removed, printed onto, and reattached to the transmitter.

Software

- If sensor tagging is requested, the Transducer Block SERIAL_NUMBER parameters will be set at the factory.
- The SERIAL_NUMBER parameters can be updated in the field.


2.7 Installation

2.7.1 Using cable glands

Use the following steps to install the 848T with cable glands:

1. Remove the junction box cover by unscrewing the four cover screws.
2. Run the sensor and power/signal wires through the appropriate cable glands using the pre-installed cable glands (see [Figure 2-11](#)).
3. Install the sensor wires into the correct screw terminals (follow the label on the electronics module).
4. Install the power/signal wires onto the correct screw terminals. Power is polarity insensitive, allowing the user to connect positive (+) or negative (-) to either fieldbus wiring terminal labeled "Bus."
5. Replace the enclosure cover and securely tighten all cover screws.

Figure 2-11. Installing the 848T with Cable Glands




- A. Enclosure cover screw (4)
- B. Cable gland
- C. Sensor 1
- D. Sensor 3
- E. Sensor 5
- F. Sensor 7
- G. Power/signal
- H. Sensor 2
- I. Sensor 4
- J. Sensor 6
- K. Sensor 8

2.7.2 Using conduit entries

Use the following steps to install the 848T with conduit entries.

1. Remove the junction box cover by unscrewing the four cover screws.
2. Remove the five conduit plugs and install five conduit fittings (supplied by the installer).
3. Run pairs of sensor wires through each conduit fitting.
4. Install the sensor wires into the correct screw terminals (follow the label on the electronics module).
5. Install the power/signal wires into the correct screw terminals. Power is polarity insensitive, allowing the user to connect positive (+) or negative (-) to either fieldbus wiring terminal labeled "Bus."
6. Replace the junction box cover and securely tighten all cover screws.

Figure 2-12. Installing the 848T with Conduit Entries



- A. Enclosure cover screw
- B. Sensors 1 and 2 conduit
- C. Sensors 3 and 4 conduit
- D. Sensors 5 and 6 conduit
- E. Sensors 7 and 8 conduit
- F. Power/signal

Section 3 Configuration

Safety messages	page 19
Configuration	page 20
Common configurations for high density applications	page 22
Block configuration	page 25

3.1 Safety messages

Instructions and procedures in this section may require special precautions to ensure the safety of the personnel performing the operations. Information that potentially raises safety issues is indicated by a warning symbol (⚠). Refer to the following safety messages before performing an operation preceded by this symbol.

3.1.1 Warnings

WARNING

Failure to follow these installation guidelines could result in death or serious injury.

- Make sure only qualified personnel perform the installation.

Process leaks could result in death or serious injury.

- Do not remove the thermowell while in operation. Removing while in operation may cause process fluid leaks.
- Install and tighten thermowells and sensors before applying pressure, or process leakage may result.

Electrical shock could cause death or serious injury.

- If the sensor is installed in a high voltage environment and a fault condition or installation error occurs, high voltage may be present on transmitter leads and terminals.
 - Use extreme caution when making contact with the leads and terminals.
-

3.2 Configuration

3.2.1 Standard

Each FOUNDATION™ fieldbus configuration tool or host system has a different way of displaying and performing configurations. Some will use Device Descriptions (DDs) and DD Methods to make configuration and displaying of data consistent across host platforms.

Unless otherwise specified, the 848T will be shipped with the following configuration (default):

Table 3-1. Standard Configuration Settings

Sensor Type ⁽¹⁾	Type J Thermocouple
Damping ⁽¹⁾	5 seconds
Measurement Units ⁽¹⁾	°C
Output ⁽¹⁾	Linear with Temperature
Line Voltage Filter ⁽¹⁾	60 Hz
Temperature Specific Blocks	<ul style="list-style-type: none"> • Transducer Block (1)
FOUNDATION fieldbus Function Blocks	<ul style="list-style-type: none"> • Analog Input (8) • Multiple Analog Input (2) • Input Selector (4)

(1) For all eight sensors

Refer to that systems documentation to perform configuration changes using a FOUNDATION fieldbus host or configuration tool.

Note

To make configuration changes, ensure that the block is Out of Service (OOS) by setting the MODE_BLK.TARGET to OOS, or set the SENSOR_MODE to Configuration.

3.2.2 Transmitter configuration

The transmitter is available with the standard configuration setting. The configuration settings and block configuration may be changed in the field with the Emerson Process Management Systems DeltaV™, with AMS®inside, or other FOUNDATION fieldbus host or configuration tool.

3.2.3 Custom configuration

Custom configurations are to be specified when ordering.

3.2.4 Methods

For FOUNDATION fieldbus hosts or configuration tools that support device description (DD) methods, there are two configuration methods available in the transducer block. These methods are included with the DD software.

- Sensor Configuration
- Sensor Input Trim (user input trim)

See the host system documentation for information on running DD methods from the host system. If the FOUNDATION fieldbus host or configuration tool does not support DD methods, refer to “Block configuration” on page 25 for information on how to modify sensor configuration parameters.

3.2.5 Alarms

Use the following steps to configure the alarms, which are located in the Resource Function Block:

1. Set the resource block to OOS.
2. Set WRITE_PRI to the appropriate alarm level (WRITE_PRI has a selectable range of priorities from 0 to 15, see “Alarm Priority Levels” on page 31. Set the other block alarm parameters at this time.
3. Set CONFIRM_TIME to the time, in $\frac{1}{32}$ of a millisecond, that the device will wait for confirmation of receiving a report before trying again (the device does not retry if CONFIRM_TIME is 0).
4. Set LIM_NOTIFY to a value between zero and MAX_NOTIFY. LIM_NOTIFY is the maximum number of alert reports allowed before the operator needs to acknowledge an alarm condition.
5. Enable the reports bit in FEATURES_SEL. (When Multi-bit alerts is enabled, every active alarm is visible for any of the eight sensors, generated by a PlantWeb® and Field Diagnostics alert. This is different than only viewing the highest priority alarm.)
6. Set the resource block to AUTO.

For modifying alarms on individual function blocks (AI or ISEL blocks), refer to [Appendix D: Function Blocks](#).

3.2.6 Damping

Use the following steps to configure the damping, which is located in the transducer function block:

1. Set Sensor Mode to Out of Service.
2. Change DAMPING to the desired filter rate (0.0 to 32.0 seconds).
3. Set Sensor Mode to In Service.

3.2.7 Configure the differential sensors

Use the following steps to configure the differential sensors:

1. Set Dual Sensor Mode to Out of Service.
2. Set Input A and Input B to the sensor values that are to be used in the differential equation $\text{diff} = A - B$. (Note: Unit types must be the same.)
3. Set the DUAL_SENSOR_CALC to either Not Used, Absolute, or INPUT A minus INPUT B.
4. Set Dual Sensor Mode to In Service.

3.2.8 Configure measurement validation

Use the following steps to configure measurement validation:

1. Set mode to Disabled for specific sensor.
2. Select sample rate. 1-10 sec/sample is available. 1 second/sample is preferred for sensor degradation. The higher the number of seconds between samples, the more emphasis put on process variation.
3. Select Deviation Limit from 0 to 10 units. If deviation limit is exceeded, a status event will be triggered.
4. Select Increasing Limit. Sets the limit for increasing rate of change. If limit is exceeded, a status event will be triggered.
5. Select Decreasing Limit. Sets the limit for decreasing rate of change. If limit is exceeded, a status event will be triggered.

Note

The decreasing limit selected is required to be a negative value.

6. Set the Deadband from 0 to 90%. This threshold is used to clear the PV status.
7. Set Status Priority. This determines what happens when the specific limit has been exceeded. No Alert - Ignores limit settings. Advisory - Sets Advisory Plant Web Alert, but does not do anything with PV status. Warning - Sets a Maintenance Plant Web Alert and sets PV status to uncertain. Failure - Sets A Failure Plant Web Alert and sets PV status to Bad.
8. Set mode to Enabled for specific sensor.

3.3 Common configurations for high density applications

For the application to work properly, configure the links between the function blocks and schedule the order of their execution. The Graphical User Interface (GUI) provided by the FOUNDATION fieldbus host or configuration tool will allow easy configuration.


The measurement strategies shown in this section represent some of the common types of configurations available in the 848T. Although the appearance of the GUI screens will vary from host to host, the configuration logic is the same.

Note

Ensure the host system or configuration tool is properly configured before downloading the transmitter configuration. If configured improperly, the FOUNDATION fieldbus host or configuration tool could overwrite the default transmitter configuration.

Typical profiling application


Example: Distillation column temperature profile where all channels have the same sensor units (°C, °F, etc.).



1. Place the Multiple Analog Input (MAI) function block in OOS mode (set `MODE_BLK.TARGET` to OOS).
2. Set `CHANNEL= "channels 1 to 8."` Although the `CHANNEL_X` parameters remain writable, `CHANNEL_X` can only be set = X when `CHANNEL=1`.
3. Set `L_TYPE` to direct or indirect.
4. Set `XD_SCALE` (transducer measurement scaling) to the appropriate upper and lower range values, the appropriate sensor units, and display decimal point.
5. Set `OUT_SCALE` (MAI output scaling) to the appropriate upper and lower range values, the appropriate sensor units, and display decimal point.
6. Place the MAI Function Block in auto mode.
7. Verify that the function blocks are scheduled.

Monitoring application with a single selection

Example: Average exhaust temperature of gas and turbine where there is a single alarm level for all inputs.




1. Link the MAI outputs to the ISEL inputs.
2. Place the Multiple Analog Input (MAI) function block in OOS mode (set `MODE_BLK.TARGET` to OOS).
3. Set `CHANNEL= "channels 1 to 8."` Although the `CHANNEL_X` parameters remain writable, `CHANNEL_X` can only be set = X when `CHANNEL=1`.
4. Set `L_TYPE` to direct or indirect.
5. Set `XD_SCALE` (transducer measurement scaling) to the appropriate upper and lower range values, the appropriate sensor units, and display decimal point.

6. Set OUT_SCALE (MAI output scaling) to the appropriate upper and lower range values, the appropriate sensor units, and display decimal point.
7. Place the MAI function block in auto mode.
8. Place the Input Selector (ISEL) function block in OOS mode by setting MODE_BLK.TARGET to OOS.
9. Set OUT_RANGE to match the OUT_SCALE in the MAI block.
10. Set SELECT_TYPE to the desired function (Maximum Value, Minimum Value, First Good Value, Midpoint Value, or Average Value).
11. Set the alarm limits and parameters if necessary.
12. Place the ISEL function block in auto mode.
13. Verify that the function blocks are scheduled.

Measuring temperature points individually

Example: Miscellaneous monitoring of temperature in a “close proximity” where each channel can have different sensor inputs with different units and there are independent alarm levels for each input.



1. Place the first Analog Input (AI) function block in OOS mode (set MODE_BLK.TARGET to OOS).
2. Set CHANNEL to the appropriate channel value. Refer to “[Alarm Priority Levels](#)” on [page 31](#) for a listing of channel definitions.
3. Set L_TYPE to direct.
4. Set XD_SCALE (transducer measurement scaling) to the appropriate upper and lower range values, the appropriate sensor units, and display decimal point.
5. Set OUT_SCALE (AI output scaling) to the appropriate upper and lower range values, the appropriate sensor units, and display decimal point.
6. Set the alarm limits and parameters if necessary.
7. Place the AI function block in auto mode.
8. Repeat steps 1 through 7 for each AI function block.
9. Verify that the function blocks are scheduled.

3.3.1 Interfacing analog transmitters to FOUNDATION fieldbus

Transducer block configuration

Use the sensor configuration method to set the sensor type to mV – 2-wire for the applicable transducer block or follow these steps.

1. Set the MODE_BLK.TARGET to OOS mode, or set the SENSOR_MODE to configuration.
2. Set the SENSOR to mV.
3. Set the MODE_BLK.TARGET to AUTO, or set the SENSOR_MODE to operation.

Multiple analog input or analog input block configuration

Follow these steps to configure the applicable block.

1. Set the MODE_BLK.TARGET to OOS mode, or set the SENSOR_MODE to configuration.
2. Set CHANNEL to the transducer block configured for the analog input.
3. Set XD_SCALE.EU_0 to 20
Set XD_SCALE.EU_100 to 100
Set XD_SCALE.ENGUNITS to mV
4. SET OUT_SCALE to match the desired scale and units for the connected analog transmitter.
Flow Example: 0 – 200 gpm
OUT_SCALE.EU_0 = 0
OUT_SCALE.EU_100 = 200
OUT_SCALE.ENGUNITS = gpm
5. Set L_TYPE to INDIRECT.
6. Set the MODE_BLK.TARGET to AUTO, or set the SENSOR_MODE to operation.

3.4 Block configuration

3.4.1 Resource block

The resource block defines the physical resources of the device including type of measurement, memory, etc. The resource block also defines functionality, such as shed times, that is common across multiple blocks. The block has no linkable inputs or outputs and it performs memory-level diagnostics.

Table 3-2. Resource Block Parameters

Number	Parameter	Description
01	ST_REV	The revision level of the static data associated with the function block.
02	TAG_DESC	The user description of the intended application of the block.
03	STRATEGY	The strategy field can be used to identify grouping of blocks.
04	ALERT_KEY	The identification number of the plant unit.
05	MODE_BLK	The actual, target, permitted, and normal modes of the block. For further description, see the Mode parameter formal model in FF-890.
06	BLOCK_ERR	This parameter reflects the error status associated with the hardware or software components associated with a block. Multiple errors may be shown. For a list of enumeration values, see FF-890, Block_Err formal model.

Table 3-2. Resource Block Parameters

Number	Parameter	Description
07	RS_STATE	State of the function block application state machine. For a list of enumeration values, see FF-890.
08	TEST_RW	Read/write test parameter - used only for conformance testing.
09	DD_RESOURCE	String identifying the tag of the resource which contains the Device Description for the resource.
10	MANUFAC_ID	Manufacturer identification number - used by an interface device to locate the DD file for the resource.
11	DEV_TYPE	Manufacturer's model number associated with the resource - used by interface devices to locate the DD file for the resource.
12	DEV_REV	Manufacturer revision number associated with the resource - used by an interface device to locate the DD file for the resource.
13	DD_REV	Revision of the DD associated with the resource - used by the interface device to locate the DD file for the resource.
14	GRANT_DENY	Options for controlling access of host computer and local control panels to operating, tuning and alarm parameters of the block.
15	HARD_TYPES	The types of hardware available as channel numbers. The supported hardware type is: SCALAR_INPUT
16	RESTART	Allows a manual restart to be initiated. 1) Run: This is passive state of this parameter. 2) Restart resource: To clear up the problems like garbage collection. 3) Restart with defaults: reset all configurable function block application objects to their initial value i.e. their value before any configuration was done by the user. This will also remove appended serial numbers of function block tags 4) Restart processor: provides a way to hit the reset button on the processor associated with the resource. 5) Restart to append serial number: Appends serial number to function block tags. 11) Restart default blocks: defaults manufacturer pre-instantiated blocks.
17	FEATURES	Used to show supported resource block options. The supported features are: SOFT_WRITE_LOCK_SUPPORT, HARD_WRITE_LOCK_SUPPORT, REPORTS, UNICODE, MULTI_BIT_ALARM_SUPPORT and FB_ACTION_RESTART_RELINK
18	FEATURE_SEL	Used to select resource block options.
19	CYCLE_TYPE	Identifies the block execution methods available for this resource. The supported cycle types are: SCHEDULED, and COMPLETION_OF_BLOCK_EXECUTION
20	CYCLE_SEL	Used to select the block execution method for this resource.
21	MIN_CYCLE_T	Time duration of the shortest cycle interval of which the resource is capable.
22	MEMORY_SIZE	Available configuration memory in the empty resource. To be checked before attempting a download.
23	NV_CYCLE_T	Minimum time interval specified by the manufacturer for writing copies of NV parameters to non-volatile memory. Zero means it will never be automatically copied. At the end of NV_CYCLE_T, only those parameters which have changed need to be updated in NVRAM.
24	FREE_SPACE	Percent of memory available for further configuration. Zero in preconfigured resource.
25	FREE_TIME	Percent of the block processing time that is free to process additional blocks.
26	SHED_RCAS	Time duration at which to give up on computer writes to function block RCAs locations. Shed from RCAs will never happen when SHED_RCAS = 0.
27	SHED_ROUT	Time duration at which to give up on computer writes to function block ROut locations. Shed from ROut will never happen when SHED_ROUT = 0.
28	FAULT_STATE	Condition set by loss of communication to an output block, fault promoted to an output block or physical contact. When FAIL_SAFE condition is set, then output function blocks will perform their FAIL_SAFE actions.
29	SET_FSTATE	Allows the FAIL_SAFE condition to be manually initiated by selecting Set.
30	CLR_FSTATE	Writing a Clear to this parameter will clear the device FAIL_SAFE if the field condition has cleared.
31	MAX_NOTIFY	Maximum number of unconfirmed notify messages possible.

Table 3-2. Resource Block Parameters

Number	Parameter	Description
32	LIM_NOTIFY	Maximum number of unconfirmed alert notify messages allowed.
33	CONFIRM_TIME	The time the resource will wait for confirmation of receipt of a report before trying again. Retry will not happen when CONFIRM_TIME=0.
34	WRITE_LOCK	If set, all writes to static and non-volatile parameters are prohibited, except to clear WRITE_LOCK. Block inputs will continue to be updated.
35	UPDATE_EVT	This alert is generated by any change to the static data.
36	BLOCK_ALM	The BLOCK_ALM is used for all configuration, hardware, connection failure or system problems in the block. The cause of the alert is entered in the subcode field. The first alert to become active will set the Active status in the Status attribute. As soon as the Unreported status is cleared by the alert reporting task, another block alert may be reported without clearing the Active status, if the subcode has changed.
37	ALARM_SUM	The current alert status, unacknowledged states, unreported states, and disabled states of the alarms associated with the function block.
38	ACK_OPTION	Selection of whether alarms associated with the block will be automatically acknowledged.
39	WRITE_PRI	Priority of the alarm generated by clearing the write lock.
40	WRITE_ALM	This alert is generated if the write lock parameter is cleared.
41	ITK_VER	Major revision number of the interoperability test case used in certifying this device as interoperable. The format and range are controlled by the fieldbus FOUNDATION.
42	FD_VER	This parameter's value equals the value of the major version of the Field Diagnostics specification that this device was designed to.
43	FD_FAIL_ACTIVE	Reflects the error conditions that are being detected as active as selected for this category. It is a bit string, so that multiple conditions may be shown.
44	FD_OFFSPEC_ACTIVE	Reflects the error conditions that are being detected as active as selected for this category. It is a bit string, so that multiple conditions may be shown.
45	FD_MAINT_ACTIVE	Reflects the error conditions that are being detected as active as selected for this category. It is a bit string, so that multiple conditions may be shown.
46	FD_CHECK_ACTIVE	Reflects the error conditions that are being detected as active as selected for this category. It is a bit string, so that multiple conditions may be shown.
47	FD_FAIL_MAP	Maps conditions to be detected as active for this alarm category. Thus the same condition may be active in all, some, or none of the 4 alarm categories.
48	FD_OFFSPEC_MAP	Maps conditions to be detected as active for this alarm category. Thus the same condition may be active in all, some, or none of the 4 alarm categories.
49	FD_MAINT_MAP	Maps conditions to be detected as active for this alarm category. Thus the same condition may be active in all, some, or none of the 4 alarm categories.
50	FD_CHECK_MAP	Maps conditions to be detected as active for this alarm category. Thus the same condition may be active in all, some, or none of the 4 alarm categories.
51	FD_FAIL_MASK	Allows the user to suppress any single or multiple conditions that are active, in this category, from being broadcast to the host through the alarm parameter. A bit equal to '1' will mask i.e. inhibit the broadcast of a condition, and a bit equal to '0' will unmask i.e. allow broadcast of a condition.
52	FD_OFFSPEC_MASK	Allows the user to suppress any single or multiple conditions that are active, in this category, from being broadcast to the host through the alarm parameter. A bit equal to '1' will mask i.e. inhibit the broadcast of a condition, and a bit equal to '0' will unmask i.e. allow broadcast of a condition.
53	FD_MAINT_MASK	Allows the user to suppress any single or multiple conditions that are active, in this category, from being broadcast to the host through the alarm parameter. A bit equal to '1' will mask i.e. inhibit the broadcast of a condition, and a bit equal to '0' will unmask i.e. allow broadcast of a condition.
54	FD_CHECK_MASK	Allows the user to suppress any single or multiple conditions that are active, in this category, from being broadcast to the host through the alarm parameter. A bit equal to '1' will mask i.e. inhibit the broadcast of a condition, and a bit equal to '0' will unmask i.e. allow broadcast of a condition.

Table 3-2. Resource Block Parameters

Number	Parameter	Description
55	FD_FAIL_ALM	Used primarily to broadcast a change in the associated active conditions, which are not masked, for this alarm category to a Host System.
56	FD_OFFSPEC_ALM	Used primarily to broadcast a change in the associated active conditions, which are not masked, for this alarm category to a Host System.
57	FD_MAINT_ALM	Used primarily to broadcast a change in the associated active conditions, which are not masked, for this alarm category to a Host System.
58	FD_CHECK_ALM	Used primarily to broadcast a change in the associated active conditions, which are not masked, for this alarm category to a Host System.
59	FD_FAIL_PRI	Allows the user to specify the priority of this alarm category.
60	FD_OFFSPEC_PRI	Allows the user to specify the priority of this alarm category.
61	FD_MAINT_PRI	Allows the user to specify the priority of this alarm category.
62	FD_CHECK_PRI	Allows the user to specify the priority of this alarm category.
63	FD_SIMULATE	Allows the conditions to be manually supplied when simulation is enabled. When simulation is disabled both the diagnostic simulate value and the diagnostic value track the actual conditions. The simulate jumper is required for simulation to be enabled and while simulation is enabled the recommended action will show that simulation is active.
64	FD_RECOMMEN_ACT	A device enumerated summarization of the most severe condition or conditions detected. The DD help should describe by enumerated action, what should be done to alleviate the condition or conditions. 0 is defined as Not Initialized, 1 is defined as No Action Required, all others defined by manufacturer.
65	FD_EXTENDED_ACTIVE_1	An optional parameter or parameters to allow the user finer detail on conditions causing an active condition in the FD_*_ACTIVE parameters.
66	FD_EXTENDED_MAP_1	An optional parameter or parameters to allow the user finer control on enabling conditions contributing to the conditions in FD_*_ACTIVE parameters.
67	COMPATIBILITY_REV	Optionally used when replacing field devices. The correct usage of this parameter presumes the COMPATIBILITY_REV value of the replacing device should be equal or lower than the DEV_REV value of the replaced device.
68	HARDWARE_REVISION	Manufacturer hardware revision
69	SOFTWARE_REV	Manufacturer hardware revision
70	PD_TAG	PD tag description of device
71	DEV_STRING	Used to load new licensing into the device. The value can be written but will always read back with a value of 0.
72	DEV_OPTIONS	Indicates which miscellaneous and diagnostic device licensing options are enabled. It also indicates Transducer options.
73	OUTPUT_BOARD_SN	Output board serial number
74	FINAL_ASSY_NUM	Same final assembly number placed on the neck label
75	DOWNLOAD_MODE	Gives access to the boot block code for over the wire downloads
76	HEALTH_INDEX	Parameter shall be set based on the active FD alarms or PWA alarms. HEALTH_INDEX will show 100 if target mode of block is OOS or there are no active alarms in device. The table below represents HEALTH_INDEX value when FD or PWA alarms are active in a device.
77	FAILED_PRI	Designates the alarming priority of the FAILED_ALM and also used as switch b/w FD and legacy PWA. If value is greater than or equal to 1 then PWA alerts will be active in device else device will have FD alerts.
78	RECOMMENDED_ACTION	Enumerated list of recommended actions displayed with a device alert
79	FAILED_ALM	Alarm indicating a failure within a device which makes the device non-operational
80	MAINT_ALM	Alarm indicating the device needs maintenance soon. If the condition is ignored, the device will eventually fail.
81	ADVISE_ALM	Alarm indicating advisory alarms. These conditions do not have a direct impact on the process or device integrity.

Table 3-2. Resource Block Parameters

Number	Parameter	Description
82	FAILED_ENABLE	Enabled FAILED_ALM alarm conditions. Corresponds bit for bit to the FAILED_ACTIVE. A bit on means that the corresponding alarm condition is enabled and will be detected. A bit off means the corresponding alarm condition is disabled and will not be detected. This parameter is the Read Only copy of FD_FAIL_MAP.
83	FAILED_MASK	Mask of Failure Alarm. Corresponds bit for bit to the FAILED_ACTIVE. A bit on means that the failure is masked out from alarming. This parameter is the Read Only copy of FD_FAIL_MASK.
84	FAILED_ACTIVE	Enumerated list of failure conditions within a device. All open bits are free to be used as appropriate for each specific device. This parameter is the Read Only copy of FD_FAIL_ACTIVE.
85	MAINT_PRI	Designates the alarming priority of the MAINT_ALM
86	MAINT_ENABLE	Enabled MAINT_ALM alarm conditions. Corresponds bit for bit to the MAINT_ACTIVE. A bit on means that the corresponding alarm condition is enabled and will be detected. A bit off means the corresponding alarm condition is disabled and will not be detected. This parameter is the Read Only copy of FD_OFFSPEC_MAP.
87	MAINT_MASK	Mask of Maintenance Alarm. Corresponds bit for bit to the MAINT_ACTIVE. A bit on means that the failure is masked out from alarming. This parameter is the Read Only copy of FD_OFFSPEC_MASK.
88	MAINT_ACTIVE	Enumerated list of maintenance conditions within a device. All open bits are free to be used as appropriate for each specific device. This parameter is the Read Only copy of FD_OFFSPEC_ACTIVE.
89	ADVISE_PRI	Designates the alarming priority of the ADVISE_ALM
90	ADVISE_ENABLE	Enabled ADVISE_ALM alarm conditions. Corresponds bit for bit to the ADVISE_ACTIVE. A bit on means that the corresponding alarm condition is enabled and will be detected. A bit off means the corresponding alarm condition is disabled and will not be detected. This parameter is the Read Only copy of FD_MAINT_MAP & FD_CHECK_MAP.
91	ADVISE_MASK	Mask of Advisory Alarm. Corresponds bit for bit to the ADVISE_ACTIVE. A bit on means that the failure is masked out from alarming. This parameter is the Read Only copy of FD_MAINT_MASK & FD_CHECK_MASK.
92	ADVISE_ACTIVE	Enumerated list of advisory conditions within a device. All open bits are free to be used as appropriate for each specific device. This parameter is the Read Only copy of FD_MAINT_ACTIVE & FD_CHECK_ACTIVE.

Block errors

The table below lists conditions reported in the BLOCK_ERR parameter.

Table 3-3. BLOCK_ERR Conditions

Number	Name and description
0	Other
1	Block Configuration Error: A feature in CYCLE_SEL is set that is not supported by CYCLE_TYPE.
3	Simulate Active: This indicates that the simulation jumper is in place. This is not an indication that the I/O blocks are using simulated data.
6	Device needs maintenance soon
7	Input failure/process variable has bad status
9	Memory Failure: A memory failure has occurred in FLASH, RAM, or EEPROM memory.
10	Lost Static Data: Static data that is stored in non-volatile memory has been lost.
11	Lost NV Data: Non-volatile data that is stored in non-volatile memory has been lost.
13	Device Needs Maintenance Now
14	Power Up: The device was just powered-up.
15	OOS: The actual mode is out of service.

Modes

The resource block supports two modes of operation as defined by the MODE_BLK parameter:

Automatic (Auto)

The block is processing its normal background memory checks.

Out of service (OOS)

The block is not processing its tasks. When the resource block is in OOS, all blocks within the resource (device) are forced into OOS. The BLOCK_ERR parameter shows Out of Service. In this mode, changes can be made to all configurable parameters. The target mode of a block may be restricted to one or more of the supported modes.

Alarm detection

A block alarm will be generated whenever the BLOCK_ERR has an error bit set. The types of block error for the resource block are defined above. A write alarm is generated whenever the WRITE_LOCK parameter is cleared. The priority of the write alarm is set in the following parameter:

- WRITE_PRI

Table 3-4. Alarm Priority Levels

Number	Description
0	The priority of an alarm condition changes to 0 after the condition that caused the alarm is corrected.
1	An alarm condition with a priority of 1 is recognized by the system, but is not reported to the operator.
2	An alarm condition with a priority of 2 is reported to the operator, but does not require operator attention (such as diagnostics and system alerts).
3-7	Alarm conditions of priority 3 to 7 are advisory alarms of increasing priority.
8-15	Alarm conditions of priority 8 to 15 are critical alarms of increasing priority.

Status handling

There are no status parameters associated with the resource block.

3.4.2

Field Diagnostics & PlantWeb Alerts

The 848T ITK6 has two mechanisms for alarms, one is Field Diagnostics (FD) and other is PlantWeb Alerts (PWA) for backward compatibility only.

The flexible capability has been added to allow user to select any alarm to be in the PWA FAILED/FD FAILED group or PWA MAINTENANCE/FD OFFSPEC group or PWA ADVISE/FD MAINTENANCE group or PWA ADVISE/FD CHECK group.

In PlantWeb Alerts, the alarms can be represented in three groups i.e. FAILED, MAINT & ADVISE. In Field Diagnostic, the alarms can be represented in four groups i.e. FAILED, OFFSPEC, MAINT & CHECK.

Parameter FAILED_PRI is used as a switch for using Field Diagnostic and PlantWeb Alerts.

How to use Field Diagnostic Alarm

If FAILED_PRI is equal to 0, Field Diagnostic alarms are supported and PlantWeb alarms are not. Field Diagnostic functionality includes four different Field Diagnostic Alarms such as FD_FAIL_ALM, FD_OFFSPEC_ALM, FD_MAINT_ALM and FD_CHECK_ALM. For these alarms, there are corresponding alarm priority parameter, masking parameter alarm active and alarm mapping parameter such as FD_*_PRI, FD_*_MASK & FD_*_ACTIVE & FD_*_MAP.

How to use PlantWeb Alarm

If FAILED_PRI is greater than 0, PlantWeb alarms are supported and Field Diagnostic are not. PlantWeb functionality includes three different PlantWeb Alarms FAILED_ALM, MAINT_ALM and ADVISE_ALM. For PlantWeb Alerts, there are corresponding alarm masking parameter, alarm active parameter and alarm mapping parameter such as *_MASK, *_ACTIVE & *_ENABLE. These parameters have Read only access and are duplicated from corresponding FD parameters.

So for example, in case of PWA alarms, if user wishes to change the mapping of any PlantWeb Alerts then the new value is written to the corresponding FD_*_MAP parameter. *_ENABLE shall reflect whatever is being written to FD_*_MAP parameter. The same applies for *_MASK parameters.

Note

Here * implies all 4 categories of FD alerts for e.g. FD_*_ACTIVE resembles FD_FAIL_ACTIVE, FD_OFFSPEC_ACTIVE, FD_MAINT_ACTIVE & FD_CHECK_ACTIVE.

The similar notation is also applicable for PWA alarms for e.g. FD_*_ACTIVE resembles FAIL_ACTIVE, MAINT_ACTIVE & ADVISE_ACTIVE.

3.4.3 PlantWeb alerts

The alerts and recommended actions should be used in conjunction with “[Operation and Maintenance](#)” on page 53.

The Resource Block will act as a coordinator for PlantWeb alerts. There will be three alarm parameters (FAILED_ALARM, MAINT_ALARM, and ADVISE_ALARM) which will contain information regarding some of the device errors which are detected by the transmitter software. There will be a RECOMMENDED_ACTION parameter which will be used to display the recommended action text for the highest priority alarm and a HEALTH_INDEX parameters (0 - 100) indicating the overall health of the transmitter. FAILED_ALARM will have the highest priority followed by MAINT_ALARM and ADVISE_ALARM will be the lowest priority.

FAILED_ALARMS

A failure alarm indicates a failure within a device that will make the device or some part of the device non-operational. This implies that the device is in need of repair and must be fixed immediately. There are five parameters associated with FAILED_ALARMS specifically, they are described below.

FAILED_ENABLED

This parameter contains a list of failures in the device which makes the device non-operational that will cause an alert to be sent. Below is a list of the failures with the highest priority first.

Table 3-5. Failure Alarms

Alarm	Priority
ASIC Failure	1
Electronics Failure	2
Hardware/Software Incompatible	3
Memory Failure	4
Body Temperature Failure	5
Sensor 1 Failure	6
Sensor 2 Failure	7
Sensor 3 Failure	8
Sensor 4 Failure	9
Sensor 5 Failure	10
Sensor 6 Failure	11
Sensor 7 Failure	12
Sensor 8 Failure	13

FAILED_MASK

This parameter will mask any of the failed conditions listed in FAILED_ENABLED. A bit on means that the condition is masked out from alarming and will not be reported.

FAILED_PRI

Designates the alerting priority of the FAILED_ALM, see [Table 3-4 on page 31](#). The default is 0 and the recommended value are between 8 and 15.

FAILED_ACTIVE

This parameter displays which of the alarms is active. Only the alarm with the highest priority will be displayed. This priority is not the same as the FAILED_PRI parameter described above. This priority is hard coded within the device and is not user configurable.

FAILED_ALM

Alarm indicating a failure within a device which makes the device non-operational.

MAINT_ALARMS

A maintenance alarm indicates the device or some part of the device needs maintenance soon. If the condition is ignored, the device will eventually fail. There are five parameters associated with MAINT_ALARMS, they are described below.

MAINT_ENABLED

The MAINT_ENABLED parameter contains a list of conditions indicating the device or some part of the device needs maintenance soon.

Table 3-6. Maintenance Alarms/Priority Alarm

Alarm	Priority
CJC Degraded	1
Body Temperature Out of Range	2
Sensor 1 Degraded	3
Sensor 2 Degraded	4
Sensor 3 Degraded	5
Sensor 4 Degraded	6
Sensor 5 Degraded	7
Sensor 6 Degraded	8
Sensor 7 Degraded	9
Sensor 8 Degraded	10

MAINT_MASK

The MAINT_MASK parameter will mask any of the failed conditions listed in MAINT_ENABLED. A bit on means that the condition is masked out from alarming and will not be reported.

MAINT_PRI

MAINT_PRI designates the alarming priority of the MAINT_ALM, [Table 3-4 on page 31](#). The default is 0 and the recommended values is 3 to 7.

MAINT_ACTIVE

The MAINT_ACTIVE parameter displays which of the alarms is active. Only the condition with the highest priority will be displayed. This priority is not the same as the MAINT_PRI parameter described above. This priority is hard coded within the device and is not user configurable.

MAINT_ALM

An alarm indicating the device needs maintenance soon. If the condition is ignored, the device will eventually fail.

Advisory alarms

An advisory alarm indicates informative conditions that do not have a direct impact on the device's primary functions. There are five parameters associated with ADVISE_ALARMS, they are described below.

ADVISE_ENABLED

The ADVISE_ENABLED parameter contains a list of informative conditions that do not have a direct impact on the device's primary functions. Below is a list of the advisories with the highest priority first.

Alarm	Priority
Excessive Deviation	1
Excessive Rate of Change	2
Check	3

Note

Alarms are only prioritized if Multi-Bit Alerts are disabled. If MBA is enabled, all alerts are visible.

ADVISE_MASK

The ADVISE_MASK parameter will mask any of the failed conditions listed in ADVISE_ENABLED. A bit on means the condition is masked out from alarming and will not be reported.

ADVISE_PRI

ADVISE_PRI designates the alarming priority of the ADVISE_ALM, see [Table 3-4 on page 31](#). The default is 0 and the recommended values are 1 or 2.

ADVISE_ACTIVE

The ADVISE_ACTIVE parameter displays which of the advisories is active. Only the advisory with the highest priority will be displayed. This priority is not the same as the ADVISE_PRI parameter described above. This priority is hard coded within the device and is not user configurable.

ADVISE_ALM

ADVISE_ALM is an alarm indicating advisory alarms. These conditions do not have a direct impact on the process or device integrity.

3.4.4 Recommended actions for PlantWeb alerts

RECOMMENDED_ACTION

The RECOMMENDED_ACTION parameter displays a text string that will give a recommended course of action to take based on which type and which specific event of the PlantWeb alerts are active.

Table 3-7. RB.RECOMMENDED_ACTION

Alarm type	Active event	Recommended action
None	None	No action required
Advisory	Excessive Deviation	Verify the process temperature, sensor wiring, and check sensor integrity.
Advisory	Excessive Rate of Change	Verify sensor wiring is appropriate in each junction point and check sensor integrity.
Maintenance	CJC Degraded	If T/C sensors are being used, restart the device. If condition persists, replace the device.
Maintenance	Body Temperature Out of Range	Verify the ambient temperature is within operating limits.
Maintenance	Sensor 1 Degraded	Confirm the operating range of Sensor 1 and/or verify the sensor connection and device environment.
Maintenance	Sensor 2 Degraded	Confirm the operating range of Sensor 2 and/or verify the sensor connection and device environment.
Maintenance	Sensor 3 Degraded	Confirm the operating range of Sensor 3 and/or verify the sensor connection and device environment.
Maintenance	Sensor 4 Degraded	Confirm the operating range of Sensor 4 and/or verify the sensor connection and device environment.
Maintenance	Sensor 5 Degraded	Confirm the operating range of Sensor 5 and/or verify the sensor connection and device environment.
Maintenance	Sensor 6 Degraded	Confirm the operating range of Sensor 6 and/or verify the sensor connection and device environment.
Maintenance	Sensor 7 Degraded	Confirm the operating range of Sensor 7 and/or verify the sensor connection and device environment.
Maintenance	Sensor 8 Degraded	Confirm the operating range of Sensor 8 and/or verify the sensor connection and device environment.
Failed	Sensor 1 Failure	Verify the Sensor 1 Instrument process is within the Sensor range and/or confirm sensor configuration and wiring.
Failed	Sensor 2 Failure	Verify the Sensor 2 Instrument process is within the Sensor range and/or confirm sensor configuration and wiring.
Failed	Sensor 3 Failure	Verify the Sensor 3 Instrument process is within the Sensor range and/or confirm sensor configuration and wiring.
Failed	Sensor 4 Failure	Verify the Sensor 4 Instrument process is within the Sensor range and/or confirm sensor configuration and wiring.
Failed	Sensor 5 Failure	Verify the Sensor 5 Instrument process is within the Sensor range and/or confirm sensor configuration and wiring.
Failed	Sensor 6 Failure	Verify the Sensor 6 Instrument process is within the Sensor range and/or confirm sensor configuration and wiring.
Failed	Sensor 7 Failure	Verify the Sensor 7 Instrument process is within the Sensor range and/or confirm sensor configuration and wiring.

Table 3-7. RB.RECOMMENDED_ACTION

Alarm type	Active event	Recommended action
Failed	Sensor 8 Failure	Verify the Sensor 8 Instrument process is within the Sensor range and/or confirm sensor configuration and wiring.
Failed	Body Temperature Failure	Verify the ambient temperature is within the operating limits of this device. If condition persists, replace the device.
Failed	Hardware/Software Incompatible	Contact Service Center to verify the Device Information (RESOURCE.HARDWARE_REV, AND RESOURCE.RB_SFTWR_REV_ALL).
Failed	Memory Error	Restart the transmitter by writing the RESTART parameter to 4 - Restart Processor. If condition persists, replace the transmitter.
Failed	Electronics Failure	Electronics failure has occurred. Restart the transmitter. If condition persists, replace the transmitter.
Failed	ASIC Failure	ASIC failure has occurred. Restart the transmitter. If condition persists, replace the transmitter.

Note

If status is set up to flag failure/warning you will see associated sensor degraded or failure alert.

3.4.5 Field Diagnostics Alerts

The Resource Block will act as a coordinator for Field Diagnostic Alerts. There will be four alarm parameters (FD_FAILED_ALARM, FD_OFFSPEC_ALARM, FD_MAINT_ALARM, and FD_CHECK_ALARM) that will contain information regarding some of the device errors that are detected by the transmitter software. There will be a RECOMMENDED_ACTION parameter that will be used to display the recommended action text for the highest priority alarm and a HEALTH_INDEX parameters (0 - 100) indicating the overall health of the transmitter. FD_FAILED_ALARM will have the highest priority followed by FD_OFFSPEC_ALARM, FD_MAINT_ALARM and FD_CHECK_ALARM will be the lowest priority.

FD failed alarms

A failure alarm indicates a failure within a device that will make the device or some part of the device non-operational. This implies that the device is in need of repair and must be fixed immediately. There are five parameters associated with FD_FAILED_ALARMS specifically, they are described below.

FD_FAILED_MAP

FD_FAIL_MAP parameter maps conditions to be detected as active for FD_FAIL_ALARM category. Thus the same condition may be active in all, some, or none of the 4 alarm categories. Below is a list of the failures with the highest priority first.

Table 3-8. FD Failure Alarms

Alarm	Priority
ASIC Failure	1
Electronics Failure	2
Hardware/Software Incompatible	3
Memory Failure	4
Body Temperature Failure	5

Table 3-8. FD Failure Alarms

Alarm	Priority
Sensor 1 Failure	6
Sensor 2 Failure	7
Sensor 3 Failure	8
Sensor 4 Failure	9
Sensor 5 Failure	10
Sensor 6 Failure	11
Sensor 7 Failure	12
Sensor 8 Failure	13

FD_FAILED_MASK

FD_FAIL_MASK parameter will mask any of the failed conditions listed in FD_FAILED_MAP. A bit on means the condition is masked out from alarming and will not be reported.

FD_FAILED_PRI

Designates the alerting priority of the FD_FAILED_ALM, see [Table 3-4 on page 31](#). The default is 0 and the recommended value are between 8 and 15.

FD_FAILED_ACTIVE

FD_FAIL_ACTIVE parameter displays the active alarms is active that are being selected for this category. Only the alarm with the highest priority will be displayed. This priority is not the same as the FD_FAILED_PRI parameter described above. This priority is hard coded within the device and is not user configurable.

FD_FAILED_ALM

FD_FAIL_ALM indicates a failure within a device which makes the device non-operational. FD_FAIL_ALM parameter is used primarily to broadcast a change in the associated active conditions, which are not masked, for this alarm category to a Host System.

FD OFFSPEC ALARMS

An offspec alarm indicates that the device or some part of the device needs maintenance soon, if the condition is ignored the device will eventually fail. There are five parameters associated with FD OFFSPEC ALARMS, they are described below.

FD_OFFSPEC_MAP

FD_OFFSPEC_MAP parameter maps conditions to be detected as active for FD_OFFSPEC_ALARM category. Thus the same condition may be active in all, some, or none of the 4 alarm categories. Below is a list of the failures with the highest priority first.

Table 3-9. FD Offspec Alarms

Alarm	Priority
CJC Degraded	1
Body Temperature Out of Range	2
Sensor 1 Degraded	3
Sensor 2 Degraded	4

Table 3-9. FD Offspec Alarms

Alarm	Priority
Sensor 3 Degraded	5
Sensor 4 Degraded	6
Sensor 5 Degraded	7
Sensor 6 Degraded	8
Sensor 7 Degraded	9
Sensor 8 Degraded	10

FD_OFFSPEC_MASK

The `FD_OFFSPEC_MASK` parameter will mask any of the failed conditions listed in `FD_OFFSPEC_MAP`. A bit on means the condition is masked out from alarming and will not be reported.

FD_OFFSPEC_PRI

`FD_OFFSPEC_PRI` designates the alarming priority of the `FD_OFFSPEC_ALM`, see [Table 3-4 on page 31](#). The default is 0 and the recommended values are 3 to 7.

FD_OFFSPEC_ACTIVE

`FD_OFFSPEC_ACTIVE` parameter displays the active alarms is active that are being selected for this category. Only the alarm with the highest priority will be displayed. This priority is not the same as the `FD_OFFSPEC_PRI` parameter described above. This priority is hard coded within the device and is not user configurable.

FD_OFFSPEC_ALM

An alarm indicating the device needs maintenance soon. If the condition is ignored, the device will eventually fail. `FD_OFFSPEC_ALM` parameter is used primarily to broadcast a change in the associated active conditions, which are not masked, for this alarm category to a Host System.

FD MAINT ALARMS

A maintenance alarm indicates informative conditions that do not have a direct impact on the device's primary function(s). There are five parameters associated with `MAINT_ALARMS`, they are described below.

FD_MAINT_MAP

The `FD_MAINT_MAP` parameter contains a list of conditions that do not have a direct impact on the device's primary function(s).

Table 3-10. Maintenance Alarms/Priority Alarm

Alarm	Priority
Excessive Deviation	1
Excessive Rate of Change	2

FD_MAINT_MASK

The `FD_MAINT_MASK` parameter will mask any of the failed conditions listed in `FD_MAINT_ENABLED`. A bit on means that the condition is masked out from alarming and will not be reported.

FD_MAINT_PRI

FD_MAINT_PRI designates the alarming priority of the MAINT_ALM, [Table 3-4 on page 31](#). The default is 0 and the recommended value is greater than 2.

FD_MAINT_ACTIVE

FD_MAINT_ACTIVE parameter displays the active alarms is active that are being selected for this category. Only the alarm with the highest priority will be displayed. This priority is not the same as the FD_MAINT_PRI parameter described above. This priority is hard coded within the device and is not user configurable.

FD_MAINT_ALM

FD_MAINT_ALM indicates advisory alarms. These conditions do not have a direct impact on the process or device integrity.

FD CHECK ALARMS

An advisory alarm indicates informative conditions that do not have a direct impact on the device's primary functions. There are five parameters associated with ADVISE_ALARMS, they are described below.

FD_CHECK_MAP

The FD_CHECK_MAP parameter contains a list of informative conditions that do not have a direct impact on the device's primary functions. Below is a list of the advisories with the highest priority first.

Table 3-11. Check Alarms

Alarm	Priority
Check	1

FD_CHECK_MASK

The FD_CHECK_MASK parameter will mask any of the failed conditions listed in FD_CHECK_MAP. A bit on means the condition is masked out from alarming and will not be reported.

FD_CHECK_PRI

FD_CHECK_PRI designates the alarming priority of the ADVISE_ALM, see [Table 3-4 on page 31](#). The default is 0 and the recommended values is 1.

FD_CHECK_ACTIVE

The FD_CHECK_ACTIVE parameter displays which of the advisories is active. Only the advisory with the highest priority will be displayed. This priority is not the same as the FD_CHECK_PRI parameter described above. This priority is hard coded within the device and is not user configurable.

FD_CHECK_ALM

FD_CHECK_ALM is an alarm indicating advisory alarms. These conditions do not have a direct impact on the process or device integrity.

3.4.6 Recommended actions for field diagnostics alerts

RECOMMENDED_ACTION

The RECOMMENDED_ACTION parameter displays a text string that will give a recommended course of action to take based on which type and which specific event of the Field Diagnostics alerts are active.

Table 3-12. RB.RECOMMENDED_ACTION

Alarm type	Active event	Recommended action
None	None	No action required
Failed	ASIC Failure	ASIC Failure has occurred. Restart the transmitter. If condition persists, replace the transmitter
Failed	Electronics Failure	Electronics Failure has occurred. Restart the transmitter. If condition persists, replace the transmitter.
Failed	Hardware/Software Incompatible	Contact a Service Center and verify the Device Information (RESOURCE.HARDWARE_REV and RESOURCE.RB_SFTWR_REV)
Failed	Memory Failure	Restart the transmitter by writing the RESTART parameter to 4 - Restart Processor. If condition persists, replace the transmitter.
Failed	Body Temperature Failure	Verify the ambient temperature is within the operating limits of this device. If condition persists, replace the device
Failed	Sensor 1 Failure	Verify the Instrument process for Sensor 1 is within the Sensor range and/or confirm sensor configuration and wiring.
Failed	Sensor 2 Failure	Verify the Instrument process for Sensor 2 is within the Sensor range and/or confirm sensor configuration and wiring.
Failed	Sensor 3 Failure	Verify the Instrument process for Sensor 3 is within the Sensor range and/or confirm sensor configuration and wiring.
Failed	Sensor 4 Failure	Verify the Instrument process for Sensor 4 is within the Sensor range and/or confirm sensor configuration and wiring.
Failed	Sensor 5 Failure	Verify the Instrument process for Sensor 5 is within the Sensor range and/or confirm sensor configuration and wiring.
Failed	Sensor 6 Failure	Verify the Instrument process for Sensor 6 is within the Sensor range and/or confirm sensor configuration and wiring.
Failed	Sensor 7 Failure	Verify the Instrument process for Sensor 7 is within the Sensor range and/or confirm sensor configuration and wiring.
Failed	Sensor 8 Failure	Verify the Instrument process for Sensor 8 is within the Sensor range and/or confirm sensor configuration and wiring.
Off Spec	CJC Degraded	If T/C sensors are being used, restart the device. If condition persists, replace the device.
Off Spec	Body Temperature Out of Range	Verify the ambient temperature is within operating limits
Off Spec	Sensor 1 Degraded	Confirm the operating range of Sensor 1 and/or verify the sensor connection and device environment.
Off Spec	Sensor 2 Degraded	Confirm the operating range of Sensor 2 and/or verify the sensor connection and device environment.
Off Spec	Sensor 3 Degraded	Confirm the operating range of Sensor 3 and/or verify the sensor connection and device environment.

Table 3-12. RB.RECOMMENDED_ACTION

Alarm type	Active event	Recommended action
Off Spec	Sensor 4 Degraded	Confirm the operating range of Sensor 4 and/or verify the sensor connection and device environment.
Off Spec	Sensor 5 Degraded	Confirm the operating range of Sensor 5 and/or verify the sensor connection and device environment.
Off Spec	Sensor 6 Degraded	Confirm the operating range of Sensor 6 and/or verify the sensor connection and device environment.
Off Spec	Sensor 7 Degraded	Confirm the operating range of Sensor 7 and/or verify the sensor connection and device environment.
Off Spec	Sensor 8 Degraded	Confirm the operating range of Sensor 8 and/or verify the sensor connection and device environment.
Maintenance	Excessive Deviation	Verify the process temperature, sensor wiring, and check sensor integrity.
Maintenance	Excessive Rate of Change	Verify sensor wiring is appropriate in each junction point and check sensor integrity
Check	Check	Transducer block under maintenance

3.4.7 Transducer blocks

The transducer block allows the user to view and manage the channel information. There is one transducer block for the eight sensors that contains specific temperature measurement data, including:

- Sensor Type
- Engineering Units
- Damping
- Temperature Compensation
- Diagnostics

Transducer block channel definitions

The 848T supports multiple sensor inputs. Each input has a channel assigned to it allowing an AI or MAI Function Blocks to be linked to that input. The channels for the 848T are as follows:


Table 3-13. Channel Definitions for the 848T

Channel	Description	Channel	Description
1	Sensor One	16	Sensor 3 Deviation
2	Sensor Two	17	Sensor 4 Deviation
3	Sensor Three	18	Sensor 5 Deviation
4	Sensor Four	19	Sensor 6 Deviation
5	Sensor Five	20	Sensor 7 Deviation
6	Sensor Six	21	Sensor 8 Deviation
7	Sensor Seven	22	Sensor 1 Rate Change
8	Sensor Eight	23	Sensor 2 Rate Change
9	Differential Sensor 1	24	Sensor 3 Rate Change

Table 3-13. Channel Definitions for the 848T

Channel	Description	Channel	Description
10	Differential Sensor 2	25	Sensor 4 Rate Change
11	Differential Sensor 3	26	Sensor 5 Rate Change
12	Differential Sensor 4	27	Sensor 6 Rate Change
13	Body Temperature	28	Sensor 7 Rate Change
14	Sensor 1 Deviation	29	Sensor 8 Rate Change
15	Sensor 2 Deviation		

Figure 3-1. Transducer Block Data Flow



Transducer block errors

The following conditions are reported in the BLOCK_ERR and XD_ERROR parameters.

Table 3-14. Block/Transducer Error

BLOCK_ERR	Condition number, name, and description	
	0	Other ⁽¹⁾
	7	Input failure/process variable has bad status
	15	Out of service: The actual mode is out of service

(1) If BLOCK_ERR is "other," then see XD_ERROR.

Transducer block modes

The transducer block supports two modes of operation as defined by the MODE_BLK parameter:

Automatic (Auto)

The block outputs reflect the analog input measurement.

Out of Service (OOS)

The block is not processed. Channel outputs are not updated and the status is set to Bad: Out of Service for each channel. The BLOCK_ERR parameter shows Out of Service. In this mode, changes can be made to all configurable parameters. The target mode of a block may be restricted to one or more of the supported modes.

Transducer block alarm detection

Alarms are not generated by the transducer block. By correctly handling the status of the channel values, the down stream block (AI or MAI) will generate the necessary alarms for the measurement. The error that generated this alarm can be determined by looking at BLOCK-ERR and XD_ERROR.

Transducer block status handling

Normally, the status of the output channels reflect the status of the measurement value, the operating condition of the measurement electronics card, and any active alarm conditions. In a transducer, PV reflects the value and status quality of the output channels.

Table 3-15. Transducer Block Parameters

Number	Parameter	Description
0	BLOCK	
1	ST_REV	The revision level of the static data associated with the function block.
2	TAG_DESC	The user description of the intended application of the block.
3	STRATEGY	The strategy field can be used to identify grouping of blocks.
4	ALERT_KEY	The identification number of the plant unit.
5	MODE_BLK	The actual, target, permitted, and normal modes of the block.
6	BLOCK_ERR	This parameter reflects the error status associated with the hardware or software components associated with a block. Multiple errors may be shown. <i>For a list of enumeration values, see FF-890, Block_Err formal model.</i>
7	UPDATE_EVENT	This alert is generated by any change to the static data.
8	BLOCK_ALM	The BLOCK-ALM is used for all configuration, hardware, connection failure or system problems in the block. The cause of the alert is entered in the subcode field. The first alert to become active will set the Active status in the Status attribute. As soon as the Unreported status is cleared by the alert reporting task, another block alert may be reported without clearing the Active status, if the subcode has changed.
9	TRANSDUCER_DIRECTORY	A directory that specified the number and stating indices of the transducers in the transducer block.
10	TRANSDUCER_TYPE	Identifies the transducer that follows 101 – Standard Temperature with Calibration.

Table 3-15. Transducer Block Parameters

Number	Parameter	Description
11	XD_ERROR	Provides additional error codes related to transducer blocks. <i>For a list of enumeration values, see FF-902.</i> See tables below for a list of sub-parameters that pertain to XD_ERROR messages.
12	COLLECTION_DIRECTORY	A directory that specifies the number, starting indices, and DD Item ID's of the data collections in each transducer block.
13	SENSOR_1_CONFIG	Sensor Configuration Parameters. See tables below for a list of sub-parameters that pertain to Sensor Configuration functions.
14	PRIMARY_VALUE_1	The measured value and status available to the function block.
15	SENSOR_2_CONFIG	Sensor Configuration parameters. See tables below for a list of sub-parameters that pertain to Sensor Configuration functions.
16	PRIMARY_VALUE_2	The measured value and status available to the function block.
17	SENSOR_3_CONFIG	Sensor Configuration Parameters. See tables below for a list of sub-parameters that pertain to Sensor Configuration functions.
18	PRIMARY_VALUE_3	The measured value and status available to the function block
19	SENSOR_4_CONFIG	Sensor Configuration Parameters. See tables below for a list of sub-parameters that pertain to Sensor Configuration functions.
20	PRIMARY_VALUE_4	The measured value and status available to the function block.
21	SENSOR_5_CONFIG	Sensor Configuration Parameters. See tables below for a list of sub-parameters that pertain to Sensor Configuration functions.
22	PRIMARY_VALUE_5	The measured value and status available to the function block.
23	SENSOR_6_CONFIG	Sensor Configuration Parameters. See tables below for a list of sub-parameters that pertain to Sensor Configuration functions.
24	PRIMARY_VALUE_6	The measured value and status available to the function block.
25	SENSOR_7_CONFIG	Sensor Configuration Parameters. See tables below for a list of sub-parameters that pertain to Sensor Configuration functions.
26	PRIMARY_VALUE_7	The measured value and status available to the function block.
27	SENSOR_8_CONFIG	Sensor Configuration Parameters. See tables below for a list of sub-parameters that pertain to Sensor Configuration functions.
28	PRIMARY_VALUE_8	The measured value and status available to the function block
29	SENSOR_STATUS	Status of each individual sensor. See tables below for a list of possible status messages.

Table 3-15. Transducer Block Parameters

Number	Parameter	Description
30	SENSOR_CAL	Parameter structure to allow for calibration of each sensor. See tables below for a list of sub-parameters that pertain to Sensor Calibration functions.
31	CAL_STATUS	Status of the calibration that was previously performed. See tables below for a list of possible Calibration Statuses.
32	ASIC_REJECTION	A configurable power line noise rejection setting.
33	BODY_TEMP	Body Temperature of the device.
34	BODY_TEMP_RANGE	The range of the body temperature including the units index.
35	TB_SUMMARY_STATUS	Overall summary status of the sensor transducer. See tables below for a list of possible transducer statuses.
36	DUAL_SENSOR_1_CONFIG	Parameter structure to allow for calibration of each differential measurement. See tables below for a list of sub-parameters that pertain to Dual Sensor Calibration functions.
37	DUAL_SENSOR_VALUE_1	The measured value and status available to the function block.
38	DUAL_SENSOR_2_CONFIG	Parameter structure to allow for calibration of each differential measurement. See tables below for a list of sub-parameters that pertain to Dual Sensor Calibration functions.
39	DUAL_SENSOR_VALUE_2	The measured value and status available to the function block.
40	DUAL_SENSOR_3_CONFIG	Parameter structure to allow for calibration of each differential measurement. See tables below for a list of sub-parameters that pertain to Dual Sensor Calibration functions.
41	DUAL_SENSOR_VALUE_3	The measured value and status available to the function block.
42	DUAL_SENSOR_4_CONFIG	Parameter structure to allow for calibration of each differential measurement. See tables below for a list of sub-parameters that pertain to Dual Sensor Calibration functions.
43	DUAL_SENSOR_VALUE_4	The measured value and status available to the function block.
44	DUAL_SENSOR_STATUS	Status of each individual differential measurement. See tables below for a list of possible Dual Sensor statuses.
45	VALIDATION_SNSR1_CONFIG	Validation configuration parameters. See tables below for a list of sub-parameters that pertain to Validation Configuration functions.
46	VALIDATION_SNSR1_VALUES	Validation value parameters. See tables below for a list of sub-parameters that pertain to Validation values.
47	VALIDATION_SNSR2_CONFIG	Validation configuration parameters. See tables below for a list of sub-parameters that pertain to Validation Configuration functions.
48	VALIDATION_SNSR2_VALUES	Validation value parameters. See tables below for a list of sub-parameters that pertain to Validation values.

Table 3-15. Transducer Block Parameters

Number	Parameter	Description
49	VALIDATION_SNSR3_CONFIG	Validation configuration parameters. See tables below for a list of sub-parameters that pertain to Validation Configuration functions.
50	VALIDATION_SNSR3_VALUES	Validation value parameters. See tables below for a list of sub-parameters that pertain to Validation values.
51	VALIDATION_SNSR4_CONFIG	Validation configuration parameters. See tables below for a list of sub-parameters that pertain to Validation Configuration functions.
52	VALIDATION_SNSR4_VALUES	Validation value parameters. See tables below for a list of sub-parameters that pertain to Validation values.
53	VALIDATION_SNSR5_CONFIG	Validation configuration parameters. See tables below for a list of sub-parameters that pertain to Validation Configuration functions.
54	VALIDATION_SNSR5_VALUES	Validation value parameters. See tables below for a list of sub-parameters that pertain to Validation values.
55	VALIDATION_SNSR6_CONFIG	Validation configuration parameters. See tables below for a list of sub-parameters that pertain to Validation Configuration functions.
56	VALIDATION_SNSR6_VALUES	Validation value parameters. See tables below for a list of sub-parameters that pertain to Validation values.
57	VALIDATION_SNSR7_CONFIG	Validation configuration parameters. See tables below for a list of sub-parameters that pertain to Validation Configuration functions.
58	VALIDATION_SNSR7_VALUES	Validation value parameters. See tables below for a list of sub-parameters that pertain to Validation values.
59	VALIDATION_SNSR8_CONFIG	Validation configuration parameters. See tables below for a list of sub-parameters that pertain to Validation Configuration functions.
60	VALIDATION_SNSR8_VALUES	Validation value parameters. See tables below for a list of sub-parameters that pertain to Validation values.
61	SENSOR_GRAPH_LIMIT	Sensor graph limit parameters
62	DIFFERENTIAL_GRAPH_LIMIT	Differential graph limit parameters

Changing the sensor configuration in the transducer block

If the FOUNDATION fieldbus configuration tool or host system does not support the use of DD methods for device configuration, the following steps illustrate how to change the sensor configuration in the transducer block:

1. Set the MODE_BLK.TARGET to OOS, or set the SENSOR_MODE to configuration.
2. Set SENSOR_n_CONFIG.SENSOR to the appropriate sensor type, and then set SENSOR_n_CONFIG.CONNECTION to the appropriate type and connection.
3. In the Transducer Block, set MODE_BLK.TARGET to AUTO, or set the SENSOR_MODE to operation.

3.4.8 Transducer block sub-parameter tables

Table 3-16. XD_ERROR Sub-parameter Structure

XD ERROR		Description
0	No Error	
17	General Error	An error has occurred that could not be classified as one of the errors listed below.
18	Calibration Error	An error occurred during calibration of the device or a calibration error has been detected during operation of the device.
19	Configuration Error	An error occurred during configuration of the device or a configuration error has been detected during operation of the device.
20	Electronics Failure	An electronic component has failed.
22	I/O Failure	An I/O failure has occurred.
23	Data Integrity Error	Indicates that data stored within the system may no longer be valid due to non-volatile memory checksum failure, data verify after write failure, etc.
24	Software Error	The software has detected an error. This could be caused by an improper interrupt service routine, an arithmetic overflow, a watchdog timer, etc.
25	Algorithm Error	The algorithm used in the transducer block produced an error. This could be due to an overflow, data reasonableness.

Table 3-17. SENSOR_CONFIG Sub-parameter Structure

Parameter	Description
SENSOR_MODE	Disables or enables a sensor for configuration.
SENSOR_TAG	Sensor description.
SERIAL_NUMBER	Serial number for the attached sensor.
SENSOR	Sensor Type and Connection. MSB is the sensor type and LSB is the connection.
DAMPING	Sampling Interval used to smooth output using a first order linear filter. A value entered between 0 and the Update_Rate, will result in a damping value equal to the Update_Rate.
INPUT_TRANSIENT_FILTER	Enables or Disables the option for reporting fast changing sensor inputs without temporary holdoff. 0 = Disable, 1 = Enabled.
RTD_2_WIRE_OFFSET	User entered value for constant lead-wire resistance correction in a 2-wire RTD and ohm sensor types.
ENG_UNITS	The engineering units used for reporting measured sensor values.
UPPER_RANGE	The upper sensor limit for the selected sensor is displayed using Units_Index sub parameter.
LOWER_RANGE	The lower sensor limit for the selected sensor is displayed using Units_Index sub parameter.

Table 3-18. SENSOR_STATUS Sub-parameter Structure

Sensor status table	
0x00	Active
0x01	Out of Service
0x02	Inactive
0x04	Open
0x08	Short
0x10	Out of Range
0x20	Beyond Limits
0x40	Excess EMF Detected
0x80	Other

Table 3-19. SENSOR_CAL Sub-parameter Structure

Parameter	Description
SENSOR_NUMBER	The sensor number to calibrate
CALIB_POINT_HI	The High calibration point for the selected sensor
CALIB_POINT_LO	The Low calibration point for the selected sensor
CALIB_UNIT	The engineering units used for calibrating the sensor
CALIB_METHOD	The method of the last calibration for sensor 103 - factory trim standard calibration 104 - user trim standard calibration
CALIB_INFO	Information regarding the calibration
CALIB_DATE	Date that the calibration was completed
CALIB_MIN_SPAN	The minimum calibration span value allowed. This minimum span information is necessary to ensure that when calibration is done, the two calibrated points are not too close together
CALIB_PT_HI_LIMIT	The High calibration unit
CALIB_PT_LO_LIMIT	The Low calibration unit

Table 3-20. CAL_STATUS Structure

	Cal status
0	No Command Active
1	Command Executing
2	Command Done
3	Command Done: Errors

Table 3-21. Transducer Status Sub-parameter Structure

Transducer status table	
0x01	A/D Failure
0x02	Sensor Failure
0x04	Dual Sensor Failure
0x08	CJC Degraded
0x10	CJC Failure
0x20	Body Temp Failure
0x40	Sensor Degraded
0x80	Body Temperature Degraded

Table 3-22. DUAL_SENSOR_CONFIG Sub-parameter Structure

Parameter	Description
DUAL_SENSOR_MODE	Disables or enables a sensor for configuration
DUAL_SENSOR_TAG	Differential description
INPUT_A	Sensor to be used in DUAL_SENSOR_CALC
INPUT_B	Sensor to be used in DUAL_SENSOR_CALC
DUAL_SENSOR_CALC	Equation used for the dual sensor measurement including: Not Used, Difference (Input A - Input B), and Absolute Difference (Input A - Input B)
ENG_UNITS	Units used to display sensor parameter
UPPER_RANGE	Upper Differential Limit (Input A High - Input B Low)
LOWER_RANGE	Lower Differential Limit (Input A Low - Input B High)

Table 3-23. DUAL_SENSOR_STATUS Sub-parameter Structure

Dual sensor status table	
0x00	Active
0x01	Out of Service
0x02	Inactive
0x04	Component Sensor Open
0x08	Component Sensor Short
0x10	Component Sensor Out of Range or Degraded
0x20	Component Sensor Out of Limits
0x40	Component Sensor Inactive
0x80	Configuration Error

Table 3-24. Validation Value Sub-parameter Structure

Validation value sub-parameter structure	
Parameter	Description
VALIDATION_STATUS	State of the channel specific measurement validation measurement
DEVIATION_VALUE	Deviation output value
DEVIATION_STATUS	Status of the deviation output
RATE_OF_CHANGE_VALUE	Rate of change value output
RATE_OF_CHANGE_STATUS	Status of Rate of change output

Table 3-25. Validation Config Sub-parameter Structure

Parameter	Description
VALIDATION_MODE	Activates the measurement validation data gathering process 0 = Disable 1 = Enable
SAMPLE_RATE	Number of seconds per sample used for measurement validation data collection. This shouldn't exceed 10 seconds per sample, but currently there are no upper limits.
DEVIATION_LIMIT	Sets the limit for the deviation diagnostic. DD limits the upper range to 10.
DEVIATION_ENG_UNITS	Units tied to the deviation output value
DEVIATION_ALERT_SEVERITY	Advisory, Maintenance, Failure 0 = Disabled = Does not use the limits, but provides an output 1 = Advisory = No effect on sensor status, sets advisory PWA 2 = Maint = Sets sensor status to uncertain, sets advisory PWA 3 = Failure = Sets sensor status to Bad, sets advisory PWA
DEVIATION_PCNT_LIM_HYST	Deviation Hysteresis Limit = $(1 - \text{DEVIATION_PCNT_LIM_HYST}/100) * \text{DEVIATION_LIMIT}$
RATE_INCREASING_LIMIT	Increasing Rate of Change limit set point
RATE_DECREASING_LIMIT	Decreasing Rate of Change limit set point
RATE_ENG_UNITS	Units tied to the rate of change output value
RATE_ALERT_SEVERITY	Advisory, Maintenance, Failure 0 = Disabled = Does not use the limits, but provides an output 1 = Advisory = No effect on sensor status, sets advisory PWA 2 = Maint = Sets sensor status to uncertain, sets advisory PWA 3 = Failure = Sets sensor status to Bad, sets advisory PWA
RATE_PCNT_LIM_HYST	Rate of Change Increasing Hysteresis Limit = $(1 - \text{RATE_PCNT_LIM_HYST}/100) * \text{RATE_INCREASING_LIMIT}$

Sensor calibration in the sensor transducer block

If the FOUNDATION fieldbus configuration tool or host system does not support the use of DD methods for device configuration, the following steps illustrate how to calibrate the sensor from the sensor transducer block.

Note

Active calibrators should not be used in conduction with RTDs on any multiple input temperature transmitter such as the 848T.

1. Under SENSOR_CALIB, the SENSOR_NUMBER to the number of the sensor to calibrate.
2. Set CALIB_UNIT to calibration unit.
3. Set CALIB_METHOD to User Trim (see [Table on page 41](#) for valid values).
4. Set the input value of the sensor simulator to be within the range defined by CALIB_LO_LIMIT and CALIB_HI_LIMIT.
5. Set CALIB_POINT_LO (CALIB_POINT_HI) to the value set at the sensor simulator.
6. Read CALIB_STATUS and wait until it reads “Command Done”
7. Repeat steps 3 to 5 if performing a two-point trim. Note that the difference in values between CALIB_POINT_LO and CALIB_POINT_HI must be greater than CALIB_MIN_SPAN.

Section 4 Operation and Maintenance

Safety messages	page 53
FOUNDATION™ fieldbus information	page 53
Hardware maintenance	page 54
Troubleshooting	page 55

4.1 Safety messages

Instructions and procedures in this section may require special precautions to ensure the safety of the personnel performing the operations. Information that potentially raises safety issues is indicated by a warning symbol (⚠). Refer to the following safety messages before performing an operation preceded by this symbol.

4.1.1 Warnings

⚠ WARNING

Failure to follow these installation guidelines could result in death or serious injury.

- Make sure only qualified personnel perform the installation.

Process leaks could result in death or serious injury.

- Do not remove the thermowell while in operation. Removing while in operation may cause process fluid leaks.
- Install and tighten thermowells and sensors before applying pressure, or process leakage may result.


Electrical shock could cause death or serious injury.

- If the sensor is installed in a high voltage environment and a fault condition or installation error occurs, high voltage may be present on transmitter leads and terminals.
 - Use extreme caution when making contact with the leads and terminals.
-

4.2 FOUNDATION™ fieldbus information

FOUNDATION fieldbus is an all-digital, serial, two-way, multi-drop communication protocol that interconnects devices such as transmitters and valve controllers. It is a local area network (LAN) for instruments that enable basic control and I/O to be moved to the field devices. The Model 848T uses FOUNDATION fieldbus technology developed and supported by Emerson Process Management and the other members of the independent Fieldbus Foundation.

Table 4-1. Block Diagram for the Rosemount 848T



4.2.1 Commissioning (addressing)

To be able to setup, configure, and have it communicate with other devices on a segment, a device must be assigned a permanent address. Unless requested otherwise, it is assigned a temporary address when shipped from the factory.

If there are two or more devices on a segment with the same address, the first device to start up will use the assigned address (ex. Address 20). Each of the other devices will be given one of the four available temporary addresses. If a temporary address is not available, the device will be unavailable until a temporary address becomes available.

Use the host system documentation to commission a device and assign a permanent address.

4.3 Hardware maintenance

The 848T has no moving parts and requires a minimal amount of scheduled maintenance. If a malfunction is suspected, check for an external cause before performing the diagnostics presented below.

4.3.1 Sensor check

To determine whether the sensor is causing the malfunction, connect a sensor calibrator or simulator locally at the transmitter. Consult an Emerson Process Management representative for additional temperature sensor and accessory assistance.

4.3.2 Communication/power check

If the transmitter does not communicate or provides an erratic output, check for adequate voltage to the transmitter. The transmitter requires between 9.0 and 32.0 VDC at the terminals to operate with complete functionality. Check for wire shorts, open circuits, and multiple grounds.

4.3.3 Resetting the configuration (RESTART)

There are two types of restarts available in the Resource Block. The following section outlines the usage for each of these. For further information, see RESTART in [Table 3-2 on page 3-25](#).

Restart processor (cycling)

Performing a Restart Processor has the same effect as removing power from the device and reapplying power.

Restart with defaults

Performing a Restart with Defaults resets the static parameters for all of the blocks to their initial state. This is commonly used to change the configuration and/or control strategy of the device, including any custom configurations done at the Rosemount factory.

4.4 Troubleshooting

4.4.1 FOUNDATION fieldbus

Symptom	Possible cause	Corrective action
Device does not show up in the live list	Network configuration parameters are incorrect	Set the network parameters of the LAS (host system) according to the FF Communications Profile
		ST: 8
		MRD: 4
		DLPDU PhLO: 4
		MID: 7
		TSC: 4 (1 ms)
		T1: 96000 (3 seconds)
		T2: 9600000 (300 seconds)
		T3: 480000 (15 seconds)
	Network address is not in polled range	Set first Unpolled Node and Number of UnPolled Nodes so that the device address is within range
	Power to the device is below the 9 VDC minimum	Increase the power to at least 9V
	Noise on the power / communication is too high	Verify terminators and power conditioners are within specification Verify that the shield is properly terminated and not grounded at both ends. It is best to ground the shield at the power conditioner
Device that is acting as a LAS does not send out CD	LAS Scheduler was not downloaded to the Backup LAS device	Ensure that all of the devices that are intended to be a Backup LAS are marked to receive the LAS schedule
All devices go off live list and then return	Live list must be reconstructed by Backup LAS device	Current link setting and configured links settings are different. Set the current link setting equal to the configured settings.

4.4.2 Resource block

Symptom	Possible causes	Corrective action
Mode will not leave OOS	Target mode not set	Set target mode to something other than OOS.
	Memory Failure	BLOCK_ERR will show the lost NV Data or Lost Static Data bit set. Restart the device by setting RESTART to Processor. If the block error does not clear, call the factory.
Block Alarms Will not work	Features	FEATURES_SEL does not have Alerts enabled. Enable the report bit.
	Notification	LIM_NOTIFY is not high enough. Set equal to MAX_NOTIFY.

4.4.3 Transducer block troubleshooting

Symptom	Possible causes	Corrective action
Mode will not leave OOS	Target mode not set	Set target mode to something other than OOS.
	A/D board check sum error	The A/D board has a checksum error.
	Resource block	The actual mode of the Resource block is in OOS. See Resource Block Diagnostics for corrective action.
	Transducer Block	The actual mode of the Transducer Block is OOS.
The primary value is BAD	Measurement	Look at the SENSOR_STATUS parameter (See Table 3-16 on page 3-47)

Appendix A Reference Data

Functional specifications	page 57
Physical specifications	page 58
Performance specifications	page 60
Function blocks	page 59
Dimensional drawings	page 64
Ordering information	page 67

A.1 Functional specifications

A.1.1 Inputs

Eight independently configurable channels including combinations of 2- and 3-wire RTDs, thermocouples, mV, 2- and 3-wire and ohm inputs.

4–20 mA inputs using optional connector(s).

A.1.2 Outputs

Manchester-encoded digital signal that conforms to IEC 61158 and ISA 50.02.

A.1.3 Status

- 600 Vdc channel to channel isolation⁽¹⁾
- 10 Vdc channel to channel isolation for all operating conditions with maximum 150 m. (500 ft) of sensor lead length 18 AWG.

A.1.4 Ambient temperature limits

–40 to 185 °F (–40 to 85 °C)

A.1.5 Isolation

Isolation between all sensor channels is rated to 10Vdc over all operating conditions. No damage will occur to the device with up to 600 Vdc between any sensor channel.

A.1.6 Power supply

Powered over FOUNDATION™ fieldbus with standard fieldbus power supplies. The transmitter operates between 9.0 and 32.0 V dc, 22 mA maximum (transmitter power terminals are rated to 42.4 V dc).

A.1.7 Transient protection

The transient protector (option code T1) helps to prevent damage to the transmitter from transients induced on the loop wiring by lightning, welding, heavy electrical equipment, or switch gears. This option is installed at the factory for the Rosemount 848T and is not intended for field installation.

(1) Reference conditions are -40 to 60 °C (-40 to 140 °F) with 30 m. (100 ft) of sensor lead length 18 AWG wire.

A.1.8 Update time

Approximately 1.5 seconds to read all 8 inputs.

A.1.9 Humidity limits

0–99% non-condensing relative humidity

A.1.10 Turn-on time

Performance within specifications is achieved in less than 30 seconds after power is applied to the transmitter.

A.1.11 Alarms

The AI and ISEL function blocks allow the user to configure the alarms to HI-HI, HI, LO, or LO-LO with a variety of priority levels and hysteresis settings.

A.1.12 Backup Link Active Scheduler (LAS)

The transmitter is classified as a device link master, which means it can function as a Link Active Scheduler (LAS) if the current link master device fails or is removed from the segment.

The host or other configuration tool is used to download the schedule for the application to the link master device. In the absence of a primary link master, the transmitter will claim the LAS and provide permanent control for the H1 segment.

FOUNDATION fieldbus parameters

Schedule Entries	20
Links	30
Virtual Communications Relationships (VCR)	20

A.2 Physical specifications

A.2.1 Mounting

The Rosemount 848T can be mounted directly onto a DIN rail or it can be ordered with an optional junction box. When using the optional junction box, the transmitter can be mounted onto a panel or a 2-in. pipe stand (with option code B6).

A.2.2 Entries for optional junction box

No entry

- Used for custom fittings

Cable Gland

- 9 x M20 nickel-plated brass glands for 7.5–11.9 mm unarmored cable

Conduit

- 5 plugged 0.86-in. diameter holes suitable for installing 1/2-in. NPT fittings.

Materials of construction for optional junction box

Junction box type	Paint
Aluminum	Epoxy Resin
Plastic	NA
Stainless Steel	NA
Aluminum Explosion-proof	NA

Weight

Assembly	Weight		
	oz	lb	kg
Rosemount 848T only	7.5	.47	.208
Aluminum ⁽¹⁾	78.2	4.89	2.22
Plastic ⁽¹⁾	78.2	4.89	2.22
Stainless Steel ⁽¹⁾	77.0	4.81	2.18
Aluminum Explosion-proof	557	34.8	15.5

(1) Add 35.2 oz. (2.2 lb., 0.998 kg) for nickel-plated brass glands.

A.2.3 Environmental ratings

NEMA Type 4X and IP66 with optional junction box. JX3 Explosion-proof enclosure rated to -4 °F (-20 °C).

A.3 Function blocks

A.3.1 Analog input (AI)

- Processes the measurement and makes it available on the fieldbus segment.
- Allows filtering, alarming, and engineering unit changes.

A.3.2 Input selector (ISEL)

- Used to select between inputs and generate an output using specific selection strategies such as minimum, maximum, midpoint, or average temperature.
- Since the temperature value always contains the measurement status, this block allows the selection to be restricted to the first “good” measurement.

A.3.3 Multiple analog input block (MAI)

- The MAI block allows the eight AI blocks to be multiplexed together so they serve as one function block on the H1 segment, resulting in greater network efficiency.

A.4 Performance specifications

A.4.1 Stability

- $\pm 0.1\%$ of reading or $0.1\text{ }^{\circ}\text{C}$ ($0.18\text{ }^{\circ}\text{F}$), whichever is greater, for 2 years for RTDs
- $\pm 0.1\%$ of reading or $0.1\text{ }^{\circ}\text{C}$ ($0.18\text{ }^{\circ}\text{F}$), whichever is greater, for 1 year for thermocouples.

A.4.2 Self calibration

The transmitter's analog-to-digital circuitry automatically self-calibrates for each temperature update by comparing the dynamic measurement to extremely stable and accurate internal reference elements.

A.4.3 Vibration effect

Transmitters are tested to high pipeline vibration specification per IEC 60770-1 1999 with no effect on performance.

A.4.4 Electromagnetic compatibility compliance testing

- Meets the criteria under IEC 61326:2006
- Meets the criteria under European Union Directive 2004/108/EC

A.4.5 Accuracy

Table A-1. Input Options/Accuracy

Sensor option	Sensor reference	Input ranges		Accuracy over range(s)	
		$^{\circ}\text{C}$	$^{\circ}\text{F}$	$^{\circ}\text{C}$	$^{\circ}\text{F}$
2- and 3-Wire RTDs					
Pt 50 ($\alpha = 0.00391$)	GOST 6651-94	-200 to 550	-328 to 1022	± 0.57	± 1.03
Pt 100 ($\alpha = 0.00391$)	GOST 6651-94	-200 to 550	-328 to 1022	± 0.28	± 0.50
Pt 100 ($\alpha = 0.00385$)	IEC 751; $\alpha = 0.00385$, 1995	-200 to 850	-328 to 1562	± 0.30	± 0.54
Pt 100 ($\alpha = 0.003916$)	JIS 1604, 1981	-200 to 645	-328 to 1193	± 0.30	± 0.54
Pt 200 ($\alpha = 0.00385$)	IEC 751; $\alpha = 0.00385$, 1995	-200 to 850	-328 to 1562	± 0.54	± 0.98
Pt 200 ($\alpha = 0.003916$)	JIS 1604; $\alpha = 0.003916$, 1981	-200 to 645	-328 to 1193	± 0.54	± 0.98
Pt 500	IEC 751; $\alpha = 0.00385$, 1995	-200 to 850	-328 to 1562	± 0.38	± 0.68
Pt 1000	IEC 751; $\alpha = 0.00385$, 1995	-200 to 300	-328 to 572	± 0.40	± 0.72
Ni 120	Edison Curve No. 7	-70 to 300	-94 to 572	± 0.30	± 0.54
Cu 10	Edison Copper Winding No. 15	-50 to 250	-58 to 482	± 3.20	± 5.76
Cu 100 ($a=428$)	GOST 6651-94	-185 to 200	-365 to 392	± 0.48	± 0.86
Cu 50 ($a=428$)	GOST 6651-94	-185 to 200	-365 to 392	± 0.96	± 1.73
Cu 100 ($a=426$)	GOST 6651-94	-50 to 200	-122 to 392	± 0.48	± 0.86
Cu 50 ($a=426$)	GOST 6651-94	-50 to 200	-122 to 392	± 0.96	± 1.73
Thermocouples—Cold Junction Adds $+ 0.5\text{ }^{\circ}\text{C}$ to Listed Accuracy					
NIST Type B (Accuracy varies according to input range)	NIST Monograph 175	100 to 300 301 to 1820	212 to 572 573 to 3308	± 6.00 ± 1.54	± 10.80 ± 2.78

Table A-1. Input Options/Accuracy

Sensor option	Sensor reference	Input ranges		Accuracy over range(s)	
		°C	°F	°C	°F
NIST Type E	NIST Monograph 175	-200 to 1000	-328 to 1832	± 0.40	± 0.72
NIST Type J	NIST Monograph 175	-180 to 760	-292 to 1400	± 0.70	± 1.26
NIST Type K	NIST Monograph 175	-180 to 1372	-292 to 2501	± 1.00	± 1.80
NIST Type N	NIST Monograph 175	-200 to 1300	-328 to 2372	± 1.00	± 1.80
NIST Type R	NIST Monograph 175	0 to 1768	32 to 3214	± 1.50	± 2.70
NIST Type S	NIST Monograph 175	0 to 1768	32 to 3214	± 1.40	± 2.52
NIST Type T	NIST Monograph 175	-200 to 400	-328 to 752	± 0.70	± 1.26
DIN L	DIN 43710	-200 to 900	-328 to 1652	± 0.70	± 1.26
DIN U	DIN 43710	-200 to 600	-328 to 1112	± 0.70	± 1.26
w5Re26/W26Re	ASTME 988-96	0 to 2000	32 to 3632	± 1.60	± 2.88
GOST Type L	GOST R 8.585-2001	-200 to 800	-392 to 1472	± 0.71	± 1.28
Terminal Temperature		-50 to 85	-58 to 185	±3.50	± 6.30
Ohm Input		0 to 2000 ohms		± 0.90 ohms	
Millivolt Input		-10 to 100 mV		± 0.05 mV	
1000 mV		-10 to 1000 mV		± 1.0 mA	
4–20 mA (Rosemount) ⁽¹⁾		4–20 mA		± 0.01 mA	
4–20 mA (NAMUR) ⁽¹⁾		4–20 mA		± 0.01 mA	
Multi-point Sensors ⁽²⁾					

(1) Requires the S002 option code.

(2) Multi-point (up to 8 points) thermocouples and RTDs are available for purchase with the Rosemount 848T. Input ranges and accuracy for these sensors will depend on the specific multi-point sensor chosen. For more information, contact your local Emerson representative.

A.4.6 Differential configuration notes

Differential capability exists between any two sensor types.

For all differential configurations, the input range is X to Y where:

- X = Sensor A minimum - Sensor B max.
- Y = Sensor A maximum - Sensor B min.

A.4.7 Accuracy for differential configurations

If sensor types are similar (for example, both RTDs or both thermocouples), the accuracy = 1.5 times worst case accuracy of either sensor type. If sensor types are dissimilar (for example, one RTD and one thermocouple), the accuracy = Sensor 1 Accuracy + Sensor 2 Accuracy.

A.4.8 Analog sensors 4–20mA

Two types of 4–20 mA sensors are compatible with the Rosemount 848T. These types must be ordered with the S002 option code complete with an analog connector kit. The alarm levels, accuracy for each type are listed in Table A-2.

Table A-2. Analog Sensors

Sensor option	Alarm levels	Accuracy
4–20mA (Rosemount Standard)	3.9 to 20.8 mA	± 0.01 mA
4–20mA (NAMUR)	3.8 to 20.5 mA	± 0.01 mA

A.4.9 Ambient temperature effect

Transmitter may be installed in locations where the ambient temperature is between -40 and 85 °C (-40 and 185 °F).

A.4.10 Ambient temperature effects

NIST type	Accuracy per 1.0 °C (1.8 °F) change in ambient temperature ⁽¹⁾ °C	Temperature range (°C)
RTD		
Pt 50 ($\alpha = 0.00391$)	• 0.004 °C (0.0072 °F)	N/A
Pt 100 ($\alpha = 0.00391$)	• 0.002 °C (0.0036 °F)	N/A
Pt 100 ($\alpha = 0.00385$)	• 0.003 °C (0.0054 °F)	N/A
Pt 100 ($\alpha = 0.003916$)	• 0.003 °C (0.0054 °F)	N/A
Pt 200 ($\alpha = 0.003916$)	• 0.004 °C (0.0072 °F)	N/A
Pt 200 ($\alpha = 0.00385$)	• 0.004 °C (0.0072 °F)	N/A
Pt 500	• 0.003 °C (0.0054 °F)	N/A
Pt 1000	• 0.003 °C (0.0054 °F)	N/A
Cu 10	• 0.03 °C (0.054 °F)	N/A
Cu 100 (a=428)	• 0.002 °C (0.0036 °F)	N/A
Cu 50 (a=428)	• 0.004 °C (.0072 °F)	N/A
Cu 100 (a=426)	• 0.002 °C (0.0036 °F)	N/A
Cu 50 (a=426)	• 0.004 °C (.0072 °F)	N/A
Ni 120	• 0.003 °C (0.0054 °F)	N/A
Thermocouple (R = the value of the reading)		
Type B	<ul style="list-style-type: none"> • 0.014 °C • 0.032 °C - (0.0025% of (R - 300)) • 0.054 °C - (0.011% of (R - 100)) 	<ul style="list-style-type: none"> • $R \geq 1000$ • $300 \leq R < 1000$ • $100 \leq R < 300$
Type E	• 0.005 °C + (0.00043% of R)	• All
Type J, DIN Type L	<ul style="list-style-type: none"> • 0.0054 °C + (0.00029% of R) • 0.0054 °C + (0.0025% of R) 	<ul style="list-style-type: none"> • $R \geq 0$ • $R < 0$
Type K	<ul style="list-style-type: none"> • 0.0061 °C + (0.00054% of R) • 0.0061 °C + (0.0025% of R) 	<ul style="list-style-type: none"> • $R \geq 0$ • $R < 0$
Type N	• 0.0068 °C + (0.00036% of R)	• All

NIST type	Accuracy per 1.0 °C (1.8 °F) change in ambient temperature ⁽¹⁾ °C	Temperature range (°C)
Type R, Type S	<ul style="list-style-type: none"> • 0.016 °C • 0.023 °C - (0.0036% of R) 	<ul style="list-style-type: none"> • R ≥ 200 • R < 200
Type T, DIN Type U	<ul style="list-style-type: none"> • 0.0064 °C • 0.0064 °C + (0.0043% of R) 	<ul style="list-style-type: none"> • R ≥ 0 • R < 0
GOST Type L	<ul style="list-style-type: none"> • 0.007 °C • 0.007 °C + (0.003% of IRI) 	<ul style="list-style-type: none"> • R ≥ 0 • R < 0
Millivolt	• 0.0005 mV	N/A
2- and 3-wire ohm	• 0.0084 ohms	N/A
4-20 mA (Rosemount)	• 0.0001 mA	N/A
4-20 mA (NAMUR)	• 0.0001 mA	N/A

(1) Change in ambient is in reference to the calibration temperature of the transmitter (20 °C (68 °F) typical from the factory).

A.4.11 Ambient temperature notes



Examples

When using a Pt 100 ($\alpha = 0.00385$) sensor input at 30 °C ambient temperature:


- Digital Temperature Effects: $0.003 \text{ °C} \times (30 - 20) = 0.03 \text{ °C}$
- Worst Case Error: Digital + Digital Temperature Effects = $0.3 \text{ °C} + 0.03 \text{ °C} = 0.33 \text{ °C}$
- Total Probable Error $\sqrt{0.30^2 + 0.03^2} = 0.30 \text{ °C}$

A.5 Dimensional drawings


Junction boxes with no entries (option codes JP1, JA1, and JS1)— external dimensions are the same as those outlined for the other junction box materials in this section.




Stainless-Steel Junction Box—Cable Gland (Option Code JS2)





Aluminum/Plastic Junction Box—Conduit Entry (Option Codes JA3 and JP3)





A.5.1 Mounting options



A.6 Ordering information

Table A-3. Rosemount 848T FOUNDATION fieldbus Ordering Information

★ The Standard offering represents the most common options. The starred options (★) should be selected for best delivery. The Expanded offering is subject to additional delivery lead time.

Model	Product description		
848T	High Density Temperature Measurement Family		
Transmitter output			
F	FOUNDATION fieldbus digital signal (includes AI, MAI, and ISEL function blocks, and Backup Link Active Scheduler)		★
Product certifications⁽¹⁾		Rosemount junction box required?	
I1	ATEX Intrinsic Safety	No	★
I3	NEPSI Intrinsic Safety	No	★
I4	TIIS Intrinsically Safety (FISCO) Type "ia"	No	★
H4	TIIS Intrinsic Safety (FISCO) Type "ib"	No	★
I5 ⁽²⁾	FM Intrinsically Safe	No	★
I6 ⁽²⁾	CSA Intrinsically Safe	No	★
I7	IECEx Intrinsic Safety	No	★
IA	ATEX FISCO Intrinsic Safety	No	★
IE	FM FISCO Intrinsically Safe	No	★
IF ⁽²⁾	CSA FISCO Intrinsically Safe, Division 2	No	★
IG	IECEx FISCO (Intrinsic Safety)	No	★
N1	ATEX Type n (enclosure required)	Yes	★
N5	FM Class I, Division 2, and Dust Ignition-proof (enclosure required)	Yes	★
N6	CSA Class I, Division 2	No	★
N7	IECEx Type n (enclosure required)	Yes	★
NC	ATEX Type n Component (Ex nA nL)	No ⁽³⁾	★
ND	ATEX Dust (enclosure required)	Yes	★
NJ	IECEx Type n Component (Ex nA nL)	No ⁽³⁾	★
NK	FM Class 1, Division 2	No	★
NA	No Approval	No	★
E6	CSA Explosion-proof, Dust Ignition-proof, Division 2 (JX3 enclosure required)	Yes ⁽⁴⁾	
Options (include with selected model number)			
Input types			
S001	RTD, Thermocouple, mV, ohm Inputs		★
S002 ⁽⁵⁾	RTDs, Thermocouple, mV, ohm and 4–20 mA Inputs		★
PlantWeb advanced diagnostics			
D04	Measurement Validation Diagnostic		★
Transient protection			
T1	Integral Transient Protector		★
Mounting bracket			
B6	Mounting Bracket for 2-in. pipe mounting – SST bracket and bolts		★
Enclosure options			
JP1	Plastic Junction Box; No Entries		★
JP2	Plastic Box, Cable Glands (9 x M20 nickel-plated brass glands for 7.5–11.9 mm unarmored cable)		★

Table A-3. Rosemount 848T FOUNDATION fieldbus Ordering Information

★ The Standard offering represents the most common options. The starred options (★) should be selected for best delivery. The Expanded offering is subject to additional delivery lead time.

JP3	Plastic Box, Conduit Entries (5 Plugged Holes, suitable for installing 1/2-in. NPT fittings)	★
JA1	Aluminum Junction Box; No Entries	★
JA2	Aluminum Cable Glands (9 x M20 nickel-plated brass glands for 7.5–11.9 mm unarmored cable)	★
JA3	Aluminum Conduit Entries (5 Plugged Holes, suitable for installing 1/2-in. NPT fittings)	★
JS1	Stainless Steel Junction Box; No Entries	★
JS2	Stainless Steel Box, Cable Glands (9 x M20 nickel-plated brass glands for 7.5–11.9 mm unarmored cable)	★
JS3	Stainless Steel Box, Conduit Entries (5 Plugged Holes, suitable for installing 1/2-in. NPT fittings)	★
JX3 ⁽⁶⁾	Explosion-proof Box, Conduit Entries (4 Plugged Holes, suitable for installing 1/2-in. NPT fittings)	★
Software configuration		
C1	Custom Configuration of Date, Descriptor, Message and Wireless Parameters (Requires CDS with Order)	★
Line filter		
F5	50 Hz Line Voltage Filter	★
Calibration certificate		
Q4	Calibration Certificate (3-Point Calibration)	★
Shipboard certification		
SBS	American Bureau of Shipping (ABS) Type Approval	★
SLL	Lloyd's Register (LR) Type Approval	★
Special temperature test		
LT	Test to -60 °F (-51.1 °C)	
Conduit electrical connector		
GE ⁽⁷⁾	M12, 4-pin, Male Connector (eurofast [®])	★
GM ⁽⁷⁾	A size Mini, 4-pin, Male Connector (minifast [®])	★
Typical model number: 848T F I5 S001 T1 B6 JA2		

(1) Consult factory for availability.

(2) Available only with S001 option.

(3) The Rosemount 848T ordered with component approval is not approved as a stand-alone unit. Additional system certification is required.

(4) Enclosure Option JX3 must be ordered with Product Certification Code E6. (O-ring for the JX3 enclosure rated to -20 °C).

(5) S002 is only available with Product Certification N5, N6, N1, NC, NK, and NA.

(6) JX3 Explosion-proof enclosure rated to -4 °F (-20 °C).

(7) Available with no approval or Intrinsically Safe approvals only. For FM Intrinsically Safe (option code I5), install in accordance with Rosemount drawing 00848-4402.

Appendix B Product Certificates

European Directive Information	page 69
Intrinsically Safe and Non-Incendive installations	page 81
Installation drawings	page 82

B.1 European Directive Information

A copy of the EC Declaration of Conformity can be found at the end of the Quick Start Guide. The most recent revision of the EC Declaration of Conformity can be found at www.rosemount.com.

B.2 Ordinary Location Certification from FM Approvals

As standard, the transmitter has been examined and tested to determine that the design meets the basic electrical, mechanical, and fire protection requirements by FM Approvals, a nationally recognized test laboratory (NRTL) as accredited by the Federal Occupational Safety and Health Administration (OSHA).

B.3 Installing Equipment in North America

The US National Electrical Code (NEC) and the Canadian Electrical Code (CEC) permit the use of Division marked equipment in Zones and Zone marked equipment in Divisions. The markings must be suitable for the area classification, gas, and temperature class. This information is clearly defined in the respective codes.

B.3.1 USA

I5 FM Intrinsically Safe and Nonincendive Certificate: 3011568

Standards: FM Class 3600:1998, FM Class 3610:2010, FM Class 3611:2004, FM Class 3810:2005, ANSI/ISA 60079-0:2009, ANSI/ISA 60079-11:2009, NEMA 250:1991, IEC 60529:2011

Markings: IS CL I, DIV 1, GP A, B, C, D; T4 (-50 °C ≤ Ta ≤ +60 °C); NI CL I, DIV 2, GP A, B, C, D; T4A (-50 °C ≤ Ta ≤ +85 °C); T5 (-50 °C ≤ Ta ≤ +70 °C) when installed per Rosemount drawing 00848-4404

Note

Transmitters marked with Nonincendive CL I, DV 2 can be installed in Division 2 locations using general Division 2 wiring methods or Nonincendive Field Wiring (NIFW). See Drawing 00848-4404.

- IE** FM FISCO
Certificate: 3011568
Standards: FM Class 3600:1998, FM Class 3610:2010, FM Class 3611:2004, FM Class 3810:2005, ANSI/ISA 60079-0:2009, ANSI/ISA 60079-11:2009, NEMA 250:1991, IEC 60529:2011
Markings: IS CLI, DIV 1, GP A, B, C, D; T4 (-50 °C ≤ Ta ≤ +60 °C); NI CLI, DIV 2, GP A, B, C, D; T4A (-50 °C ≤ Ta ≤ +85 °C); T5 (-50 °C ≤ Ta ≤ +70 °C) when installed per Rosemount drawing 00848-4404
- N5** Nonincendive and Dust-Ignition-proof
Certificate: 3011568
Standards: FM Class 3600:1998, FM Class 3611:2004, FM Class 3810:2005, ANSI/ISA 60079-0:2009, NEMA 250:1991, IEC 60529:2011
Markings: NI CLI, DIV 2, GP A, B, C, D; DIP CL II/III, DIV 1, GP E, F, G; T4A (-50 °C ≤ Ta ≤ +85 °C); T5 (-50 °C ≤ Ta ≤ +70 °C) when installed per Rosemount drawing 00848-4404; Type 4X
- NK** Nonincendive
Certificate: 3011568
Standards: FM Class 3600:1998, FM Class 3611:2004, FM Class 3810:2005, ANSI/ISA 60079-0:2009, NEMA 250:1991, IEC 60529:2001
Markings: NI CLI, DIV 2, GP A, B, C, D; T4A (-50 °C ≤ Ta ≤ +85 °C); T5 (-50 °C ≤ Ta ≤ +70 °C) when installed per Rosemount drawing 00848-4404

Note

Only the N5 and NK are valid with the S002 option.

Table B-1. Entity Parameters

FIELDBUS (Input)	FISCO (Input)	Nonincendive (Input)	Sensor Field Terminal (Output)
$V_{\max} = 30 \text{ V}$	$V_{\max} = 17.5 \text{ V}$	$V_{\max} = 42.4 \text{ V}$	$V_{\text{OC}} = 12.5 \text{ V}$
$I_{\max} = 300 \text{ mA}$	$I_{\max} = 380 \text{ mA}$	$C_i = 2.1 \text{ nF}$	$I_{\text{SC}} = 4.8 \text{ mA}$
$P_i = 1.3 \text{ W}$	$P_i = 5.32 \text{ W}$	$L_i = 0 \text{ H}$	$P_o = 15 \text{ mW}$
$C_i = 2.1 \text{ nF}$	$C_i = 2.1 \text{ nF}$	-	$C_A = 1.2 \text{ mF}$
$L_i = 0 \text{ H}$	$L_i = 0 \text{ H}$	-	$L_A = 1 \text{ H}$

B.3.2

Canada

- E6** CSA Explosion-proof, Dust-Ignition-proof, Division 2 (JX3 Enclosure Required)
Certificate: 1261865
Standards: CAN/CSA C22.2 No. 0-M91 (R2001), CSA Std. C22.2 No. 25.1966, CSA Std. C22.2 No. 30-M1986, CAN/CSA C22.2 No. 94-M91, CSA Std. C22.2 No. 142-M1987, CSA Std. C22.2 No. 213-M1987, CSA Std. C22.2 No. 60529:05
Markings: Explosion-proof for Class I, Division 1, Groups B, C, and D; T4 (-40 °C ≤ Ta ≤ +40 °C) when installed per Rosemount drawing 00848-1041; Dust-Ignition-proof for Class II, Division 1, Groups E, F, and G; Class III; Class I, Division 2, Groups A, B, C, and D; T3C (-50 °C ≤ Ta ≤ +60 °C) when installed per Rosemount drawing 00848-4405; Conduit Seal Required

- I6** CSA Intrinsically Safe and Division 2
Certificate: 1261865
Standards: CAN/CSA C22.2 No. 0-M91 (R2001), CAN/CSA C22.2 No. 94-M91, CSA Std. C22.2 No. 142-M1987, CSA Std. C22.2 No. 157-92, CSA Std. C22.2 No. 213-M1987, CSA Std. C22.2 No. 60529:05
Markings: Intrinsically Safe for Class I, Division 1, Groups A, B, C, and D; T3C (-50 °C ≤ Ta ≤ +60 °C) when installed per Rosemount drawing 00848-4405; Class I, Division 2, Groups A, B, C, D; T3C (-50 °C ≤ Ta ≤ +60 °C) when installed per Rosemount drawing 00848-4405
- IF** CSA FISCO
Certificate: 1261865
Standards: CAN/CSA C22.2 No. 0-M91 (R2001), CAN/CSA C22.2 No. 94-M91, CSA Std. C22.2 No. 142-M1987, CSA Std. C22.2 No. 157-92, CSA Std. C22.2 No. 213-M1987, CSA Std. C22.2 No. 60529:05
Markings: Intrinsically Safe for Class I, Division 1, Groups A, B, C, and D; T3C (-50 °C ≤ Ta ≤ +60 °C) when installed per Rosemount drawing 00848-4405; Class I, Division 2, Groups A, B, C, D; T3C (-50 °C ≤ Ta ≤ +60 °C) when installed per Rosemount drawing 00848-4405
- N6** CSA Division 2 and Dust-Ignition-proof (enclosure required)
Certificate: 1261865
Standards: CAN/CSA C22.2 No. 0-M91 (R2001), CSA Std. C22.2 No. 30-M1986, CAN/CSA C22.2 No. 94-M91, CSA Std. C22.2 No. 142-M1987, CSA Std. C22.2 No. 213-M1987, CSA Std. C22.2 No. 60529:05
Markings: Class I, Division 2, Groups A, B, C, and D; T3C (-50 °C ≤ Ta ≤ +60 °C) when installed per Rosemount drawing 00848-4405; Dust-Ignition-proof for Class II, Division 1, Groups E, F, and G; Class III; Conduit Seal Required

B.4 Europe


- I1** ATEX Intrinsic Safety
Certificate: Baseefa09ATEX0093X
Standards: EN 60079-0:2012, EN60079-11:2012
Marking Ⓔ II 1 G Ex ia IIC T4 Ga (-50 °C ≤ Ta ≤ +60 °C) when installed per drawing 00848-4406

Special Conditions for Safe Use (X):

1. The equipment must be installed in an enclosure that provides a degree of protection of at least IP20. Non-metallic enclosures must be suitable to prevent electrostatic hazards and light alloy or zirconium enclosures must be protected from impact and friction when installed.
2. The equipment is not capable of withstanding the 500V insulation test required by EN 60079-11:2012, clause 6.3.13. This must be taken into account when installing the equipment.

Table B-2. ATEX Entity Parameters

Fieldbus (Input)	Sensor Field Terminal (Output)
$U_i = 30 \text{ V}$	$U_o = 12.5 \text{ V}$
$I_i = 300 \text{ mA}$	$I_o = 4.8 \text{ mA}$
$P_i = 1.3 \text{ W}$	$P_o = 15 \text{ mW}$
$C_i = 2.1 \text{ nF}$	$C_o = 1.2 \text{ }\mu\text{F}$
$L_i = 0$	$L_o = 1 \text{ H}$


- IA** ATEX FISCO Intrinsic Safety
Certificate: Baseefa09ATEX0093X
Standards: EN 60079-0:2012, EN60079-11:2012
Marking  II 1 G Ex ia IIC T4 Ga (-50 °C ≤ Ta ≤ +60 °C) when installed per drawing 00848-4406

Special Conditions for Safe Use (X):

1. The equipment must be installed in an enclosure that provides a degree of protection of at least IP20. Non-metallic enclosures must be suitable to prevent electrostatic hazards and light allow or zirconium enclosures must be protected from impact and friction when installed.
2. The equipment is note capable of withstanding the 500V insulation test required by EN 60079-11:2012, clause 6.3.13. This must be taken into account when installing the equipment.


Table B-3. ATEX FISCO Entity Parameters

Power/bus	Sensor
$U_i = 17.5 \text{ V}$	$U_o = 12.5 \text{ V}$
$I_i = 380 \text{ mA}$	$I_o = 4.8 \text{ mA}$
$P_i = 5.32 \text{ W}$	$P_o = 15 \text{ mW}$
$C_i = 2.1 \text{ nF}$	$C_o = 1.2 \text{ mF}$
$L_i = 0$	$L_o = 1 \text{ H}$

- N1** ATEX Type n (with enclosure)
Certificate: Baseefa09ATEX0095X
Standards: EN 60079-0:2006, EN60079-15:2005
Marking  II 3 G Ex nA nL IIC T5 (- 40 °C ≤ Ta ≤ + 65 °C)

Special Conditions for Safe Use (X):

1. Provision must be made, external to the apparatus, to ensure the rated voltage of the apparatus supply is not exceeded by transient disturbances of more than 40.
2. The electrical circuit is connected directly to earth; this must be taken into account when installing the apparatus.

- NC** ATEX Type n (without enclosure)
Certificate: Baseefa09ATEX0094U
Standards: EN 60079-0:2006, EN60079-15:2005
Marking  II 3 G Ex nA nL IIC T4 (-50 °C ≤ Ta ≤ +85 °C), T5(-50 °C ≤ Ta ≤ +70 °C)

Special Conditions for Safe Use (X):


1. The component must be installed in a suitable component certified enclosure that provides a degree of protection of at least IP54 and meets the relevant material and environmental requirements of EN 60079-0:2006 and EN 60079-15:2005.
2. Provision must be made, external to the apparatus, to ensure the rated voltage of the apparatus supply is not exceeded by transient disturbances of more than 40%.
3. The electrical circuit is connected directly to earth; this must be taken into account when installing the apparatus.

Note

The 848T may also be installed in an external energy limited circuit as Ex nL IIC. In this case the following parameters apply

Table B-4. Baseefa Entity Parameters

Power/Bus (Input)	Sensor Field Terminal (Output)
$U_i = 42.4 \text{ V}$	$U_o = 12.5 \text{ V}$
$C_i = 2.1 \text{ nF}$	$I_o = 2.5 \text{ mA}$
$L_i = 0$	$C_o = 1000 \text{ mF}$
-	$L_o = 1 \text{ H}$

ND ATEX Dust
Certificate: BAS01ATEX1315X
Standards: EN 50281-1-1:1998
Marking  II 1 D T90 (-40 °C ≤ Ta ≤ +65 °C); IP66

Special Conditions for Safe Use (X):

1. The user must ensure that the maximum rated voltage and current (42.4 volts, 22 milliamp DC) are not exceeded. All connections to other apparatus or associated apparatus shall have control over this voltage and current equivalent to a category “ib” circuit according to EN 50020.
2. Component approved EEx e cable entries must be used which maintain the ingress protection of the enclosure to at least IP66.
3. Any unused cable entry holes must be filled with component approved EEx e blanking plugs.
4. The ambient temperature range of use shall be the most restrictive of the apparatus, cable gland or blanking plug.

B.5 International

I7 IECEx Intrinsic Safety
Certificate: IECEx BAS 09.0030X
Standards: IEC 60079-0:2011, IEC60079-11:2011
Markings: II 1 G Ex ia IIC T4 Ga (- 50 °C ≤ Ta ≤ + 60 °C)

Special Conditions of Safe Use (X):

1. The equipment must be installed in an enclosure that provides a degree of protection of at least IP20. Non-metallic enclosures must be suitable to prevent electrostatic hazards and light allow or zirconium enclosures must be protected from impact and friction when installed.
2. The equipment is note capable of withstanding the 500V insulation test required by EN 60079-11:2012, clause 6.3.13. This must be taken into account when installing the equipment.

IG IECEx FISCO Intrinsic Safety
Certificate: IECEx BAS 09.0030X
Standards: IEC 60079-0:2011, IEC60079-11:2011
Markings: II 1 G Ex ia IIC T4 Ga (-50 °C ≤ Ta ≤ +60 °C)

Special Conditions of Safe Use (X):

1. The equipment must be installed in an enclosure that provides a degree of protection of at least IP20. Non-metallic enclosures must be suitable to prevent electrostatic hazards and light allow or zirconium enclosures must be protected from impact and friction when installed.
2. The equipment is note capable of withstanding the 500V insulation test required by EN 60079-11:2012, clause 6.3.13. This must be taken into account when installing the equipment.

Table B-5. IECEx Entity Parameters

FISCO (Input)	Sensor Field Terminal (Output)
$U_i = 17.5 \text{ Vdc}$	$U_o = 12.5 \text{ Vdc}$
$I_i = 380 \text{ mA}$	$I_o = 4.8 \text{ mA}$
$P_i = 5.32 \text{ W}$	$P_o = 15 \text{ mW}$
$C_i = 2.1 \text{ nF}$	$C_o = 1.2 \text{ mF}$
$L_i = 0$	$L_o = 1 \text{ H}$

N7 IECEx Type n Approval
Certificate: IECEx BAS 09.0032X
Standards: IEC 60079-0:2004, IEC 60079-15:2005
Markings: Ex nA nL IIC T5(-40 °C ≤ Ta ≤ +65 °C)

Special Conditions of Safe Use:

1. Provision must be made, external to the apparatus, to ensure the rated voltage of the apparatus supply is not exceeded by transient disturbances of more than 40%.
2. The electrical circuit is connected directly to earth; this must be taken into account when installing the apparatus.

NC ATEX Type n (without enclosure)
Certificate: IECEx BAS 09.0031U
Standards: IEC 60079-0:2004, IEC 60079-15:2005
Markings: Ex nA nL IIC T4 (-50 °C ≤ Ta ≤ +85 °C), T5(-50 °C ≤ Ta ≤ +70 °C)

Special Conditions of Safe Use:

1. The component must be installed in a suitable component certified enclosure that provides a degree of protection of at least IP54 and meets the relevant material and environmental requirements of EN 60079-0:2006 and EN 60079-15:2005.
2. Provision must be made, external to the apparatus, to ensure the rated voltage of the apparatus supply is not exceeded by transient disturbances of more than 40%.
3. The electrical circuit is connected directly to earth; this must be taken into account when installing the apparatus.

B.5.1 Brazil

- I2** INMETRO Intrinsic Safety
Certificate: NCC 12.1156X
Standards: ABNT NBR IEC 60079-0:2008 Versão corrigida 2011, ABNT NBR IEC 60079-11:2009, ABNT NBR IEC 60079-26:2008 Versão corrigida 2009, ABNT NBR IEC 60079-27:2010
Markings: Ex ia IIC T4 (-50 °C ≤ T_a ≤ +60 °C)

Special Conditions of Safe Use:

1. The equipment must be installed in an enclosure that provides a degree of protection of at least IP20 and which is appropriate to the application specified in ABNT NBR IEC60079-0.
2. The equipment is not capable of withstanding the dielectric strength test of 500V according to item 6.3.12 of ABNT NBR IEC60079-1, this should be considered in the installation, see installation manual.

Table B-6. INMETRO-2 Entity Parameters

FISCO (Input)	Sensor Field Terminal (Output)
U _i = 30 Vdc	U _o = 12.5 Vdc
I _i = 300 mA	I _o = 4.8 mA
P _i = 1.3 W	P _o = 15 mW
C _i = 2.1 nF	C _o = 1.2 mF
L _i = 0	L _o = 1 H

- IB** INMETRO Intrinsic Safety
Certificate: NCC 12.1156X
Standards: ABNT NBR IEC 60079-0:2008 Versão corrigida 2011, ABNT NBR IEC 60079-11:2009, ABNT NBR IEC 60079-26:2008 Versão corrigida 2009, ABNT NBR IEC 60079-27:2010
Markings: Ex ia IIC T4 (-50 °C ≤ T_a ≤ +60 °C)

Special Conditions of Safe Use:

1. The equipment must be installed in an enclosure that provides a degree of protection of at least IP20 and which is appropriate to the application specified in ABNT NBR IEC60079-0.
2. The equipment is not capable of withstanding the dielectric strength test of 500V according to item 6.3.12 of ABNT NBR IEC60079-1, this should be considered in the installation, see installation manual.

Table B-7. INMETRO-B Entity Parameters

FISCO (Input)	Sensor Field Terminal (Output)
$U_i = 17.5 \text{ Vdc}$	$U_o = 12.5 \text{ Vdc}$
$I_i = 380 \text{ mA}$	$I_o = 4.8 \text{ mA}$
$P_i = 5.32 \text{ W}$	$P_o = 15 \text{ mW}$
$C_i = 2.1 \text{ nF}$	$C_o = 1.2 \text{ mF}$
$L_i = 0$	$L_o = 1 \text{ H}$

- N2** INMETRO Intrinsic Safety Zone 2
Certificate: NCC 12.1182X
Standards: ABNT NBR IEC 60079-0:2008 Versao corrigida 2011, ABNT NBR IEC 60079-11:2009
Markings: Ex ic IIC T5 (-40°C ≤ T_a ≤ +65 °C) Gc

Special Conditions of Safe Use:

1. The equipment must be mounted within an enclosure that meets at least the degree of protection IP54, with material and manufacture covered by a quality certificate. If the enclosure is non-metallic, the enclosure must have a surface resistance less than 1 GΩ. If the enclosure is made of zirconium alloy, the enclosure must be protected against impact and friction when installed.
2. Provision must be made, external to the equipment, to ensure that the supply voltage (42.2Vdc) is not exceeded by transient disturbances of more than 40%.
3. The maximum ambient temperature will be restricted to lowest temperature rating of the equipment, cables, cables glands or plugs.
4. The electric circuit is connected directly to ground, this should be taken into account when installing the equipment.

B.5.2 China

- I3** NEPSI Intrinsic Safety
Certificate: GYJ111365X
Standards: GB3836.1-2000, GB3836.4-2000
Markings: Ex ia IIC T4

Special Conditions for Safe Use (X):

1. Only when temperature transmitter is installed in IP 20(GB4208-2008) housing, can it be used in a hazardous location. Metallic housing should observe the requirements of GB3836.1-2000 Clause 8. Non-metallic housing should observe the requirements of GB3836.1-2000 Clause 7.3.

2. This apparatus is not capable of withstanding the 500 V rms insulation test required by Clause 6.4.12 of GB3836.4-2000.
3. The ambient temperature range of the equipments is T4 ($-50\text{ }^{\circ}\text{C} \leq T_a \leq +60\text{ }^{\circ}\text{C}$).
4. Parameters:

Terminals of power/loop (1-2):

Output	Maximum output voltage: U_o (V)	Maximum output current: I_o (mA)	Maximum output power: P_o (mW)	Maximum external parameters	
				C_o (mF)	L_o (H)
F	30	300	1.3	2.1	0
F (FISCO)	17.5	380	5.32	2.1	0

Note

Non-FISCO parameters listed above must be derived from a linear supply with a resistance limited output.

Terminals of sensor:

Output	Terminals	Maximum output voltage: U_o (V)	Maximum output current: I_o (mA)	Maximum output power: P_o (mW)	Maximum external parameters	
					C_o (mF)	L_o (H)
F	1-8	12.5	4.8	15	1.2	1

5. The product complies to the requirements for FISCO field devices specified in IEC60079-27: 2008. For the connection of an intrinsically safe circuit in accordance FISCO model, FISCO parameters of this product are as above.
6. The product should be used with Ex-certified associated apparatus to establish explosion protection system that can be used in explosive gas atmospheres. Wiring and terminals should comply with the instruction manual of the product and associated apparatus.
7. The cables between this product and associated apparatus should be shielded cables (the cables must have insulated shield). The shielded cable has to be grounded reliably in non-hazardous area.
8. End users are not permitted to change any component's insides, but to settle the problem, in conjunction with manufacturer to avoid damage to the product.
9. During installation, use and maintenance of this product, observe following standards:
GB3836.13-1997 "Electrical apparatus for explosive gas atmospheres Part 13: Repair and overhaul for apparatus used in explosive gas atmospheres."
GB3836.15-2000 "Electrical apparatus for explosive gas atmospheres Part 15: Electrical installations in hazardous area (other than mines)."

GB3836.16-2006 “Electrical apparatus for explosive gas atmospheres Part 16: Inspection and maintenance of electrical installation (other than mines).”

GB50257-1996 “Code for construction and acceptance of electric device for explosion atmospheres and fire hazard electrical equipment installation”

- N3** NEPSI Type n
 Certificate: GYJ12.1035U
 Standards: GB3836.1-2010, GB3836.8-2003
 Markings: Ex nA nL IIC T4/T5 Gc

Special Conditions for Safe Use (X):

1. This component is not capable of withstanding the 500V electrical strength test defined in Clause 8.1 of GB3836.8-2003. The must be taken into account during installation.
2. This component must be housed in a suitable component certified enclosure that provides a degree of protection of at least IP54 and meets the relevant material and environmental requirements of GB3836.1-2010 and GB3836.8-2003.
3. Provision must be made, external to the component, to ensure the rated voltage of the component supply is not exceeded by transient disturbances of more the 40%.
4. The ambient temperature range is:

T code	Ambient Temperature
T4	$-50\text{ °C} \leq T_a \leq +85\text{ °C}$
T5	$-50\text{ °C} \leq T_a \leq +70\text{ °C}$

5. Maximum input voltage: 42.4V.
6. End users are not permitted to change any components inside, but to settle the problem in conjunction with manufacturer to avoid damage to the product.
7. During installation, use and maintenance of this product, observe following standards:

GB3836.13-1997 “Electrical apparatus for explosive gas atmospheres Part 13: Repair and overhaul for apparatus used in explosive gas atmospheres”

GB3836.15-2000 “Electrical apparatus for explosive gas atmospheres Part 15: Electrical installations in hazardous area (other than mines)”

GB3836.16-2006 “Electrical apparatus for explosive gas atmospheres Part 16: Inspection and maintenance of electrical installation (other than mines)”

GB50257-1996 “Code for construction and acceptance of electric device for explosion atmospheres and fire hazard electrical equipment installation engineering”

B.5.3 Japan

- I4** TIIS FISCO Intrinsic Safety (ia)
 Certificate: TC19713
 Markings: IIC T4
- H4** TIIS FISCO Intrinsic Safety (ib)
 Certificate: TC20737
 Markings: IIC T4

B.6 Combinations


KG Combination of I1/IA, I5/IE, I6/IF, and I7/IG

B.7 Conduit Plugs and Adapters

ATEX Flameproof and Increased Safety

Certificate: FM13ATEX0076X

Standards: EN 60079-0:2012, EN 60079-1:2007, IEC 60079-7:2007

Marking  2 G Ex de IIC Gb

Special Conditions for Safe Use (X):

1. When the thread adapter or blanking plug is used with an enclosure in type of protection increased safety “e” the entry thread shall be suitably sealed in order to maintain the ingress protection rating (IP) of the enclosure.
2. The blanking plug shall not be used with an adapter.
3. Blanking Plug and Threaded Adapter shall be either NPT or Metric thread forms. G½ and PG 13.5 thread forms are only acceptable for existing (legacy) equipment installations.

IECEx Flameproof and Increased Safety

Certificate: IECEx FMG 13.0032X

Standards: IEC 60079-0:2011, IEC 60079-1:2007, IEC 60079-7:2006-2007

Markings: Ex de IIC Gb

Special Conditions for Safe Use (X):

1. When the thread adapter or blanking plug is used with an enclosure in type of protection increased safety “e” the entry thread shall be suitably sealed in order to maintain the ingress protection rating (IP) of the enclosure.
2. The blanking plug shall not be used with an adapter.
3. Blanking Plug and Threaded Adapter shall be either NPT or Metric thread forms. G½ and PG 13.5 thread forms are only acceptable for existing (legacy) equipment installations.

Conduit plug thread sizes:

Thread	Identification Mark
M20 x 1.5	M20
½ - 14 NPT	½ NPT
G½	G½

Thread adapter thread sizes:

Male Thread	Identification Mark
M20 x 1.5 – 6H	M20
½ - 14 NPT	½ - 14 NPT
¾ - 14 NPT	¾ - 14 NPT
Female Thread	Identification Mark
M20 x 1.5 – 6H	M20
½ - 14 NPT	½ - 14 NPT
PG 13.5	PG 13.5

B.8 Additional Certifications






- SBS** American Bureau of Shipping (ABS) Type Approval
Certificate: 011-HS771994C-1-PDA
ABS Rules: 2013 Steel Vessels Rules 1-1-4/7.7, 1-1-Appendix 3, 4-8-3/1.7, 4-8-3/13.1
- SBV** Bureau Veritas (BV) Type Approval
Certificate: 26325/A1 BV
Requirements: Bureau Veritas Rules for the Classification of Steel Ships
Application: Class notations: AUT-UMS, AUT-CCS, AUT-PORT and AUT-IMS
- SDN** Det Norske Veritas (DNV) Type Approval
Certificate: A-13246
Intended Use: Det Norske Veritas' Rules for Classification of Ships, High Speed & Light Craft and Det Norske Veritas' Offshore Standards

Applications:

Location Classes	
Temperature	D
Humidity	B
Vibration	A
EMC	B
Enclosure	B/IP66: AI C/IP66: SST

- I3** Lloyds Register (LR) Type Approval
Certificate: 11/60002 (E2)
Application: Environmental categories ENV1, ENV2, ENV2 and ENV5

B.9 Intrinsically Safe and Non-Incendive installations

Approval	Safe area	Zone 2 (category 3) Division 2	Zone 1 (category 2)	Zone 0 (category 1)	
		Division 1			
GAS INSTALLATIONS					
I5, I6, I1, I7, IE, IA	Approved I.S. or FISCO barrier	—		 848T without enclosure	
N1, N7	Non-approved power supply	 848T with enclosure	—		
N5	Non-approved power supply	 848T with enclosure	—		
NC	Approved non-incendive power supply or barrier	—		 848T without enclosure	
DUST INSTALLATIONS					
N5, ND	Non-approved power supply	—			 848T with enclosure

— Standard cable
— Division 2 wiring


B.10 Installation drawings


The installation guidelines presented by the drawings must be followed in order to maintain certified ratings for installed transmitters.

Rosemount Drawing 00848-4404, 3 Sheets
Factory Mutual Intrinsic Safety/ FISCO Installation Drawing

Rosemount Drawing 00848-4405, 2 Sheets
Canadian Standards Association Intrinsic Safety/FISCO Installation Drawing

Figure B-1. FM Intrinsic Safety/ FISCO





FM CERTIFIED PRODUCT
NO MODIFICATIONS PERMITTED WITHOUT THE APPROVAL OF RITC TEMPERATURE DESIGN ENGINEERING

SENSOR TERMINAL OUTPUT PARAMETER LIMITS
 $U_o = 12.5 \text{ Vdc}$
 $I_o = 4.8 \text{ mAdc}$
 $P_o = 15 \text{ mW}$
 $C_o = 1.2 \text{ uF}$
 $L_o = 1 \text{ H}$

POWER / LOOP TERMINAL INPUT FISCO PARAMETER LIMITS
 $U_i = 17.5 \text{ Vdc}$
 $I_i = 380 \text{ mAdc}$
 $P_i = 5.32 \text{ W}$
 $C_i = 2.1 \text{ nF}$
 $L_i = 0 \text{ mH}$

NOTES:

2.1. FISCO IS A SUBSET OF STANDARD INTRINSICALLY SAFE INSTALLATION (SEE PAGE 1) EXCEPT AS SPECIFICALLY NOTED HERE.

2.2. THE FM FISCO INSTALLATION IS ONLY VALID WITH MODEL OPTION CODE IE OR IG.

WHAT IS FISCO?
FIELDBUS INTRINSICALLY SAFE CONCEPT IS A PARTICULAR, YET SUFFICIENTLY FLEXIBLE, AGREED UPON INSTALLATION CONFIGURATION. THIS ALLOWS FOR A CONTROLLED DISTRIBUTION OF THE ELECTRICAL CHARACTERISTICS AROUND THE SEGMENT.

WHAT ARE THE BENEFITS TO INSTALLING WITHIN THE BOUNDS OF THIS CONFIGURATION?
A. MORE DEVICES ARE ALLOWED ON THE FIELDBUS SINCE MORE POWER CAN BE APPLIED.
B. THE R, L, AND C CHARACTERISTICS OF THE FIELDBUS CABLE NEED NOT BE CALCULATED.

WIRING CONFIGURATION:

- LENGTH, $L \leq 1000 \text{ m}$
- TRUNK CABLE, $R \leq 30 \text{ m}$
- SPUR CABLE, $R \leq 1 \text{ m}$
- CABLE PROPERTIES, $R = 15 \text{ TO } 150 \text{ Ohms/km}$
- LOOP RESISTANCE, $R = 0.4 \text{ TO } 1 \text{ Ohm/km}$
- INDUCTANCE, $L = 80 \text{ TO } 200 \text{ nH/km}$
- CAPACITANCE, $C = 80 \text{ TO } 200 \text{ nF/km}$

C = C LINE-TO-LINE +1/2 C LINE-TO-SHIELD (FOR BOTH LINES FLOATING WITH RESPECT TO SHIELD)

C = C LINE-TO-LINE + C LINE-TO-SHIELD (FOR ONE LINE TIED TO SHIELD)

FISCO FOR CLASS 1, DIVISION 1, GROUPS A, B, C, D.

APPARATUS CRITERIA:

2.3. $C_i \leq 5 \text{ uF}$ AND $L_i \leq 10 \text{ uH}$ FOR EACH APPARATUS, OTHER THAN THE TERMINATOR, CONNECTED TO THE FIELDBUS.

$R = 90 \text{ TO } 100 \text{ Ohms}$ AND $C = 0 \text{ TO } 2.2 \text{ uF}$ FOR THE LINE TERMINATION. THIS TERMINATOR MAY BE INTEGRATED INTO AN APPARATUS.

2.5. EACH APPARATUS, OTHER THAN THE ASSOCIATED APPARATUS, MUST BE PASSIVE. (NOT ALLOWED TO PROVIDE ENERGY TO THE SYSTEM.)

2.6. INTERCONNECTION IS ALLOWED WHEN THE FOLLOWING IS TRUE:

I.S. APPARATUS (FIELD DEVICE) INPUT \geq ASSOCIATED APPARATUS OUTPUT

$V_{max} \text{ OR } U_i \geq V_{oc}, V_i \text{ OR } U_o$

$I_{max} \text{ OR } I_i \geq I_{sc}, I_i \text{ OR } I_o$

$P_{max} \text{ OR } P_i \geq P_o$

COMPENSATE AND PROPORTIONATE SURFACE FINISH UNLESS OTHERWISE SPECIFIED

UNLESS OTHERWISE SPECIFIED DIMENSIONS IN INCHES, MILLIMETERS AND METERS SHALL BE TO UNLESS OTHERWISE SPECIFIED

ROSEMOUNT
800 North Rosemount, Channahon, IL 61515 USA

11 FM INSTALLATION DRAWING, I.S. & NON-INCLUSIVE, FISCO, CL 1 DV 2 & DUST

DATE: 12/17/09 DRAWING NO. 00848-4404


REVISION: 1.0


SCALE: 1:1


DRAWING NO. 00848-4404


SHEET 2 OF 3


Figure B-2. CSA Intrinsic Safety/ FISCO











Appendix C FOUNDATION™ fieldbus Technology

Overview	page 89
Function blocks	page 89
Device descriptions	page 90
Block operation	page 91
Network communication	page 91

C.1 Overview

FOUNDATION fieldbus is an all-digital, serial, two-way, multi-drop communication protocol that interconnects devices such as transmitters, sensors, actuators, and valve controllers. Fieldbus is a Local Area Network (LAN) for instruments that are used in both process and manufacturing automation, having the built-in capability to distribute the control applications across the network. The fieldbus environment is the base level group of digital networks and the hierarchy of plant networks.

The FOUNDATION fieldbus retains the desirable features of the 4–20 mA analog system, including standardized physical interface to the wire, bus-powered devices on a single pair of wires, and intrinsic safety options. It also enables the following capabilities:

- Increased capabilities due to full digital communication.
- Reduced wiring and wire terminations due to multiple devices on one pair of wires.
- Increased supplier selection due to interoperability
- Reduced loading on control room equipment due to the distribution of some control and input/output functions to field devices.

FOUNDATION fieldbus devices work together to provide I/O and control for automated processes and operations. The Fieldbus Foundation provides a framework for describing these systems as a collection of physical devices interconnected by a fieldbus network. One of the ways that the physical devices are used is to perform their portion of the total system operation by implementing one or more function blocks.

C.2 Function blocks


Function blocks perform process control functions, such as analog input (AI) and analog output (AO) functions as well as proportional-integral-derivative (PID) functions. The standard function blocks provide a common structure for defining function block inputs, outputs, control parameters, events, alarms, and modes, and combining them into a process that can be implemented within a single device or over the fieldbus network. This simplifies the identification of characteristics that are common to function blocks.

The Fieldbus Foundation has established the function blocks by defining a small set of parameters used in all function blocks called universal parameters. The FOUNDATION has also defined a standard set of function block classes, such as input, output, control, and calculation blocks. Each of these classes has a small set of parameters established for it. They have also published definitions for transducer blocks commonly used with standard function blocks. Examples include temperature, pressure, level, and flow transducer blocks.

The Fieldbus Foundation specifications and definitions allow vendors to add their own parameters by importing and subclassing specified classes. This approach permits extending function block definitions as new requirements are discovered and as technology advances.

Figure C-1 illustrates the internal structure of a function block. When execution begins, input parameter values from other blocks are snapped-in by the block. The input snap process ensures that these values do not change during the block execution. New values received for these parameters do not affect the snapped values and will not be used by the function block during the current execution.

Figure C-1. Function Block Internal Structure



Once the inputs are snapped, the algorithm operates on them, generating outputs as it progresses. Algorithm executions are controlled through the setting of contained parameters. Contained parameters are internal to function blocks and do not appear as normal input and output parameters. However, they may be accessed and modified remotely, as specified by the function block.

Input events may affect the operation of the algorithm. An execution control function regulates the receipt of input events and the generation of output events during execution of the algorithm. Upon completion of the algorithm, the data internal to the block is saved for use in the next execution, and the output data is snapped, releasing it for use by other function blocks.

A block is a tagged logical processing unit. The tag is the name of the block. System management services locate a block by its tag. Thus the service personnel need only know the tag of the block to access or change the appropriate block parameters.

Function blocks are also capable of performing short-term data collection and storage for reviewing their behavior.

C.3 Device descriptions

Device descriptions (DD) are specified tool definitions that are associated with the Resource and Transducer Blocks. Device descriptions provide the definition and description of the function blocks and their parameters.

To promote consistency of definition and understanding, descriptive information, such as data type and length, is maintained in the device description. Device Descriptions are written using an open language called the Device Description Language (DDL). Parameter transfers between function blocks can be easily verified because all parameters are described using the same language. Once written, the device description can be stored on an external medium, such as a CD-ROM or diskette. Users can then read the device description from the external medium. The use of an open language in the device description permits interoperability of function blocks

within devices from various vendors. Additionally, human interface devices, such as operator consoles and computers, do not have to be programmed specifically for each type of device on the bus. Instead their displays and interactions with devices are driven from the device descriptions.

Device descriptions may also include a set of processing routines called methods. Methods provide a procedure for accessing and manipulating parameters within a device.

C.4 Block operation

In addition to function blocks, fieldbus devices contain two other block types to support the function blocks. These are the resource block and the transducer block.

C.4.1 Instrument- specific function blocks

Resource blocks

Resource blocks contain the hardware-specific characteristics associated with a device; they have no input or output parameters. The algorithm within a resource block monitors and controls the general operation of the physical device hardware. The execution of this algorithm is dependent on the characteristics of the physical device, as defined by the manufacturer. As a result, the algorithm may cause the generation of events. There is only one resource block defined for a device. For example, when the mode of a resource block is “Out of Service (OOS),” it impacts all of the other blocks.

Transducer blocks

Transducer blocks connect function blocks to local input/output functions. They read sensor hardware and write to effector (actuator) hardware. This permits the transducer block to execute as frequently as necessary to obtain good data from sensors and ensure proper writes to the actuator without burdening the function blocks that use the data. The transducer block also isolates the function block from the vendor-specific characteristics of the physical I/O.

C.4.2 Alerts


When an alert occurs, execution control sends an event notification and waits a specified period of time for an acknowledgment to be received. This occurs even if the condition that caused the alert no longer exists. If the acknowledgment is not received within the pre-specified time-out period, the event notification is retransmitted, assuring that alert messages are not lost.

Two types of alerts are defined for the block: events and alarms. Events are used to report a status change when a block leaves a particular state, such as when a parameter crosses a threshold. Alarms not only report a status change when a block leaves a particular state, but also report when it returns back to that state.

C.5 Network communication

Figure C-2 illustrates a simple fieldbus network consisting of a single segment (link).

Figure C-2. Simple, Single-Link Fieldbus Network



- A. Link Active Scheduler (LAS)
- B. Fieldbus Link
- C. Link Master
- D. Basic Device and/or Link Master Devices

C.5.1 LAS

All links have one LAS that operates as the bus arbiter for the link. The LAS does the following:

- recognizes and adds new devices to the link
- removes non-responsive devices from the link
- distributes Data Link Time (DL) and Link Scheduling Time (LS) on the link
 - DL is a network-wide time periodically distributed by the LAS to synchronize all device clocks on the bus.
 - LS time is a link-specific time represented as an offset from DL. It is used to indicate when the LAS on each link begins and repeats its schedule. It is used by system management to synchronize function block execution with the data transfers scheduled by the LAS
- polls devices for process loop data at scheduled transmission times
- distributes a priority-driven token to devices between scheduled transmissions

Any device on the link may become the LAS. The devices that are capable of becoming the LAS are called Link Master devices (LM). All other devices are referred to as basic devices. When a segment first starts up, or upon failure of the existing LAS, the link master devices on the segment bid to become the LAS. The link master that wins the bid begins operating as the LAS immediately upon completion of the bidding process. Link masters that do not become the LAS act as basic devices. However, the link masters can act as LAS backups by monitoring the link for failure of the LAS and then bidding to become the LAS when a LAS failure is detected.

Only one device can communicate at a time. Permission to communicate on the bus is controlled by a centralized token passed between devices by the LAS. Only the device with the token can communicate. The LAS maintains a list of all devices that need access to the bus. This list is called the “Live List.”

Two types of tokens are used by the LAS. A time-critical token, Compel Data (CD), is sent by the LAS according to a schedule. A non-time critical token, pass token (PT), is sent by the LAS to each device in ascending numerical order according to address.


There may be many LM devices on a segment but only the LAS is actively controlling communication traffic. The remaining LM devices on the segment are in a stand-by state, ready to take over if the primary LAS fails. This is achieved by constantly monitoring the communication traffic on the bus and determining if activity is not present. Since there can be multiple LM devices on the segment when the primary LAS fails, the device with the lowest node address will become the primary LAS and take control of the bus. Using this strategy, multiple LAS failures can be handled with no loss of the LAS capability of the communications bus.

LAS parameters

There are many bus communication parameters but only a few are used. For standard RS-232 communications, the configuration parameters are baud rate, start / stop bits, and parity. The key parameters for H1 FOUNDATION fieldbus are as follows.

- **Slot Time (ST)** – Used during the bus master election process. It is the maximum amount of time permitted for device A to send a message to device B. Slot time is a parameter which defines a worst case delay which includes internal delay in the sending device and the receiving device. Increasing the value of ST slows down bus traffic because a LAS device must wait longer prior to determining that the LM is down.
- **Minimum Inter-PDU Delay (MID)** – The minimum gap between two messages on the fieldbus segment or it is the amount of time between the last byte of one message and the first byte of the next message. The units of the MID are octets. An octet is 256 μ s, hence the units for MID are approximately $1/4$ ms. This would mean an MID of 16 would specify approximately a minimum of 4 ms between messages on the fieldbus. Increasing the value of MID slows down bus traffic because a larger “gap” between messages occurs.
- **Maximum Response (MRD)** – Defines the maximum amount of time permitted to respond to an immediate response request, e.g. CD, PT. When a published value is requested using the CD command, the MRD defines how long before the device publishes the data. Increasing this parameter will slow down the bus traffic by decreasing how fast CDs can be put onto the network. The MRD is measured in units of ST.
- **Time Synchronization Class (TSC)** – A variable that defines how long the device can estimate its time before drifting out of specific limits. The LM will periodically send out time update messages to synchronize devices on the segment. Decreasing the parameter number increases the number of times that time distribution messages must be published, increasing bus traffic and overhead for the LM device. See [Figure C-3](#).

Figure C-3. LAS Parameter Diagram



Backup LAS

An LM device is one that has the ability to control the communications on the bus. The LAS is the LM capable device that is currently in control of the bus. While there can be many LM devices acting as backups, there can only be one LAS. The LAS is typically a host system but for stand-alone applications, a device may be providing the role of primary LAS.

C.5.2 Addressing

To setup, configure, and communicate with other devices on a segment, a device must be assigned a permanent address. Unless requested otherwise, it is assigned a temporary address when shipped from the factory.

FOUNDATION fieldbus uses addresses between 0 and 255. Addresses 0 through 15 are reserved for group addressing and for use by the data link layer.

If there are two or more devices on a segment with the same address, the first device to start up will use the assigned address. Each of the other devices will be given one of the four temporary addresses. If a temporary address is not available, the device will be unavailable until a temporary address is available.

Use the host system documentation to commission a device and assign a permanent address.

C.5.3 Scheduled transfers

Information is transferred between devices over the FOUNDATION fieldbus using three different types of reporting.

Publisher/subscriber

This type of reporting is used to transfer critical process loop data, such as the process variable. The data producers (publishers) post the data in a buffer that is transmitted to the subscriber, when the publisher receives the Compel Data (CD). The buffer contains only one copy of the data. New data completely overwrites previous data. Updates to published data are transferred simultaneously to all subscribers in a single broadcast. Transfers of this type can be scheduled on a precisely periodic basis.

Report distribution


This type of reporting is used to broadcast and multi-cast event and trend reports. The destination address may be predefined so that all reports are sent to the same address, or it may be provided separately with each report. Transfers of this type are queued. They are delivered to the receivers in the order transmitted, although there may be gaps due to corrupted transfers. These transfers are unscheduled and occur between scheduled transfers at a given priority.

Client/server

This type of reporting is used for request/response exchanges between pairs of devices. Like Report Distribution reporting, the transfers are queued, unscheduled, and prioritized. Queued means the messages are sent and received in the order submitted for transmission, according to their priority, without overwriting previous messages. However, unlike Report Distribution, these transfers are flow controlled and employ a retransmission procedure to recover from corrupted transfers.

Figure C-4 diagrams the method of scheduled data transfer. Scheduled data transfers are typically used for the regular cyclic transfer of process loop data between devices on the fieldbus. Scheduled transfers use publisher/ subscriber type of reporting for data transfer. The LAS maintains a list of transmit times for all publishers in all devices that need to be cyclically transmitted. When it is time for a device to publish data, the LAS issues a CD message to the device. Upon receipt of the CD, the device broadcasts or “publishes” the data to all devices on the fieldbus. Any device that is configured to receive the data is called a “subscriber.”

Figure C-4. Scheduled Data Transfer




LAS = Link Active Scheduler
P = Publisher
S = Subscriber
CD = Compel Data
DT = Data Transfer Packet

C.5.4 Unscheduled transfers

Figure C-5 diagrams an unscheduled transfer. Unscheduled transfers are used for things like user-initiated changes, including set point changes, mode changes, tuning changes, and upload/download. Unscheduled transfers use either report distribution or client/server type of reporting for transferring data.

All of the devices on the FOUNDATION fieldbus are given a chance to send unscheduled messages between transmissions of scheduled data. The LAS grants permission to a device to use the fieldbus by issuing a pass token (PT) message to the device. When the device receives the PT, it is allowed to send messages until it has finished or until the “maximum token hold time” has expired, whichever is the shorter time. The message may be sent to a single destination or to multiple destinations.

Figure C-5. Unscheduled Data Transfer




P = Publisher S = Subscriber PT = Pass Token M = Message

C.5.5 Function block scheduling

Figure C-6 shows an example of a link schedule. A single iteration of the link-wide schedule is called the macrocycle. When the system is configured and the function blocks are linked, a master link-wide schedule is created for the LAS. Each device maintains its portion of the link-wide schedule, known as the Function Block Schedule. The Function Block Schedule indicates when the function blocks for the device are to be executed. The scheduled execution time for each function block is represented as an offset from the beginning of the macrocycle start time.

Figure C-6. Example Link Schedule Showing Scheduled and Unscheduled Communication




To support synchronization of schedules, periodically Link Scheduling (LS) time is distributed. The beginning of the macrocycle represents a common starting time for all Function Block schedules on a link and for the LAS link-wide schedule. This permits function block executions and their corresponding data transfers to be synchronized in time.

Appendix D Function Blocks

Analog Input (AI) function block	page 97
Multiple analog input (MAI) function block	page 106
Input selector function block	page 113

D.1 Analog Input (AI) function block



Out = The block output value and status
Out_D = Discrete output that signals a selected alarm condition

The Analog Input (AI) function block processes field device measurements and makes them available to other function blocks. The output value from the AI block is in engineering units and contains a status indicating the quality of the measurement. The measuring device may have several measurements or derived values available in different channels. Use the channel number to define the variable that the AI block processes.

The AI block supports alarming, signal scaling, signal filtering, signal status calculation, mode control, and simulation. In Automatic mode, the block's output parameter (OUT) reflects the process variable (PV) value and status. In Manual mode, OUT may be set manually. The Manual mode is reflected on the output status. A discrete output (OUT_D) is provided to indicate whether a selected alarm condition is active. Alarm detection is based on the OUT value and user specified alarm limits. The block execution time is 30 ms.

Table D-1. Analog Input Function Block Parameters

Number	Parameter	Units	Description
01	ST_REV	None	The revision level of the static data associated with the function block. The revision value will be incremented each time a static parameter value in the block is changed.
02	TAG_DESC	None	The user description of the intended application of the block.
03	STRATEGY	None	The strategy field can be used to identify a grouping of blocks. This data is not checked or processed by the block.
04	ALERT_KEY	None	The identification number of the plant unit. This information may be used in the host for sorting alarms, etc.

Table D-1. Analog Input Function Block Parameters

Number	Parameter	Units	Description
05	MODE_BLK	None	The actual, target, permitted, and normal modes of the block. Actual: The mode the “block is currently in” Target: The mode to “go to” Permitted: Allowed modes that target may take on Normal: Most common mode for target
06	BLOCK_ERR	None	This parameter reflects the error status associated with the hardware or software components associated with a block. It is a bit string, so that multiple errors may be shown.
07	PV	EU of XD_SCALE	The process variable used in block execution.
08	OUT	EU of OUT_SCALE or XD_SCALE if in direct L_TYPE	The block output value and status.
09	SIMULATE	None	A group of data that contains the current transducer value and status, the simulated transducer value and status, and the enable/disable bit.
10	XD_SCALE	None	The high and low scale values, engineering units code, and number of digits to the right of the decimal point associated with the channel input value. The XD_SCALE units code must match the units code of the measurement channel in the transducer block. If the units do not match, the block will not transition to MAN or AUTO.
11	OUT_SCALE	None	The high and low scale values, engineering units code, and number of digits to the right of the decimal point associated with OUT when L_TYPE is not direct.
12	GRANT_DENY	None	Options for controlling access of host computers and local control panels to operating, tuning, and alarm parameters of the block. Not used by device.
13	IO_OPTS	None	Allows the selection of input/output options used to alter the PV. Low cutoff enabled is the only selectable option.
14	STATUS_OPTS	None	Allows the user to select options for status handling and processing. The options supported in the AI block are the following: Propagate fault forward Uncertain if limited Bad if limited Uncertain if Manual mode.
15	CHANNEL	None	The CHANNEL value is used to select the measurement value. Configure the CHANNEL parameter before configuring the XD_SCALE parameter. Refer to Table 3-5 on page 11 .
16	L_TYPE	None	Linearization type. Determines whether the field value is used directly (Direct), is converted linearly (Indirect), or is converted with the square root (Indirect Square Root).
17	LOW_CUT	%	If percentage value of transducer input fails below this, PV = 0.

Table D-1. Analog Input Function Block Parameters

Number	Parameter	Units	Description
18	PV_FTIME	Seconds	The time constant of the first-order PV filter. It is the time required for a 63% change in the PV or OUT value.
19	FIELD_VAL	Percent	The value and status from the transducer block or from the simulated input when simulation is enabled.
20	UPDATE_EVT	None	This alert is generated by any change to the static data.
21	BLOCK_ALM	None	The block alarm is used for all configuration, hardware, connection failure or system problems in the block. The cause of the alert is entered in the subcode field. The first alert to become active will set the Active status in the Status parameter. As soon as the Unreported status is cleared by the alert reporting task, another block alert may be reported without clearing the Active status, if the subcode has changed.
22	ALARM_SUM	None	The summary alarm is used for all process alarms in the block. The cause of the alert is entered in the subcode field. The first alert to become active will set the Active status in the Status parameter. As soon as the Unreported status is cleared by the alert reporting task, another block alert may be reported without clearing the Active status, if the subcode has changed.
23	ACK_OPTION	None	Used to set auto acknowledgment of alarms.
24	ALARM_HYS	Percent	The amount the alarm value must return within the alarm limit before the associated active alarm condition clears.
25	HI_HI_PRI	None	The priority of the HI HI alarm.
26	HI_HI_LIM	EU of PV_SCALE	The setting for the alarm limit used to detect the HI HI alarm condition.
27	HI_PRI	None	The priority of the HI alarm.
28	HI_LIM	EU of PV_SCALE	The setting for the alarm limit used to detect the HI alarm condition.
29	LO_PRI	None	The priority of the LO alarm.
30	LO_LIM	EU of PV_SCALE	The setting for the alarm limit used to detect the LO alarm condition.
31	LO_LO_PRI	None	The priority of the LO LO alarm.
32	LO_LO_LIM	EU of PV_SCALE	The setting for the alarm limit used to detect the LO LO alarm condition.
33	HI_HI_ALM	None	The HI HI alarm data, which includes a value of the alarm, a timestamp of occurrence and the state of the alarm.
34	HI_ALM	None	The HI alarm data, which includes a value of the alarm, a timestamp of occurrence and the state of the alarm.
35	LO_ALM	None	The LO alarm data, which includes a value of the alarm, a timestamp of occurrence and the state of the alarm.
36	LO_LO_ALM	None	The LO LO alarm data, which includes a value of the alarm, a timestamp of occurrence and the state of the alarm.

Table D-1. Analog Input Function Block Parameters

Number	Parameter	Units	Description
37	OUT_D	None	Discrete output to indicate a selected alarm condition.
38	ALM_SEL	None	Used to select the process alarm conditions that will cause the OUT_D parameter to be set.
39	STDDEV	% of OUT Range	Standard deviation of the measurement for 100 macrocycles.
40	CAP_STDDEV	% of OUT Range	Capability standard deviation, the best deviation that can be achieved.

D.1.1 Functionality

Simulation

To support testing, either change the mode of the block to manual and adjust the output value, or enable simulation through the configuration tool and manually enter a value for the measurement value and its status. In simulation, the ENABLE jumper must be set on the field device.

Note

All FOUNDATION™ fieldbus instruments have a simulation jumper. As a safety measure, the jumper has to be reset every time there is a power interruption. This measure is to prevent devices that went through simulation in the staging process from being installed with simulation enabled.

With simulation enabled, the actual measurement value has no impact on the OUT value or the status.

Figure D-1. Analog Input Function Block Timing Diagram





Figure D-2. Analog Input Function Block Schematic



OUT = Block output value and status
OUT_D = Discrete output that signals a selected alarm condition

Filtering

The filtering feature changes the response time of the device to smooth variations in output readings caused by rapid changes in input. Adjust the filter time constant (in seconds) using the PV_FTIME parameter. Set the filter time constant to zero to disable the filter feature.

Signal conversion

Set the signal conversion type with the Linearization Type (L_TYPE) parameter. View the converted signal (in percent of XD_SCALE) through the FIELD_VAL parameter.

$$\text{FIELD_VAL} = \frac{100 \times (\text{Channel Value} - \text{EU}^* @ 0\%)}{(\text{EU}^* @ 100\% - \text{EU}^* @ 0\%)} \quad * \text{XD_SCALE values}$$

Choose from direct, indirect, or indirect square root signal conversion with the L_TYPE parameter.

Direct

Direct signal conversion allows the signal to pass through the accessed channel input value (or the simulated value when simulation is enabled).

PV = Channel Value

Indirect

Indirect signal conversion converts the signal linearly to the accessed channel input value (or the simulated value when simulation is enabled) from its specified range (XD_SCALE) to the range and units of the PV and OUT parameters (OUT_SCALE).

$$\text{PV} = \left(\frac{\text{FIELD_VAL}}{100} \right) \times (\text{EU}^{**} @ 100\% - \text{EU}^{**} @ 0\%) + \text{EU}^{**} @ 0\% \quad ** \text{OUT_SCALE values}$$

Indirect square root

Indirect Square Root signal conversion takes the square root of the value computed with the indirect signal conversion and scales it to the range and units of the PV and OUT parameters.

$$PV = \sqrt{\left(\frac{FIELD_VAL}{100}\right)} \times (EU^{**}@100\% - EU^{**}@0\%) + EU^{**}@0\%$$

** OUT_SCALE values

When the converted input value is below the limit specified by the LOW_CUT parameter, and the Low Cutoff I/O option (IO_OPTS) is enabled (True), a value of zero is used for the converted value (PV). This option eliminates false readings when the differential pressure measurement is close to zero and it may be useful with zero-based measurement devices such as flowmeters.

Note

Low Cutoff is the only I/O option supported by the AI block. Set the I/O option when the block is OOS.

Block errors

Table lists conditions reported in the BLOCK_ERR parameter. Conditions in bold are inactive for the AI block and are given here for reference.

Table D-2. BLOCK_ERR Conditions

Number	Name and description
0	Other
1	Block Configuration Error: the selected channel carries a measurement that is incompatible with the engineering units selected in XD_SCALE, the L_TYPE parameter is not configured, or CHANNEL = zero.
2	Link Configuration Error
3	Simulate Active: Simulation is enabled and the block is using a simulated value in its execution.
4	Local Override
5	Device Fault State Set
6	Device Needs Maintenance Soon
7	Input Failure/Process Variable has Bad Status: The hardware is bad, or a bad status is being simulated.
8	Output Failure: The output is bad based primarily upon a bad input.
9	Memory Failure
10	Lost Static Data
11	Lost NV Data
12	Readback Check Failed
13	Device Needs Maintenance Now
14	Power Up
15	Out of Service: The actual mode is out of service.

Modes

The AI Function Block supports three modes of operation as defined by the MODE_BLK parameter.

Manual (Man)

The value of the block output (OUT) may be set manually

Automatic (Auto)

OUT reflects the analog input measurement or the simulated value when simulation is enabled.

Out of service (OOS)

The block is not processed. FIELD_VAL and PV are not updated and the OUT status is set to Bad: Out of Service. The BLOCK_ERR parameter shows Out of Service. In this mode, changes can be made to all configurable parameters.

Alarm detection

A block alarm will be generated whenever the BLOCK_ERR has an error bit set. The types of block error for the AI block are defined above.

Process alarm detection is based on the OUT value. Configure the alarm limits of the following standard alarms:

- High (HI_LIM)
- High high (HI_HI_LIM)
- Low (LO_LIM)
- Low low (LO_LO_LIM)

To avoid alarm chatter when the variable is oscillating around the alarm limit, an alarm hysteresis in percent of the PV span can be set using the ALARM_HYS parameter. The priority of each alarm is set in the following parameters:

- HI_PRI
- HI_HI_PRI
- LO_PRI
- LO_LO_PRI

Table D-3. Alarm Priority Levels

Number	Description
0	The priority of an alarm condition changes to 0 after the condition that caused the alarm is corrected.
1	An alarm condition with a priority of 1 is recognized by the system, but is not reported to the operator.
2	An alarm condition with a priority of 2 is reported to the operator, but does not require operator attention (such as diagnostics and system alerts).
3-7	Alarm conditions of priority 3 to 7 are advisory alarms of increasing priority.
8-15	Alarm conditions of priority 8 to 15 are critical alarms of increasing priority.

Status handling

Normally, the status of the PV reflects the status of the measurement value, the operating condition of the I/O card, and any active alarm condition. In Auto mode, OUT reflects the value and status quality of the PV. In Man mode, the OUT status constant limit is set to indicate that the value is a constant and the OUT status is *Good*.

If the sensor limit exceeds the high or low range, PV status is set high or low and EU range status is set to uncertain.

In the STATUS_OPTS parameter, select from the following options to control the status handling.

BAD if limited

Sets the OUT status quality to *Bad* when the value is higher or lower than the sensor limits.

Uncertain if limited

Sets the OUT status quality to *Uncertain* when the value is higher or lower than the sensor limits.

Uncertain if in manual mode

The status of the Output is set to *Uncertain* when the mode is set to Manual.

Notes

1. The instrument must be in OOS mode to set the status option.
 2. The AI block only supports the BAD if Limited option, uncertain if limited, and uncertain if manual.
-

Advanced features

The AI function block provided with Rosemount® fieldbus devices provides added capability through the addition of the following parameters:

ALARM_TYPE

Allows one or more of the process alarm conditions detected by the AI function block to be used in setting its OUT_D parameter.

OUT_D

Discrete output of the AI function block based on the detection of process alarm condition(s). This parameter may be linked to other function blocks that require a discrete input based on the detected alarm condition.

STD_DEV and CAP_STDDEV

Diagnostic parameters that can be used to determine the variability of the process.

Application information

The configuration of the AI function block and its associated output channels depends on the specific application. A typical configuration for the AI block involves the following parameters:

CHANNEL

The device supports more than one measurement, so verify that the selected channel contains the appropriate measurement or derived value. Refer to [Table 3-8 on page 36](#) for a listing of available channels on the 848T.

L_TYPE

Select Direct when the measurement is in the desired engineering units for the block output. Select Indirect when converting the measured variable into another, for example, pressure into level or flow into energy.


SCALING

XD_SCALE provides the range and units of the measurement and OUT_SCALE provides the range and engineering units of the output. OUT_SCALE is only used when in indirect or indirect square root.

D.1.2 AI block troubleshooting

Symptom	Possible causes	Corrective action
Mode will not leave OOS	Target mode not set	Set target mode to something other than OOS.
	Configuration error	BLOCK_ERR will show the configuration error bit set. The following are parameters that must be set before the block is allowed out of OOS: <ul style="list-style-type: none"> CHANNEL must be set to a valid value and cannot be left at initial value of 0. XD_SCALE.UNITS_INDEX must match the units in the transducer block channel value. Setting the units in the AI block automatically sets them in the XD_BLOCK. L_TYPE must be set to Direct, Indirect, or Indirect Square Root and cannot be left at initial value of 0.
	Resource block	The actual mode of the Resource block is OOS. See Resource Block Diagnostics for corrective action.
	Schedule	Block is not scheduled and therefore cannot execute to go to Target Mode. Typically, BLOCK_ERR will show "Power-Up" for all blocks that are not scheduled. Schedule the block to execute.
Process and/or block alarms will not work.	Features	FEATURES_SEL does not have Alerts enabled. Enable the Alerts bit.
	Notification	LIM_NOTIFY is not high enough. Set equal to MAX_NOTIFY. Alarm not linked to host.
	Status Options	STATUS_OPTS has Propagate Fault Forward bit set. This should be cleared to cause an alarm to occur.
Value of output does not make sense	Linearization Type	L_TYPE must be set to Direct, Indirect, or Indirect Square Root and cannot be left at initial value of 0.
	Scaling	Scaling parameters are set incorrectly: <ul style="list-style-type: none"> XD_SCALE.EU0 and EU100 should match that of the transducer block channel value. OUT_SCALE.EU0 and EU100 are not set properly. Both STB on each ASIC used must be in auto.
Cannot set HI_LIMIT, HI_HI_LIMIT, LO_LIMIT, or LO_LO_LIMIT Values	Scaling	Limit values are outside the OUT_SCALE.EU0 and OUT_SCALE.EU100 values. Change OUT_SCALE or set values within range.

D.2 Multiple analog input (MAI) function block



Out1 = The block output value and status for the first channel.

The MAI function block has the ability to process up to eight field device measurements and make them available to other function blocks. The output values from the MAI block are in engineering units and contain a status indicating the quality of the measurement. The measuring device may have several measurements or derived values available in different channels. Use the channel numbers to define the variables that the MAI block processes.

The MAI block supports signal scaling, signal filtering, signal status calculation, mode control, and simulation. In Automatic mode, the block's output parameters (OUT_1 to OUT_8) reflects the process variable (PV) values and status. In Manual mode, OUT may be set manually. The Manual mode is reflected on the output status. [Table D-4](#) lists the MAI block parameters and their units of measure, descriptions, and index numbers. The block execution time is 30 ms.

Table D-4. Multiple Analog Input Function Block Parameters

Number	Parameter	Units	Description
1	ST_REV	None	The revision level of the static data associated with the input selector block. The revision value will be incremented each time a static parameter value in the block is changed.
2	TAG_DESC	None	The user description of the intended application of the block.
3	STRATEGY	None	The strategy field can be used to identify grouping of blocks. This data is not checked or processed by the block.
4	ALERT_KEY	None	The identification number of the plant unit. This information may be used in the host for sorting alarms, etc.
5	MODE_BLK	None	The actual, target, permitted, and normal modes of the block. Actual: The mode the "block is currently in" Target: The mode to "go to" Permitted: Allowed modes that target may take on Normal: Most common mode for target
6	BLOCK_ERR	None	This parameter reflects the error status associated with the hardware or software components associated with a block. It is a bit string, so that multiple errors may be shown.

Table D-4. Multiple Analog Input Function Block Parameters

Number	Parameter	Units	Description
7	CHANNEL	None	Allows for custom channel setting. Valid values include: 0: Uninitialized 1: Channels 1 to 8 (index values 27 to 34 can only be set to their corresponding channel number, i.e. CHANNEL_X=X) 2: Custom settings (index values 27 to 34 can be configured for any valid channel as defined by the DD)
8, 9, 10, 11, 12, 13, 14, 15	OUT (1, 2, 3, 4, 5, 6, 7, 8)	EU of OUT_SCALE	The block output value and status
16	UPDATE_EVT	None	This alert is generated by any change to the static data
17	BLOCK_ALM	None	The block alarm is used for all configuration, hardware connection feature, or system problems in the block. The cause of the alert is entered in the subcode field. The first alert to become active will set the Active status in the Status parameter. As soon as the Unreported status is cleared by the alert reporting task, another block may be reported without clearing the Active status, if the subcode has changed.
18	SIMULATE	None	A group of data that contains the current sensor transducer value and status, and the enable/disable bit.
19	XD_SCALE	None	The high and low scale values, engineering units code and number of digits to the right of the decimal point associated with the channel input value. The XD_SCALE units code must match the units code of the measurement channel in the transducer block. If the units do not match, the block will not transition to MAN or AUTO. It will automatically change units in the STB block to the last one written. Multiple blocks reading the same channel may conflict (only one unit type per channel).
20	OUT_SCALE	None	The high and low scale values, engineering unit code and number of digits to the right of the decimal point associated with OUT.
21	GRANT_DENY	None	Options for controlling access of host computers and local control panels for operating, tuning, and alarm parameters of the block. Not used by device.
22	IO_OPTS	None	Allows the selection of input/output options used to alter the PV. Low cutoff enabled is the only selectable option.
23	STATUS_OPTS	None	Allows the user to select options for status handling and processing. The options supported in the MAI block are the following: <ul style="list-style-type: none"> • Propagate fault forward • Uncertain if limited • Bad if limited • Uncertain if manual mode
24	L_TYPE	None	Linearization type. Determines whether the field value is uses directly (Direct), is converted linearly (Indirect), or is converted with the square root (Indirect Square Root)
25	LOW_CUT	%	If percentage value of the sensor transducer input falls below this, PV = 0
26	PV_FTIME	Seconds	The time constant of the first-order PV filter. It is the time required for a 63% change in the IN value.

Table D-4. Multiple Analog Input Function Block Parameters

Number	Parameter	Units	Description
27, 28, 29, 30, 31, 32, 33, 34	CHANNEL_(1, 2, 3, 4, 5, 6, 7, 8)	None	The CHANNEL (1, 2, 3, 4, 5, 6, 7, 8) value is used to select the measurement value. See Table D-4 on page 106 for available channels. Configure the CHANNEL parameters to custom (2) before configuring the CHANNEL parameters.
35, 36, 37, 38, 39, 40, 41, 42	STDDEV_(1, 2, 3, 4, 5, 6, 7, 8)	% of OUT Range	Standard deviation of the corresponding measurement.
43, 44, 45, 46, 47, 48, 49, 50	CAP_STDDEV_(1, 2, 3, 4, 5, 6, 7, 8)	% of OUT Range	Capability standard deviation, the best deviation that can be achieved.

D.2.1 Functionality

Simulation

To support testing, either change the mode of the block to manual and adjust the output value or enable simulation through the configuration tool and manually enter a value for the measurement value and its status (this single value will apply to all outputs). In both cases, first set the ENABLE jumper on the field device.

Note

All FOUNDATION fieldbus instruments have a simulation jumper. As a safety measure, the jumper has to be reset every time there is a power interruption. This measure is to prevent devices that went through simulation in the staging process from being installed with simulation enabled.

With simulation enabled, the actual measurement value has no impact on the OUT value or the status. The OUT values will all have the same value as determined by the simulate value.

Figure D-3. Multiple Analog Input Function Block Timing Diagram





Figure D-4. Multiple Analog Input Function Block Schematic



Filtering

The filtering feature changes the response time of the device to smooth variations in output readings caused by rapid changes in input. Adjust the filter time constant (in seconds) using the PV_FTIME parameter (same value applied to eight channels). Set the filter time constant to zero to disable the filter feature.

Signal conversion

Set the signal conversion type with the Linearization Type (L_TYPE) parameter. Choose from direct, indirect, or indirect square root signal conversion with the L_TYPE parameter.

Direct

Direct signal conversion allows the signal to pass through the accessed channel input value (or the simulated value when simulation is enabled).

$$PV = \text{Channel Value}$$

Indirect

Indirect signal conversion converts the signal linearly to the accessed channel input value (or the simulated value when simulation is enabled) from its specified range (XD_SCALE) to the range and units of the PV and OUT parameters (OUT_SCALE).

$$PV = \left(\frac{\text{Channel Value}}{100} \right) \% (EU^{**}@100\% - EU^{**}@0\%) + EU^{**}@0\%$$

** OUT_SCALE values

Indirect square root

Indirect Square Root signal conversion takes the square root of the value computed with the indirect signal conversion and scales it to the range and units of the PV and OUT parameters.

$$PV = \sqrt{\left(\frac{\text{Channel Value}}{100} \right) \% (EU^{**}@100\% - EU^{**}@0\%) + EU^{**}@0\%}$$

** OUT_SCALE values

When the converted input value is below the limit specified by the LOW_CUT parameter, and the Low Cutoff I/O option (IO_OPTS) is enabled (True), a value of zero is used for the converted value (PV). This option is useful to eliminate false readings when the differential temperature measurement is close to zero, and it may also be useful with zero-based measurement devices such as flowmeters.

Note

Low Cutoff is the only I/O option supported by the MAI block. Set the I/O option in Manual or Out of Service mode only.

Block errors

Table lists conditions reported in the BLOCK_ERR parameter. Conditions in bold are inactive for the MAI block and are given for reference.

Table D-5. BLOCK_ERR Conditions

Number	Name and description
0	Other
1	Block Configuration Error: the selected channel carries a measurement that is incompatible with the engineering units selected in XD_SCALE, the L_TYPE parameter is not configured, or WRITE_CHECK = zero.
2	Link Configuration Error
3	Simulate Active: Simulation is enabled and the block is using a simulated value in its execution.
4	Local Override
5	Device Fault State Set
6	Device Needs Maintenance Soon
7	Input Failure/Process Variable has Bad Status: The hardware is bad, or a bad status is being simulated.
8	Output Failure: The output is bad based primarily upon a bad input.
9	Memory Failure
10	Lost Static Data
11	Lost NV Data
12	Readback Check Failed
13	Device Needs Maintenance Now
14	Power Up
15	Out of Service: The actual mode is out of service.

Modes

The MAI Function Block supports three modes of operation as defined by the MODE_BLK parameter.

Manual (Man)

The block output (OUT) may be set manually.

Automatic (Auto)

OUT_1 to OUT_8 reflects the analog input measurement or the simulated value when simulation is enabled.

Out of Service (OOS)

The block is not processed. PV is not updated and the OUT status is set to Bad: Out of Service. The BLOCK_ERR parameter shows Out of Service. In this mode, changes can be made to all configurable parameters. The target mode of a block may be restricted to one or more of the supported modes.

Status handling

Normally, the status of the PV reflects the status of the measurement value, the operating condition of the I/O card, and any active alarm condition. In Auto mode, OUT reflects the value and status quality of the PV. In Man mode, the OUT status constant limit is set to indicate that the value is a constant and the OUT status is *Good*.

If the sensor limit exceeds the high or low side range, PV status is set high or low and EU range status is set to uncertain.

In the STATUS_OPTS parameter, select from the following options to control the status handling.

BAD if limited

Sets the OUT status quality to *Bad* when the value is higher or lower than the sensor limits.

Uncertain if limited

Sets the OUT status quality to *Uncertain* when the value is higher or lower than the sensor limits.

Uncertain if in manual mode

The status of the Output is set to *Uncertain* when the mode is set to Manual.

Notes

1. The instrument must be OOS to set the status option.
 2. The MAI block only supports the BAD if Limited option.
-

Application information

The intended use for this type of function block is for applications where the sensor types and functionality of each channel (i.e. the simulate, scaling, filtering, alarms type, and options) are the same.

The configuration of the MAI function block and its associated output channels depends on the specific application. A typical configuration for the MAI block involves the following parameters:

CHANNEL

If the device supports more than one measurement, verify that the selected channel contains the appropriate measurement or derived value. Refer to [Table D-4 on page 106](#) for a listing of available channels on the 848T.

L_TYPE

Select Direct when the measurement is already in the desired engineering units for the block output. Select Indirect when converting the measured variable into another, for example, pressure into level or flow into energy. Select Indirect Square Root when the block I/O parameter value represents a flow measurement made using differential pressure, and when square root extraction is not performed by the transducer.


SCALING

XD_SCALE provides the range and units of the measurement and OUT_SCALE provides the range and engineering units of the output.

D.2.2 MAI block troubleshooting

Symptom	Possible causes	Corrective action
Mode will not leave OOS	Target mode not set	Set target mode to something other than OOS.
	Configuration error	BLOCK_ERR will show the configuration error bit set. The following are parameters that must be set before the block is allowed out of OOS: <ul style="list-style-type: none"> Initial value is 1. XD_SCALE.UNITS_INDEX must match the units in all the corresponding sensor transducer blocks. L_TYPE must be set to Direct, Indirect, or Indirect Square Root and cannot be left at initial value of 0.
	Resource block	The actual mode of the Resource block is OOS. See Resource Block Diagnostics for corrective action.
	Schedule	Block is not scheduled and therefore cannot execute to go to Target Mode. Typically, BLOCK_ERR will show "Power-Up" for all blocks that are not scheduled. Schedule the block to execute.
Process and/or block alarms will not work.	Features	FEATURES_SEL does not have Alerts enabled. Enable the Alerts bit.
	Notification	LIM_NOTIFY is not high enough. Set equal to MAX_NOTIFY.
	Status Options	STATUS_OPTS has Propagate Fault Forward bit set. This should be cleared to cause an alarm to occur.
Value of output does not make sense	Linearization Type	L_TYPE must be set to Direct, Indirect, or Indirect Square Root and cannot be left at initial value of 0.
	Scaling	Scaling parameters are set incorrectly: <ul style="list-style-type: none"> XD_SCALE.EU0 and EU100 should match that of the corresponding sensor transducer block. OUT_SCALE.EU0 and EU100 are not set properly. Both STBs in an ASIC must be set to auto. Best in 1, 2, 7, 8, ASICs in Auto for thermocouples

D.3 Input selector function block



The Input Selector (ISEL) function block can be used to select the first good, Hot Backup™, maximum, minimum, or average of as many as eight input values and place it at the output. The block supports signal status propagation. There is process alarm detection in the Input Selector function block. Table D-6 lists the ISEL block parameters and their descriptions, units of measure, and index numbers. The block execution time is 30 ms.

Table D-6. Input Selector Function Block Parameters

Number	Parameter	Units	Description
1	ST_REV	None	The revision level of the static data associated with the input selector block. The revision value will be incremented each time a static parameter value in the block is changed.
2	TAG_DESC	None	The user description of the intended application of the block.
3	STRATEGY	None	The strategy field can be used to identify groupings of blocks. This data is not checked or processed by the block.
4	ALERT_KEY	None	The identification number of the plant unit. This information may be used in the host for sorting alarms, etc.
5	MODE_BLK	None	The actual, target, permitted, and normal modes of the block. Actual: The mode the “block is currently in” Target: The mode to “go to” Permitted: Allowed modes that target may take on Normal: Most common mode for target

Table D-6. Input Selector Function Block Parameters


Number	Parameter	Units	Description
6	BLOCK_ERR	None	This parameter reflects the error status associated with the hardware or software components associated with a block. It is a bit string, so that multiple errors may be shown.
7	OUT	OUT_RANGE	The primary analog value calculated as a result of executing the function block.
8	OUT_RANGE	EU of OUT	The engineering units code to be used in displaying the OUT parameter and parameters which have the same scaling as OUT.
9	GRANT_DENY	None	Options for controlling access of host computers and local control panels to operating, tuning, and alarm parameters of the block. Not used by device.
10	STATUS_OPTS	None	Allows the user to select options for status handling and processing.
11, 12, 13, 14, 25, 26, 27, 28	IN_(1, 2, 3, 4, 5, 6, 7, 8)	Determined by source	A connection input from another block
15, 16, 17, 18, 29, 30, 31, 32	DISABLE_(1, 2, 3, 4, 5, 6, 7, 8)	None	A connection from another block that disables the associated input from the selection.
19	SELECT_TYPE	None	Specifies input selection method. Methods available include: First Good, Minimum, Maximum, Middle, Average, or Hot Backup.
20	MIN_GOOD	None	The minimum number of good inputs.
21	SELECTED	None	The selected input number (1 to 8) or the number of input used for the average output.
22	OP_SELECT	None	Overrides the algorithm to select 1 of the 8 inputs regardless of the selection type.
23	UPDATE_EVT	None	This alert is generated by any change to the static data
24	BLOCK_ALM	None	The block alarm is used for all configuration, hardware, connection failure, or system problems in the block. The cause of the alert is entered in the subcode field. The first alert to become active will set the Active status in the Status parameter. As soon as the Unreported status is cleared by the alert reporting task, another block may be reported without clearing the Active status, if the subcode has changed.
33	AVG_USE	None	Number of parameters to use in the averaging calculation. For example, if AVG_USE is 4 and the number of connected inputs is 6, then the highest and lowest values would be dropped prior to calculating the average. If AVG_USE is 2 and the number of connected inputs is 7, then the two highest and lowest values would be dropped prior to calculating the average and the average would be based on the middle three inputs.
34	ALARM_SUM	None	The current alert status, unacknowledged states, and disabled states of the alarms associated with the function block.
35	ACK_OPTION	None	Used to set automatic acknowledgment of alarms.

Table D-6. Input Selector Function Block Parameters

Number	Parameter	Units	Description
36	ALARM_HYS	Percent	The amount the alarm value must return within the alarm limit before the associated active alarm condition clears
37	HI_HI-PRI	None	The priority of the HI HI alarm
38	HI_HI_LIM	Percent	The setting for the alarm limit used to detect the HI HI alarm condition.
39	HI_PRI	None	The priority of the HI alarm
40	HI_LIM	EU of IN	The setting for the alarm limit used to detect the HI alarm condition
41	LO_PRI	None	The priority of the LO alarm
42	LO_LIM	EU of IN	The setting of the alarm limit used to detect the LO alarm condition
43	LO_LO_PRI	None	The priority of the LO LO alarm
44	LO_LO_LIM	EU of IN	The setting for the alarm limit sued to detect the LO LO alarm condition
45	HI_HI_ALM	None	The HI HI alarm data, which includes a value of the alarm, a timestamp of occurrence and the state of the alarm
46	HI_ALM	None	The HI alarm data, which includes a value of the alarm, a timestamp of occurrence and the state of the alarm
47	LO_ALM	None	The LO alarm data, which includes a value of the alarm, a timestamp of occurrence and the state of the alarm
48	LO_LO_ALM	None	The LO LO alarm data, which includes a value of the alarm, a timestamp of occurrence and the state of the alarm
49	OUT_D	None	Discrete output to indicate a selected alarm value
50	ALM_SEL	None	Used to select the process alarm conditions that will cause the OUT_D parameter to be set.

D.3.1 Functionality

Figure D-5. Input Selector Function Block Schematic



Block errors

Table D-7 lists conditions reported in the BLOCK_ERR parameter. Conditions in bold are inactive for the ISEL block and are given for reference.

Table D-7. BLOCK_ERR Conditions

Number	Name and description
0	Other: The output has a quality of uncertain.
1	Block Configuration Error: Select type is not configured
2	Link Configuration Error
3	Simulate Active
4	Local Override
5	Device Fault State Set
6	Device Needs Maintenance Soon
7	Input Failure/Process Variable has Bad Status: One of the inputs is Bad.
8	Output Failure
9	Memory Failure
10	Lost Static Data
11	Lost NV Data
12	Readback Check Failed
13	Device Needs Maintenance Now
14	Power Up: The device was just powered-up.
15	Out of Service: The actual mode is out of service.

Modes

The ISEL function block supports three modes of operation as defined by the MODE_BLK parameter:

Manual (Man)

The block output (OUT) may be set manually.

Automatic (Auto)

OUT reflects the selected value.

Out of Service (OOS)

The block is not processed. The BLOCK_ERR parameter shows Out of Service. The target mode of a block may be restricted to one or more of the supported modes. In this mode, changes can be made to all configurable parameters.

Alarm detection

A block alarm will be generated whenever the BLOCK_ERR has an error bit set. The type of block errors for the ISEL block are defined above.

Process Alarm detection is based on the OUT value. The alarm limits of the following standard alarms can be configured.

- High (HI_LIM)
- High high (HI_HI_LIM)
- Lo (LO_LIM)
- Lo low (LO_LO_LIM)

In order to avoid alarm chattering when the variable is oscillating around the alarm limit, an alarm hysteresis in percent of the PV span can be set using the ALARM_HYS parameter. The priority of each alarm is set in the following parameters:

- HI_PRI
- HI_HI_PRI
- LO_PRI
- LO_LO_PRI

Table D-8. Alarm Priority Levels

Number	Description
0	The priority of an alarm condition changes to 0 after the condition that caused the alarm is corrected.
1	An alarm condition with a priority of 1 is recognized by the system, but is not reported to the operator.
2	An alarm condition with a priority of 2 is reported to the operator, but does not require operator attention (such as diagnostics and system alerts).
3-7	Alarm conditions of priority 3 to 7 are advisory alarms of increasing priority.
8-15	Alarm conditions of priority 8 to 15 are critical alarms of increasing priority.

Block execution

The ISEL function block reads the values and status of up to eight inputs. To specify which of the six available methods (algorithms) is used to select the output, configure the selector type parameter (SELECT_TYPE) as follows:

- Max selects the maximum value of the inputs.
- Min selects the minimum value of the inputs.
- Avg calculates the average value of the inputs.
- Mid calculates the update for eight sensors.
- 1st Good selects the first available good input.

If the DISABLE_N is active, the associated input is not used in the selection algorithm.

If an input is not connected, it is also not used in the algorithm.

If the OP_SELECT is set to a value between 1 and 8, the selection type logic is overridden and the output value and status is set to the value and status of the input selected by OP_SELECT.

SELECTED will have the number of selected input unless the SELECT_TYPE is mid, in which case it will take the average of the two middle values. Then SELECTED will be set to “0” if there is an even number of inputs.

Status handling

In Auto mode, OUT reflects the value and status quality of the selected input. If the number of inputs with Good status is less than MIN_GOOD, the output status will be Bad.

In Man mode, the OUT status high and low limits are set to indicate that the value is a constant and the OUT status is always Good.

In the STATUS_OPTS parameter, select from the following options to control the status handling:

Use uncertain as good

Sets the OUT status quality to Good when the selected input status is Uncertain.

Uncertain if in manual mode

The status of the Output is set to Uncertain when the mode is set to manual.

Note


The instrument must be to OOS to set the status option.

Application information


Use the ISEL function block to:

- Select the maximum temperature input from eight inputs and send it to another function block (see <HotXRef>Figure D-6)
- Calculate the average temperature of the eight inputs (see <HotXRef>Figure D-7)
- Use only six of the eight inputs to calculate the average temperature.

Figure D-6. Input Selector Function Block Application Example (SEL_TYPE = max)



**Figure D-7. Input Selector Function Block Application Example (SEL_TYPE = average)
AVG_USE = 6**



To determine OUT for a 6-input reading, read all eight, sort in numerical order, drop the highest and lowest values, and calculate the average.

$$\frac{107 + 112 + 115 + 118 + 126 + 130}{6} = 118^{\circ}\text{F}$$

D.3.2 ISEL block troubleshooting

Symptom	Possible causes	Corrective action
Mode will not leave OOS	Target mode not set	Set target mode to something other than OOS.
	Configuration error	BLOCK_ERR will show the configuration error bit set. SELECT_TYPE must be set to a valid value and cannot be left at 0.
	Resource block	The actual mode of the Resource block is OOS. See Resource Block Diagnostics for corrective action.
	Schedule	Block is not scheduled and therefore cannot execute to go to Target Mode. Typically, BLOCK_ERR will show "Power-Up" for all blocks that are not scheduled. Schedule the block to execute.
Status of output is BAD	Inputs	All inputs have Bad status
	OP selected	OP_SELECT is not set to 0 (or it is linked to an input that is not 0), and it points to an input that is Bad.
	Min good	The number of Good inputs is less than MIN_GOOD.
	Block is in OOS mode	Change mode to Auto
Block alarms will not work.	Features	FEATURES_SEL in the resource block does not have Alerts enabled. Enable the Alerts bit.
	Notification	LIM_NOTIFY in the resource block is not high enough. Set equal to MAX_NOTIFY.
	Status Options	STATUS_OPTS has Propagate Fault Forward bit set. This should be cleared to cause an alarm to occur.
Cannot set HI_LIMIT, HI_HI_LIMIT, LO_LIMIT, LO_LO_LIMIT	Scaling	Limit values are outside the OUT_SCALE.EU0 and OUT_SCALE.EU100 values. Change OUT_SCALE or set values within range.

Index

Numerics

2-Inch Pipe Stand Mounting	7
-------------------------------------	---

A

Alarms	
Configuration	21
Analog Input	
Configuration	25
Ground	14
Analog Input Function Block	93
Advanced Features	100
Alarm Detection	99
Application Information	100
Block Errors	98
Configuration	25
Direct	97
Filtering	97
Functionality	96
Indirect	97
Indirect Square Root	98
Modes	98
Automatic	99
Manual	99
Out of Service	99
Parameters	93
Signal Conversion	97
Simulation	96
Status Handling	99
Troubleshooting	101
Wiring Diagram	11

B

Block Operation	87
Alerts	87
Instrument Specific Blocks	87

C

Cable Glands	
Installation	17
Commissioning	48
Tag	16
Conduit Entries	18

Configuration	20
Alarms	21
Analog Transmitters	25
Analog Input Block	25
Multiple Analog Input Block	25
Block	26
Custom	20
Damping	21
Differential Sensor Blocks	21
Methods	20
Monitoring Applications	
Single Selection	23
Typical	23
Reset	49
Restart Processor	49
Restart with Defaults	49
Resource Block	26
Standard	20
Transmitter	20
Connections	9
Analog Inputs	10
Millivolt Inputs	10
Ohm Inputs	10
Power Supply	12
RTD Inputs	10
Thermocouple Inputs	10

D

Damping	
Configuration	21
Device Descriptions	86
Differential Sensor Blocks	
Configuration	21
Differential Transducer Block	
Troubleshooting	50
DIN Rail	
Mounting	6
Drawing	
Switch Location	15
Drawings	
848T Analog Connector	11
Analog Input Wiring	11
Block Diagram	48
Block Internal Structure	86
Cable Gland Installation	17
Commissioning Tag	16
Conduit Entries Installation	18
Installation	76
Sensor Wiring	10
Transmitter Label	12
Transmitter Wiring	9

F			
FOUNDATION fieldbus	47	Installation	17
Addressing	89	Intrinsically Safe	75
Block Operation	87	Non-Incendive	75
Alerts	87	Using Cable Glands	17
Instrument- Specific Blocks	87	Using Conduit Entries	18
Check	48		
Device Descriptions	86	J	
Function Block Scheduling	92	Junction Box	
Function Blocks	85	Mounting	6
Link Active Scheduler	88		
Network Communication	87	L	
Overview	85	Link Active Scheduler	88
Scheduled Transfers	90	Backup LAS	89
Troubleshooting	49	LAS Parameters	89
Unscheduled Transfers	91		
Function Blocks	85	M	
Analog Input	93	Maintenance	
Input Selector Function Block	110	Hardware	48
Multiple Analog Input	102	Communication Check	48
Scheduling	92	Power Check	48
		Reset Configuration	49
		Sensor Check	48
		Measurement Transducer Block	
		Parameters	38
		Monitoring Applications	
		Common Configurations	
		Single Selection	23
		Typical	23
		Mounting	6
		2-Inch Pipe Stand	7
		DIN Rail Without an Enclosure	6
		Panel with a Junction Box	6
		Multiple Analog Input	
		Configuration	25
		Multiple Analog Input Block	
		Troubleshooting	109
		Multiple Analog Input Function Block	
		Application Information	108
		Configuration	25
		Errors	106
		Filtering	105
		Functionality	104
		Modes	107
		Automatic	107
		Manual	107
		Out of Service	107
		Parameters	103
		Signal Conversion	105
		Direct	106
		Indirect	106
		Indirect Square Root	106
		Modes	107
		Simulation	104
		Status Handling	108
G			
Grounding	12		
Analog Device	14		
Grounded Thermocouple	14		
Shielded Wire	13		
Transmitter Enclosure	14		
Ungrounded mV	13		
Ungrounded RTD/Ohm	13		
Ungrounded Thermocouple	13		
H			
Hardware			
Maintenance	48		
Communication Check	48		
Power Check	48		
Reset Configuration	49		
Sensor Check	48		
I			
Input Selector Function Block	110		
Alarm Detection	114		
Application Information	116		
Block Execution	115		
Errors	113		
Functionality	113		
Modes	114		
Automatic	114		
Manual	114		
Out of Service	114		
Parameters	111		
Status Handling	115		
Troubleshooting	117		

N

Network Communication	87
Addressing	89
Function Block Scheduling	92
Link Active Scheduler	88
Scheduled Transfer	90
Unscheduled Transfer	91

O

Overview	2
FOUNDATION fieldbus	85
Manual	2
Transmitter	2

P

Performance specifications	54
Power Supply	12
Connections	12

R

Resource Block	
Alarm Detection	30
Configuration	26
Errors	30
Modes	30
Automatic	30
Out of Service (OOS)	30
Parameters	26
PlantWeb Alerts	
Recommended Actions	34
PlantWeb™ Alerts	31
advisory alarms	33
failed_alarms	31
maint_alarms	32
Troubleshooting	50

S

Scheduled Transfers	90
Client	90
Publisher	90
Report Distribution	90
Server	90
Subscriber	90
Security Switch	15
Senor	
Connection Check	48
Sensor	
Tag	16
Sensor Transducer Block	
Change Sensor Configuration	45
Sensor Calibration	45
Sensor Wiring Diagram	10
Shield Wire	
Ground	13

Simulate Enable Switch	15
Specifications	
performance	54
Surges	12
Switches	15
Security	15
Simulate Enable	15

T

Tagging	16
Commissioning	16
Sensor	16
Transmitter	16
Transducer Block	
Alarm Detection	38
Channel Definitions	36
Errors	37
Modes	37
Automatic	37
Out of Service	37
Status Handling	38
Transients	12
Transmitter	
Configuration	20
Tag	16
Transmitter Wiring Diagram	9
Troubleshooting	49
Analog Input Function Block	101
Differential Transducer Block	50
FOUNDATION fieldbus	49
Input Selector Function Block	117
Multiple Analog Input Block	109
Resource Block	50

U

Unscheduled Transfers	91
-----------------------------	----

W

Wiring	9
Communication Check	48
Power Check	48

*Standard Terms and Conditions of Sale can be found at www.rosemount.com/terms_of_sale
The Emerson logo and DeltaV are trademarks of Emerson Electric Co.
Rosemount, PlantWeb, and the Rosemount logotype are registered trademarks of Rosemount Inc.
HART is a registered trademark of the HART Communication Foundation.
FOUNDATION fieldbus is a registered trademark of the Fieldbus Foundation.
minifast and eurofast are registered trademarks of TURCK.
All other marks are the property of their respective owners.*

© 2014 Rosemount, Inc. All rights reserved.

**Emerson Process Management
Rosemount Measurement**
8200 Market Boulevard
Chanhassen MN 55317 USA
Tel (USA) 1 800 999 9307
Tel (International) +1 952 906 8888
Fax +1 952 906 8889

**Emerson Process Management
GmbH & Co.**
Argelsrieder Feld 3
82234 Wessling
Germany
Tel 49 (8153) 9390
Fax 49 (8153) 939172

**Emerson Process Management Asia
Pacific Private Limited**
1 Pandan Crescent
Singapore 128461
T (65) 6777 8211
F (65) 6777 0947
Enquiries@AP.EmersonProcess.com

**Beijing Rosemount Far East
Instrument Co., Limited**
No. 6 North Street,
Hepingli, Dong Cheng District
Beijing 100013, China
T (86) (10) 6428 2233
F (86) (10) 6422 8586

**Emerson Process Management
Latin America**
1300 Concord Terrace, Suite 400
Sunrise Florida 33323 USA
Tel +1 954 846 5030