

Thank you for purchasing our Insulation resistance tester.
This manual describes the specifications and handling precautions of the Insulation resistance tester.
Before using this product, thoroughly read this manual to understand how to use it properly.

- Model -
MY10-01, MY10-02, MY10-03, MY10-04, MY10-05

Contact information of Yokogawa offices worldwide is provided on the following sheet.
PIM 113-01Z2: Inquiries List of worldwide contacts

Store this manual in an easily accessible place for quick reference

All Rights Reserved. Copyright ©
1999, Yokogawa M&C Corporation,
2015, Yokogawa Meters & Instruments Corporation,
2017, Yokogawa Test & Measurement Corporation

YOKOGAWA
Yokogawa Test & Measurement Corporation

B3


Printed in China

IM MY10-E
8th Edition: Oct. 2017 (YMI)

1. Safety Precautions

This product is designed to be used by a person with specialized knowledge.
When operating the instrument, be sure to observe the cautionary notes given below to ensure correct and safe use of the instrument. If you use the instrument in any way other than as instructed in this manual, the instrument's protective measures may be impaired.
This manual is an essential part of the product; keep it a safe place for future reference.
YOKOGAWA is by no means liable for any damage resulting from use of the instrument in contradiction to these cautionary notes.

The following safety symbols are used on the instrument and in this manual.

 Danger! Handle with Care.
This symbol indicates that the operator must refer to an explanation in the user's manual in order to avoid risk of injury or death of personnel or damage to the tester.

WARNING


Indicates a hazard that may result in the loss of life or serious injury of the user unless the described instruction is abided by.

CAUTION

Indicates a hazard that may result in an injury to the user and/or physical damage to the product or other equipment unless the described instruction is abided by.

Note

Indicates information that is essential for handling the instrument or should be noted in order to familiarize yourself with the instrument's operating procedures and/or functions.

 High-voltage Terminal
This symbol indicates a dangerous voltage level (terminals with voltages exceeding 1000 volts must be so marked). Never touch the terminals.

 Alternating Current
This symbol indicates alternating current (AC).

 Double Insulation
This symbol indicates double insulation.

■ Always observe the following instructions. Failure to do so may result in electric shock or other dangers that may lead to serious injury or the loss of life.

WARNING

This instrument is a insulation resistance tester that can measure insulation resistance (AC voltage).
Do not use this instrument for other purpose.
Do not use the instrument if there is a problem with its physical appearance.

1. During Measurement of Insulation Resistance

• A high voltage is present at the probes. Do not touch the measured object or the earth or line terminal.

2. Immediately After Measurement of Insulation Resistance

• The probes or measured object may remain highly charged.
Do not touch them immediately after the completion of measurement.

3. During Measurement of AC Voltage

• Do not press the MEAS key while measuring the AC voltages.
• Voltage that exceeds the specified limit must not be applied to terminals.

4. Probe

• Use the probes supplied by Yokogawa with this tester.
• Do not use probes that have deteriorated or are defective.
• Remove the probes from the measured object before attaching/detaching the probes to/from the tester.

5. Insulation of Casing

• A puncture in the protective insulation may occur if there are any cracks or other damage in the casing as a result of the instrument having been dropped or knocked against another object.
Do not use the instrument before taking the necessary remedial measures; ask the manufacturer to repair it.

6. The Measured Object

• Turn off the power to the measured object before you begin measuring insulation resistance.
• Avoid touching any electrified parts while using the tester in a location with live electricity.
Safety protectors such as rubber-insulated gloves should be worn to prevent electrical shock when using the tester.

7. Operating Environment

• Do not operate the tester in an atmosphere where any flammable or explosive gas is present.
• Do not use the tester if there is condensation on it.

8. Do Not Remove the Casing or Disassemble

Do not open the case except when replacing batteries.
Only Yokogawa service personnel are authorized to remove the casing or disassemble or modify the instrument.
Do not attempt to repair the instrument yourself, as doing so is extremely dangerous.
When the instrument needs an internal inspection or calibration,
contact Yokogawa or the dealer from whom you purchased the instrument.

CAUTION

• The instrument is for domestic use (Class B) and meets the electromagnetic compatibility requirements.
• To verify the instrument's functionality, contact the tip of the earth probe and the line probe and then press the MEAS key.
Check that the resistance indication is 0 Ω. (Check that the instrument operates normally.)
If the indication is incorrect, it may lead to possible electrical shock or personal injury.

Measurement Categories

Measurement category of the MY10

WARNING

• This instrument is designed for measurement category III (CAT III).
• Do not use the instrument for measurements in location that fall under measurement category IV.

Measurement category of the Probes

Line probe (98001) With cap: 600 V CAT III Without cap: 600 V CAT II
Earth probe (98002) 600 V CAT III

WARNING

A cap is provided on the tip of the line probe.
Use the line probe with the cap on for safety (safety standard: EN61010-031).

Measurement category	Description	Remarks
O (None, Other)	Other circuits that are not directly connected to MAINS.	Circuits not connected to a mains power source.
CAT II	For measurements performed on circuits directly connected to the low-voltage installation.	Appliances, portable equipment, etc.
CAT III	For measurements performed in the building installation.	Distribution board, circuit breaker, etc.
CAT IV	For measurements performed at the source of the low-voltage installation.	Overhead wire, cable systems, etc.

2. Measuring Functions and Additional Features


Measuring Functions

- Measuring the insulation resistance
- Measuring AC voltages (sine wave at 50/60 Hz)

Additional Features

- Discharge feature
The tester is designed to begin discharging when the MEAS key is turned off.
The ALARM LED turns off when discharging is complete.
- Battery check
This function verifies if the battery voltages are within the valid ranges.
(When the battery is checked, the pointer must be within the BATT mark.)
- Phosphorescent scale plate
The indicator window lights up according to the intensity of light.
- Locking the MEAS key
Pulling the MEAS key up allows for continuous measurement over a prolonged period of time.

3. Components and Their Functions



1. Indicator window

2. MEAS key

3. BATT CHECK key

Verifies if the battery voltages are within the valid ranges.

4. Protective cover fitting

5. Zero adjustment (screw)

6. ALARM LED

• Discharge feature (On → Off)
When lit, it indicates that a capacitive component in the measured object remains electrified and will light up even if measurement has been completed.
It turns off when discharge is complete.

7. Battery cover setscrew

Undo to replace batteries.

8. Battery cover

9. Shoulder strap guide

The shoulder strap is passed through it.

10. Earth terminal

Connection for earth probe

11. Line terminal

Connection for line probe.

Note

GUARD function is not a standard function.

4. Before Measurement

WARNING

- Remove the probes from the measured object before attaching/detaching the probes to/from the tester.
- Make sure the MEAS key is off when attaching/detaching the probes to/from the tester.

1. Safety

- Read the handling precautions in this manual carefully.
- Make sure it is safe before starting measurement.

2. How to Read the Scale

- Read the value from the top-right of the scale.

3. Zero Adjustment

- Confirm that the pointer is at the center of the infinity sign (∞);
if it is, do not press the MEAS key.
- If it is not, adjust the pointer to indicate the center of the infinity sign (∞) with the zero adjustment screw using a slotted screwdriver.

4. Battery Voltage Verification

- Press the BATT CHECK key to make sure the battery voltages are within the valid ranges.
(When the battery is checked, the pointer must be within the BATT mark.)
- If the batteries are low, replace them as specified in the battery replacement section of this manual.

5. Connecting the Probes

- Plug the earth probe into the earth terminal.
- Plug the line probe into the line terminal.

5. Measuring the Insulation Resistance

5.1 Before Connecting the Probes

WARNING

- Turn off the power to the measured object before connecting the probes or measuring insulation resistance.
- Electrical charges may be present in the cables attached to or metal of the electrical equipment being tested.
Verify that the equipment is free from electrical charges before connecting the testing terminals.

5.2 Connecting the Earth Probe

- Securely connect the earth probe to the measured object's ground line
(if the measured object is not grounded, this process may be omitted).

5.3 Connecting the Line Probe

- Bring the line probe into contact with the measured object, and then press the MEAS key.
The pointer indicates the insulation resistance of the measured object.

Note

During measurement, exercise care to prevent the lead wire of the line probe from coming into contact with the ground, floor or any other object.
Not observing this precaution may result in a failure to measure the correct insulation resistance.

5.4 After Measurement

WARNING

- Immediately after measurement, electrical charges resulting from the applied testing voltage may remain present in the probes or measured object.
- The tester, therefore, is designed to automatically begin discharging electricity upon completion of measurement. Verify that the ALARM LED turns off when discharging is complete.

■ Locking the MEAS Key (for Continuous Measurement)

The MEAS key, when pulled up to the right, can be locked to ensure the key remains turned on. Use this mechanism when making continuous measurement over a prolonged period. Note, however, that leaving the key turned on for an unreasonably long time will accelerate the discharge of the batteries.

■ Battery Life (reference only)

For MY10-03 at rated 500 V/100 MΩ:
Approximately 10 hours when in continuously operation with central indication (approx. 2 MΩ; with standard supplied batteries).

Note

The data above is typical. Nevertheless, the battery life varies depending on the operating conditions. Check the batteries before measurement.

6. Measuring AC Voltages

⚠ WARNING

- Do not press the MEAS key while measuring AC voltages. Otherwise, it may result in a failure.
- Voltage that exceeds the specified limit must not be applied to terminals.

6.1 Connecting the Earth Probe

- Securely connect the earth probe to the measured object's ground line (if the measured object is not grounded, this process may be omitted).

6.2 Connecting the Line Probe

- Bring the line probe into contact with the measured object. The pointer indicates the AC voltage. Read the value on the voltage measurement scale (\sim V). If the voltage of 20 V AC or more is present between the earth and line terminals, the ALARM LED turns on.




Note

When measuring insulation resistance, the tester can also be used to verify that there is no voltage present at the measured object.

7. Using Protection Cover and Shoulder Strap

The tester comes with a protection cover and shoulder strap as standard accessories.

- The protection cover can be used as a front cover (for the indicator window) or as a bottom cover. (It is set as the front cover when delivered from the factory.)
- Using the shoulder strap allows you to position the tester in front of your chest for ease of reading. Pass the strap through the shoulder strap guide and adjust the length of the strap to allow you a good view of the tester.
- Remove the cover from the front, and attach it to the bottom using the fixing hole (B) on the surface of the cover. This is useful when the scale is too close to your body to see clearly (See the figure on the right).
- A belt on the cover which is fitted with pieces of Velcro, can be used to store the probes (Remove the probes from the tester terminals when storing them).



8. Battery Replacement

⚠ WARNING

- Remove the probes from the tester and then turn off the MEAS key before opening the casing to replace the batteries.
- Do not touch the MEAS key during replacement. Otherwise, a high voltage may be produced.

⚠ CAUTION

- Do not mix batteries of different types or new batteries with used ones.
- Always remove the batteries if the tester will not be used for a prolonged period of time. If you store the tester with the batteries left installed, fluid is likely to leak from them, resulting in a malfunctioning of the instrument.


<Procedure>

- Loosen the battery cover setscrew, and then slide the cover off of the main unit.
- Replace all of the 4 batteries at the same time and make sure the polarities of the new batteries are exactly as shown on the battery holder.
- After replacing the batteries, attach the battery cover and tighten the setscrew.

9. Specifications

Item	Model	MY10-01	MY10-02	MY10-03	MY10-04	MY10-05
Rating		125 V/20 MΩ	250 V/50 MΩ	500 V/100 MΩ	500 V/1000 MΩ	1000 V/2000 MΩ
Central Indication		0.5 MΩ	1 MΩ	2 MΩ	20 MΩ	50 MΩ
1st Effective Measuring Range		0.02 to 10 MΩ	0.05 to 20 MΩ	0.1 to 50 MΩ	1 to 500 MΩ	2 to 1000 MΩ
2nd Effective Measuring Range		0.01 to 0.02 MΩ 10 to 20 MΩ	0.01 to 0.05 MΩ 20 to 50 MΩ	0.05 to 0.1 MΩ 50 to 100 MΩ	0.5 to 1 MΩ 500 to 1000 MΩ	1 to 2 MΩ 1000 to 2000 MΩ
Lower Measuring Limit of Resistance		0.125 MΩ	0.25 MΩ	0.5 MΩ	1 MΩ	2 MΩ
Rated Current		1 to 1.2 mA	1 to 1.2 mA	1 to 1.2 mA	0.5 to 0.6 mA	0.5 to 0.6 mA
AC Voltage Measuring Range		0 to 250 V	0 to 300 V	0 to 500 V	0 to 500 V	0 to 500 V

<First and second effective measuring ranges>



<1> 1st effective measuring range
<2> 2nd effective measuring range

The values which belong to both the first and second ranges in the table above, are included in the first range.

Standard test conditions

Ambient temperature and humidity: 23 ±5°C at 45 to 75% RH
Position: Horizontal (within 5 degrees)
Influence of external magnetic field: Earth magnetism
Battery Voltage: Within effective range for the battery (When the battery is checked, the pointer must be within the BATT mark.)

Scale length: Approx. 78 mm

Tolerances under the above conditions

Resistance measurement: ±5% of reading within the 1st effective measuring range
±10% of reading within the 2nd effective measuring range
Infinity and zero indications: 0.7% or less of scale length
AC voltage: ±5% of the maximum value
No-load voltage: Within 130% of the rated voltage
Short-circuit current: 12 mA or less

Item	Limit	Test condition
Response time	3 sec or less	From the instant the resistors whose values correspond to central indication and zero indications are abruptly connected, to when the pointer reaches a level within tolerance
Friction	No friction is recognized	---
Effects of inclination	2% or less of the scale length	Deviation from the infinity indication when the tester is tilted from a horizontal position by 30 degrees
Effect of temperature	(1) 5% or less (2) 0.7% or less of scale length	(1) Deviation from central indication when ambient temperature is varied from 20°C by ±20°C (2) Deviation from infinity and zero indications when ambient temperature is varied from 20°C by ±20°C
Effect of humidity	Within tolerance	When the tester is left for 1 hour with the humidity at 90% RH
Effect of external magnetic field	3% or less of indication	The change of indication when an external field of 400 A/m DC is applied in the most affected direction
Effect of AC component of measuring terminal voltage	10% or less of indication	A change when a capacitor with 5μF ±10% is connected in parallel to a resistor corresponding to central indication connected
Insulation resistance	50MΩ or more (between electric circuits and outer case)	When tested at 500 V if the rated measuring voltage is 500 V or less or at a voltage identical to the rated voltage if the rated voltage exceeds 500 V
Dielectric withstand voltage	There must not be an abnormality. (between electric circuits and outer case)	When a sine wave, or the like, is applied between the electric circuits and the outer case at 5550 VAC and 50/60 Hz for 1 minute
Resistance to vibration	The specifications for tolerances, friction, and the effect of tilting must be met. There are no mechanical and electrical damage.	When a vibration frequency of 16.7 Hz and peak-to-peak amplitude of 4 mm is applied in the direction of the axis of the moving part for 1 hour
Resistance to shock	The specifications for tolerances, friction, and the effect of tilting must be met. There are no mechanical and electrical damage.	When shock of 1000 m/s ² is applied twice in the direction of axis of the moving part and in a direction perpendicular to the axis
Endurance	The specifications for tolerances and friction must be met.	When a resistor corresponding to the central indication is connected across the measuring terminals and the power switch is repeatedly turned on and off 10 000 cycles at a rate of about 300 cycles/hour
Input over-voltage protection	There must not be an abnormality.	When an AC voltage of 50/60 Hz at 1.2 times the rated measuring voltage is applied to the measuring terminals for 10 seconds

General Specifications

Operation temperature and humidity:	0 to 40°C at 90% RH or less (no condensation)
Storage temperature and humidity:	-10 to 60°C at 70% RH or less (no condensation)
Battery:	AA-size (4), [R6]
External dimensions:	Approx. 125 (W) × 103 (H) × 52.5 (D) mm
Weight:	Approx. 400 g (main unit and batteries only) Approx. 600 g (main unit, batteries, protective cover, earth probe and line probe)
Safety standards:	EN 61010-1, EN 61010-2-030, EN 61010-031 Measurement category III (CAT III) 600 V Insulation class II, Indoor use, altitude 2000 m or less, pollution degree 2
EMC Standard:	EN 61326-1 Class B, EN 61326-2-2 EMC Regulatory Arrangement in Australia and New Zealand EN55011 Class B Group 1 Korea Electromagnetic Conformity Standard (한국 전자기파 적합성 기준)
Effect of radiation immunity (at the strength of radio-frequency electromagnetic field of 3 V/m)	Insulation resistance measurement: 1st effective measuring range: ±10% of rdg 2nd effective measuring range: ±20% of rdg Infinity and zero indications: ±1.4% or less of scale length AC voltage measurement: ±10% of F.S.
Environmental standard:	EN 50581 Monitoring and control instruments including industrial monitoring and control instruments


■ Standard Accessories

Name	Model No.	Quantity
Protection cover	93013	1
Shoulder strap	99005	1
Line probe	98001	1
Earth probe	98002	1
Batteries	---	4
User's manual	IM MY10-E	1

■ Optional Accessories

Name	Model No.	Description
1. Spare probe tip for the line probe (Model 98001)	99011	105 mm, breaker pin
2. Hard case	93015	Houses both the main unit, the line probe and the earth probe.
3. Accessory bag	B9108XA	Soft case, approx. 100 (W) 190 (H) 40 (D) mm

■ External Dimensions



Note

If the breaker pin (99011) is attached on the Line probe, detach the cap from Line probe.

10. Maintenance

■ Storage Conditions

- Temperature and humidity: -10°C to 60°C at 70% RH or less
- Remove the batteries before storing the tester.
- Avoid storing the tester in a location where there is: moisture; exposure to direct sunlight; a high-temperature heat source nearby; exposure to severe mechanical vibrations; a large amount of dust and/or salt, or a corrosive gas.

■ Removal of Dirt

Do not use volatile solvents (such as paint thinners or benzene) as they are likely to cause discoloration. Wipe off dirt with a cloth dampened with water or alcohol.

■ Calibration Cycle

It is recommended that the tester be calibrated once every year for correct operation; ask Yokogawa to do the periodic calibration for you.